PROPERTY OF
Electro Rent Corporation
11-A

INSTRUCTION MANUAL
2750L-PT/4500L-PT

California INSTRUMENTS

Invertron® AC POWER EQUIPMENT

California Instruments Corporation

9025 Balboa Avenue, San Diego, CA 92123-1509
(619) 279-8620 (800) 442-7693
FAX (619) 279-8139

[redacted]

California INSTRUMENTS

Revision C
February 1994
Copyright © 1993, 1994
by California Instruments.
All rights reserved.
P/N 4009-317

INSTRUCTION MANUAL
2750L-PT/4500L-PT

Invertron®

PAGE

TABLE OF CONTENTS

SECTION	TITLE	PAGE
1	INTRODUCTION AND SPECIFICATIONS.	1
	1.1 INTRODUCTION.	1
	1.2 GENERAL DESCRIPTION	1
	1.3 ACCESSORY EQUIPMENT/RACK SLIDES	3
	1.4 SPECIFICATIONS.	3
2	INSTALLATION AND ACCEPTANCE.	14
	2.1 UNPACKING	14
	2.2 POWER REQUIREMENTS.	14
	2.3 MECHANICAL INSTALLATION	14
	2.4 INPUT WIRING.	14
	2.5 OUTPUT CONNECTIONS.	14
	2.6 OUTPUT VOLTAGE RANGES	20
	2.7 FUNCTION TEST	21
3	OPERATION.	24
	3.1 GENERAL	24
	3.2 FRONT PANEL CONTROLS.	24
	3.3 FRONT PANEL INDICATORS.	24
	3.4 REAR PANEL CONNECTIONS.	26
	3.4.1 POWER INPUT.	26
	3.4.2 POWER OUTPUT	26
	3.4.3 EXTERNAL SENSE	26
	3.4.4 IEEE-488 CONNECTOR	28
	3.4.5 SYSTEM INTERFACE	28
	3.4.6 AUXILIARY OUTPUT (AX Option) . . .	31
	3.4.7 CLOCK.	31
	3.4.8 LOCK	31
	3.4.9 DFI.	31
	3.5 FRONT PANEL PROGRAMMING	32
	3.5.1 KEYPAD	32
	3.5.2 DISPLAY SCREENS.	34
	3.5.3 TO PROGRAM OUTPUT VOLTAGE AMPLITUDE (AMP=5)	39
	3.5.4 TO PROGRAM FREQUENCY (FRQ=6) . . .	39
	3.5.5 TO PROGRAM OUTPUT PHASE ANGLE (PHZ=7)	40
	3.5.6 TO PROGRAM CURRENT LIMIT (CRL=8) .	41
	3.5.7 TO PROGRAM VOLTAGE RANGE (RNG=4) .	41
	3.5.8 TO PROGRAM RAMP OR STEP FUNCTIONS (RMP=9)	41
	3.5.9 TO PROGRAM THE OUTPUT WAVEFORM (WVF=3) (SQW Option).	44
	3.5.10 TO PROGRAM EXTERNAL SYNCHRONIZATION (SNC=1)	44
	3.5.11 TO PROGRAM THE DROP CYCLES (DRP=2).	45

SECTION	TITLE	PAGE
	3.5.12 TO PROGRAM TOTAL HARMONIC DISTORTION (THD=0).	45
	3.5.13 TO PROGRAM REGISTERS AND RAMPS . .	46
	3.5.14 REGISTER LINKING	47
	3.5.15 TO PROGRAM SIMULTANEOUS RAMPS. . .	48
	3.5.16 ERROR MESSAGES	49
	3.5.17 TO PROGRAM FREQUENCY, VOLTAGE, VOLTAGE RANGE AND CURRENT LIMIT DEFAULT VALUES	50
	3.5.18 TO PROGRAM 1 OR 3 PHASE MODE MODE (MOD=30) (MODE OPTION) . .	51
	3.5.19 TO PROGRAM THE START-UP POINT. . .	51
3.6	TO MEASURE THE OUTPUT	52
	3.6.1 TO MEASURE THE OUTPUT VOLTAGE (VLT=21).	52
	3.6.2 TO MEASURE THE OUTPUT CURRENT (CUR=22).	52
	3.6.3 TO MEASURE THE OUTPUT POWER (PWR=23).	52
	3.6.4 TO MEASURE THE OUTPUT POWER FACTOR (PWF=24)	52
	3.6.5 TO MEASURE THE OUTPUT APPARENT POWER (APW=25)	52
	3.6.6 TO MEASURE THE OUTPUT FREQUENCY (FRQ=26).	52
	3.6.7 TO MEASURE THE OUTPUT PHASE ANGLE (PZM=27).	53
	3.6.8 ELAPSED TIME (ELT=11).	53
3.7	REMOTE CONTROL.	53
	3.7.1 UNIT ADDRESS	53
	3.7.2 MESSAGE FORMAT	54
	3.7.3 NUMERIC FIELD DATA	57
	3.7.4 PROGRAM HEADERS.	57
	3.7.5 TO PROGRAM OUTPUT VOLTAGE AMPLITUDE (AMP)	63
	3.7.6 TO PROGRAM FREQUENCY (FRQ)	63
	3.7.7 TO PROGRAM PHASE ANGLE (PHZ) . . .	63
	3.7.8 TO PROGRAM CURRENT LIMIT (CRL) . .	64
	3.7.9 TO PROGRAM DROP CYCLE (DRP). . . .	64
	3.7.10 TO PROGRAM TOTAL HARMONIC DISTORTION.	64
	3.7.11 TO PROGRAM HOLD OFF COMMAND (HLD).	64
	3.7.12 TO PROGRAM RAMP OR STEP OPERATIONS.	64
	3.7.13 TO PROGRAM A REGISTER (REG). . . .	66
	3.7.14 TO RECALL A REGISTER (REC)	66
	3.7.15 TO PROGRAM VOLTAGE RANGE (RNG) . .	67
	3.7.16 TO PROGRAM EXTERNAL SYNCHRONIZATION (SNC)	67

SECTION	TITLE	PAGE
	3.7.17 TO TRIGGER AN OPERATION (TRG). . .	67
	3.7.18 TO PROGRAM THE OUTPUT WAVEFORM (WVF) (Optional) . . .	68
	3.7.19 TO OPEN (OPN) AND CLOSE (CLS) THE OUTPUT RELAY.	68
	3.7.20 TO PROGRAM THE DEFAULT FREQUENCY (FLM A).	68
	3.7.21 TO PROGRAM THE DEFAULT OUTPUT VOLTAGE (INI A) . .	68
	3.7.22 TO PROGRAM THE DEFAULT CURRENT LIMIT (INI C).	69
	3.7.23 TO PROGRAM THE DEFAULT VOLTAGE RANGE (ALM A).	69
	3.7.24 TO PROGRAM 1 OR 3 PHASE MODE (MOD)	69
	3.7.25 TO TALK (TLK) MEASURED AND PROGRAMMED DATA	69
	3.7.26 TO TALK THE MEASURE OUTPUT VOLTAGE (TLK VLT)	70
	3.7.27 TO TALK THE MEASURE OUTPUT CURRENT (TLK CUR)	70
	3.7.28 TO TALK THE MEASURE OUTPUT POWER (TLK PWR)	70
	3.7.29 TO TALK THE MEASURE OUTPUT POWER FACTOR (TLK PWF). . . .	74
	3.7.30 TO TALK THE MEASURED OUTPUT APPARENT POWR (TLK APW)	74
	3.7.31 TO TALK THE MEASURE OUTPUT FREQUENCY (TLK FQM)	74
	3.7.32 TO TALK THE MEASURED OUTPUT PHASE ANGLE (TLK PZM)	74
	3.7.33 MESSAGE SEPARATORS	74
	3.7.34 SERVICE REQUEST.	75
	3.7.35 SERIAL POLL STATUS BYTE.	75
	3.7.36 END OF STRING.	75
	3.7.37 ERROR MESSAGES	75
	3.7.38 GROUP EXECUTE TRIGGER.	76
	3.7.39 HEWLETT PACKARD SERIES 80 PROGRAM EXAMPLES.	79
4	CALIBRATION PROCEDURE.	81
	4.1 GENERAL	81
	4.2 TEST EQUIPMENT.	82
	4.3 PERIODIC CALIBRATION.	87
	4.3.1 VOLTAGE CALIBRATION.	87
	4.3.2 VOLTAGE MEASUREMENT CALIBRATION. .	88
	4.3.3 CURRENT MEASUREMENT CALIBRATION. .	90
	4.3.4 POWER MEASUREMENT CALIBRATION. . .	91
	4.3.5 REMOTE MEASUREMENT CALIBRATION . .	92

SECTION	TITLE	PAGE
	4.4 NONPERIODIC CALIBRATION	92
	4.4.1 OUTPUT FREQUENCY CALIBRATION . . .	92
	4.4.2 GAIN BALANCE ADJUSTMENT.	93
	4.4.3 CURRENT TRANSFORMER ADJUSTMENT . .	96
	4.4.4 LOAD BALANCE ADJUSTMENT.	99
	4.4.5 CURRENT LIMIT CALIBRATION.	101
	4.4.6 OUTPUT PHASE ANGLE CALIBRATION . .	102
5	THEORY OF OPERATION.	104
	5.1 GENERAL	104
	5.2 OVERALL DESCRIPTION	104
	5.3 INPUT POWER SUPPLY.	104
	5.4 AUXILIARY POWER SUPPLY.	106
	5.5 CURRENT LIMIT BOARD	106
	5.6 INDICATOR BOARD	106
	5.7 RANGE RELAY BOARD	107
	5.8 AMPLIFIER MODULES	107
	5.9 OSCILLATOR MODULE	107
	5.10 CPU/GPIB BOARD.	109
	5.11 PHASE A/REF BOARD	109
	5.12 PHASE B/C BOARD	109
	5.13 DISPLAY BOARD	109
6	MAINTENANCE AND TROUBLESHOOTING	111
	6.1 GENERAL	111
	6.2 POOR VOLTAGE ACCURACY	111
	6.3 POOR OUTPUT VOLTAGE REGULATION.	111
	6.4 OVERTEMPERATURE LAMP ON	112
	6.5 OVERLOAD LAMP ON.	112
	6.6 CAN'T PROGRAM AC POWER SYSTEM ON GPIB . .	113
	6.7 DISTORTED OUTPUT.	113
	6.8 NO OUTPUT	113
	6.9 MODULE REMOVAL.	114
	6.10 OSCILLATOR MODULE REMOVAL/REPLACEMENT . .	114
	6.11 AMPLIFIER REMOVAL/REPLACEMENT	115
7	REPLACEABLE PARTS	117
	7.1 GENERAL	117
	7.2 ORDERING INFORMATION	117
8	MIL-STD-704D.	119
	8.1 GENERAL.	119
	8.2 INITIAL SETUP.	119
	8.3 TEST PERFORMED	119
	8.3.1 STEADY STATE TEST	119
	8.3.2 TRANSIENT	119
	8.3.3 ABNORMAL OPERATION.	119
	8.3.4 EMERGENCY OPERATION	120
	8.4 KEYPAD ENTRY	120

SECTION	TITLE	PAGE
	8.5 GPIB OPERATION	122
	8.6 TEST SPECIFICATION	123
	8.6.1 STEADY STATE.	123
	8.6.2 TRANSIENT	124
	8.6.3 ABNORMAL.	125
	8.6.4 EMERGENCY	126
	8.6.5 MIL704D TEST.	127
9	2-PHASE OPTION (2P)	136
	9.1 GENERAL.	136
10	RTCA/DO-160C.	137
	10.1 GENERAL.	137
	10.2 INITIAL SETUP.	137
	10.3 TEST PERFORMED	137
	10.3.1 NORMAL STATE	137
	10.3.2 EMERGENCY TEST	137
	10.3.3 ABNORMAL TEST.	137
	10.4 KEYPAD ENTRY	138
	10.5 GPIB OPERATION	140
	10.6 TEST SPECIFITION	141
	10.6.1 NORMAL STATE.	141
	10.6.2 EMERGENCY TEST.	142
	10.6.3 ABNORMAL STATE.	143

LIST OF ILLUSTRATIONS

FIGURE	DESCRIPTION	PAGE
1-1	MODEL 2750L-PT/4500L-PT	2
2-1	2750L/4500L REAR PANEL CONNECTIONS	15
2-2	SYSTEM INTERCONNECTION DIAGRAMS	16, 17, 18, 19
2-3	FUNCTION TEST SETUP	23
3-1	FRONT PANEL CONTROLS AND INDICATORS	25
3-2	2750L/4500L REAR PANEL CONNECTIONS	27
3-3	FUNCTION SYNC CONNECTIONS	32
3-4	KEYPAD	32
3-5	REMOTE COMMAND SEQUENCES	58
4-1	INTERNAL ADJUSTMENTS AND JUMPER LOCATIONS	84
4-2	EQUIPMENT HOOKUP FOR PERIODIC CALIBRATION	89
5-1	AC POWER SYSTEM BLOCK DIAGRAM	105
5-2	PROGRAMMABLE OSCILLATOR MODULE	108
6-1	MODULE LOCATION	116

LIST OF TABLES

TABLE	DESCRIPTION	PAGE
1-1	OUTPUT VA PER PHASE	1
1-2	SPECIFICATIONS 4500L-PT	4
2-1	MAXIMUM LENGTH OF OUTPUT WIRES	20
3-1	POWER OUTPUT (TB1)	26
3-2	EXTERNAL SENSE PIN CONNECTIONS (J6)	26
3-3	SYSTEM INTERFACE PIN CONNECTIONS (J7)	28
3-4	KEYBOARD KEY DESCRIPTION	33
3-5	OUTPUT PARAMETER SCREENS	35
3-6	MEASUREMENT SCREENS	36
3-7	CALIBRATION SCREENS	37
3-8	CONFIGURATION SCREENS	38
3-9	FRONT PANEL DISPLAY ERROR MESSAGES	49
3-10	COMMONLY USED GPIB ABBREVIATIONS	55
3-11	UNIT ADDRESS GROUP	56
3-12	PROGRAM HEADERS	60
3-13	TLK ARGUMENTS	71
3-14	EXAMPLE TALK RESPONSE (3-PHASE SYSTEM)	73
3-15	STATUS BYTE VALUES	77
3-16	HP SERIES 80 CONTROLLER STATEMENTS	78
4-1	SETUP LOAD VALUES	85
4-2	AMPLIFIER GAIN BALANCE ADJUSTMENTS	96
4-3	CURRENT LIMIT ADJUSTMENT	101
6-1	TROUBLESHOOTING	110

SECTION 1

INTRODUCTION AND SPECIFICATIONS

1.1 INTRODUCTION

This instruction manual contains information on the installation, operation, calibration, and maintenance of all power systems that use the 4500L-PT or the 2750L-PT.

1.2 GENERAL DESCRIPTION

The power system uses a high efficiency power source that provides a low distortion output. The output can be configured in either a single or three-phase configuration.

A number of Power Sources can be configured to supply full output power up to 30000VA. Table 1-1 shows the output VA per phase for each of the available power system models. The table also shows that increased power is available at a reduced operating temperature of 35°C.

MODEL	NUMBER 4500Ls	OUTPUT VA PER PHASE 50°C	OUTPUT VA PER PHASE 35°C	NUMBER PHASES
2750L-1PT		2700	3000	1
2750L-3PT		900	1000	3
4500L-1PT	1	4500	5000	1
4500L-3PT	1	1500	1667	3
9000L/2-1PT	2	9000	10000	1
9000L/2-3PT	2	3000	3333	3
13500L/3-1PT	3	13500	15000	1
13500L/3-3PT	3	4500	5000	3
27000L/6-1PT	6	27000	30000	1
27000L/6-3PT	6	9000	10000	3

TABLE 1-1

OUTPUT VA PER PHASE

Full power is available at the maximum output voltage on either of two voltage ranges. The standard voltage ranges are 135 and 270. Three optional voltage range pairs are available: 67.5/135, 156/312 and 200/400.

All "PT" Power systems will deliver full power from 45 to 550 Hz. The 4500L and 2750L is illustrated in Figure 1-1.

The output frequency can be programmed down to 17 Hz at a reduced output voltage.

1.3 ACCESSORY EQUIPMENT/RACK SLIDES

Zero Manufacturing Company Model CTN-1-20-E94 rack slides may be attached to the sides of the power source using 8-32 X 3/8 flat head screws.

1.4 SPECIFICATIONS

Table 1-2 contains the operation specifications of the AC Power System. All specifications are tested in accordance with standard California Instruments test procedures. The following specifications apply for operation at 100% of full scale voltage, constant line voltages and under no-load conditions unless specified otherwise. All voltages are measured at the External Sense lines.



FIGURE 1-1

CALIFORNIA INSTRUMENTS 4500L/2750L

TABLE 1-2

SPECIFICATIONS 4500L-PT, 2750L-PT

(All specifications apply using external sense, 23 ±5°C, constant line and load conditions unless specified otherwise, after 30 minute warm-up.)

ELECTRICAL

OUTPUT SPECIFICATIONS

MODEL	POWER (At full output voltage) TOTAL		POWER (At full output voltage) PER PHASE		CURRENT PER PHASE VOLTAGE RANGE 135		CURRENT PER PHASE VOLTAGE RANGE 270	
	50°C	35°C	50°C	35°C	50°C	35°C	50°C	35°C
2750L-3	2700	3000	900	1000	6.66	7.4	3.33	3.7
2750L-1	2700	3000	2700	3000	20.0	22.22	10.00	11.11
4500L-3	4500	5000	1500	1667	11.12	12.34	5.56	6.17
4500L-1	4500	5000	4500	5000	33.34	37.04	16.67	18.52
9000L/2-3	9000	10000	3000	3333	22.24	24.68	11.12	12.34
9000L/2-1	9000	10000	9000	10000	66.66	74.08	33.33	37.04
13500L/3-3	13500	15000	4500	5000	33.34	37.04	16.67	18.52
13500L/3-1	13500	15000	13500	15000	100.0	111.2	50.0	55.6
27000L/6-3	27000	30000	9000	10000	66.66	74.08	33.33	37.04
27000L/6-1	27000	30000	27000	30000	200.0	222.2	100.0	111.1

NOTE: Increased current at 35°C is available up to 2000 Hz.

For other Voltage Ranges: Current per phase = VA (per phase)/Voltage Range

Power factor: 0 to unity at full rated output VA

Peak Repetitive Current: 2.5 times the maximum TRMS current at 50°C (for 2750L, 4 times TRMS current at 50°C

Peak Non-repetitive (10ms) Current: 2.7 times the maximum TRMS current at 50°C (for 2750L, 4 times the TRMS current at 50°C)

Voltage range: 135 and 270 (Standard)
67.5 and 135 (LV Option)
156 and 312 (HV Option)
200 and 400 (EHV Option)

OUTPUT SPECIFICATIONS (continued)

Total Distortion:
(Maximum for all harmonics and noise to 300 KHz at full scale voltage with linear load)

45 Hz to 550 Hz: 1% THD

Line regulation: ±2% of full scale for ±10% line change

Load regulation:

45 Hz to 99.9 Hz: -.5% of full scale from no load to full load
(-.6% for 35°C load current)

100 Hz to 550 Hz: -2.0% of full scale from no load to full load
(-2.2% for 35°C load current)

Load regulation (EHV OPTION)

45 Hz to 99.9 Hz: -1.0% of full scale from no load to full load.
(-1.2% for 35°C load current)

100 Hz to 550 Hz: -3.0% of full scale from no load to full load.
(-3.3% for 35°C load current)

Voltage accuracy (no-load, 23°C)
±0.7% of range
±2 volts from 5 to 200 volts (EHV option)
±3.5 volts from 200 to 400 volts (EHV option)

Add 2% of programmed value below 45 Hz.

Frequency Range:

At Full Scale Voltage 45 Hz to 550 Hz

At less than Full Scale Voltage: Refer to graph below)



OUTPUT SPECIFICATIONS (continued)

Frequency accuracy: ±0.001% of programmed value

Frequency resolution: 0.01 Hz to 99.99 Hz
0.1 Hz to 550 Hz

Phase angle accuracy (With the same load on each phase):

Phase B and C relative to phase A: ±2 degrees to 2 KHz
±3 degrees to 5 KHz

PROTECTION (No automatic recovery)

Output overload:

From a steady-state condition: Immediate default with relays open.

From a programmed voltage: Immediate default with relays open after default .1 sec delay. The delay may be set from 0 to 1 sec.

Output short circuit: Immediate default with no automatic recovery.

Input Overvoltage: Causes the circuit breaker to trip.

Loss of Input phase: No output for loss of Phase B or C. Normal operation at reduced power with loss of Phase A.

Sense line fault: Immediate default of programmed output.

Temperature: Immediate default.

MEASUREMENTS (at 23°C)

Voltage accuracy: ±10 Digits of resolution

Voltage resolution: 0.1 volt for 1 digit

	MODEL	
	2750L-1PT-EHV 2750L-3PT, 4500L-3PT	All Other Models
Current accuracy:	±10 Digits of resolution	
Current resolution:	0.01 Amp	0.1 Amp
True power accuracy:	±10 Digits of resolution	
True power resolution:	1 Watt	0.01 Kw
Apparent power resolution:	1 VA	0.01 KVA
Power factor resolution:	.001	

MEASUREMENTS (continued)

Frequency	ACCURACY (Hz)	RESOLUTION (Hz)
45 to 99.99 Hz	±0.02	0.01
100 to 499.9 Hz	±0.2	0.1
500 to 550 Hz	±0.5	0.1

NOTE: For frequencies below 45 Hz, add 2% of measured value to measurement accuracy specification.

Phase angle accuracy: ±2.0 degrees

Phase angle resolution: 0.1 degree

SUPPLEMENTAL SPECIFICATIONS

LINE INPUT (for each 4500L or 2750L)

Voltage: 187 to 252V_{L-L} three-phase
2750L: 187 to 252V_{L-L} three-phase or 1-phase
UP Option: 342 to 456V_{L-L} three-phase

Current (PF=.6, EFF=75%, V line=187, full load): 31 Amps
2750L-3ø: 19 Amps
2750L-1ø: 29 Amps

Frequency: 47 to 400 Hz

Efficiency: 75% (typical)

Surge Current:
(turn-on, V_{L-L} = 252): 178 Amps

Full current range:



Output noise voltage (20 KHz to 1 MHz at full-load):
200 millivolts RMS (typical)

Voltage temperature coefficient: ±0.05 volts per °C

SUPPLEMENTAL OUTPUT SPECIFICATIONS (continued)

Voltage stability (24 hours, at constant line, load and temp.):
±0.25% of range

Voltage Settling Time: (from start of voltage change to final value.) No-load and Full-load:
0.5 milliseconds

Steady-State Output Impedance:

45 to 100 Hz: (Voltage Range) x (0.006)/Full-load current
100 to 550Hz: (Voltage Range) x (0.022)/Full-load current

Frequency Temperature Coefficient: ±5 ppm of value per °C

Frequency Stability: ±15 ppm of value per year

Functions	Range	Resolution	Initialization
[1]Voltage	0 to range	0.1	0.0
Voltage range	135/270	0.1	135
[1]Phase angle	0 to 999.9	0.1	B = 240 C = 120
[1]Distortion	0 to 20%	1	0
Current limit holdoff time (GPIB only)	0 to 1 second	0.01 sec	0.1 sec
[1]Drop Cycles	0 to 5	1	0
Phase A drop point	0 to 999.9	0.1 degree	last value
Output relay	Open or Close		Open
External Sync	Internal or External		Internal
Storage Registers	Registers 0 through 15		
Frequency	45 to 55 Hz	0.01 to 99.99 0.1 to 550.0	60 Hz

NOTE: [1]Independent control for each output phase

SUPPLEMENTAL OUTPUT SPECIFICATIONS (continued)

[1]Current Limit

MODEL	CURRENT LIMIT RANGE VOLTAGE RANGE 135 , 270	RESOLUTION	DEFAULT* (on 135 Range)
2750L-3PT	0 to 7.40, 3.70	0.01	7.40
2750L-1PT	0 to 22.22, 11.11	0.01	22.22
4500L-3PT	0 to 12.34, 6.17	0.01	12.34
4500L-1PT	0 to 37.04, 18.52	0.01	37.04
9000L/2-3PT	0 to 24.68, 12.34	0.01	24.68
9000L/2-2PT	0 to 37.04, 18.52	0.01	37.04
9000L/2-1PT	0 to 74.08, 37.04	0.01	74.08
13500L/3-3PT	0 to 37.04, 18.52	0.01	37.04
13500L/3-1PT	0 to 111.2, 55.6	0.1	111.2
27000L/6-3PT	0 to 74.08, 37.04	0.01	74.08
27000L/6-1PT	0 to 222.2, 111.1	0.1	222.2

For other Voltage Ranges: Current Limit Range = (VA per phase)/Voltage Range

Accuracy: -0 to +15% of programmed value

NOTE: [1]Independent control for each output phase

NOTE (*) Customer access to Initial/Default values for:

Frequency, Voltage, Voltage Range and Current Limit

SUPPLEMENTAL SPECIFICATIONS

Isolation: Line input to output: >500 VRMS

Front panel controls:

Power On/Off circuit breaker

Keypad: 20-key keyboard

Analog Meter Phase Selection Switch

Bus: IEEE-488 (GPIB)

Subsets; SH1, AH1, T6, L3, SR1, RL2, DC1, DT1

Codes and Formats:

Numeric Representation: NR1, NR2 or NR3

Header: HR1 or HR2 (upper or lower case)

Message Separators: SR1

Data transfer rate: 200K bytes per second

SUPPLEMENTAL SPECIFICATIONS (continued)

Language: A California Instruments language which is upward compatible from other C.I. products.

OTHER PROGRAMMABLE FUNCTIONS

Functions:

Register linking

Calibration of Phase and measurement functions.

Ramp/Sweeps of Voltage, Frequency, Phase and Current Limit up to 2 functions simultaneously.

Service request (GPIB): Service Request for output faults, syntax errors, end of measurement and end of program execution.

Group execute trigger (GPIB): Trigger setups and terminate programs.

Status reporting: Serial Poll Status Byte and error messages.

Output Relay Controlled by GPIB. Normally open at power-up. Closed when the first function is programmed from the front panel keypad.

External sense: Compensates for up to a 10% drop in the load lines.

Function Sync Output: A 400 uS logic low output when any output is programmed.

External Amplitude Modulation: 0 to 5 VRMS, 45 to 5 KHz input will generate 0 to 11% modulation of the output.

External Sync: A 5 volt, 45 to 5 KHz, 5 milliamp TTL input. The output will track the frequency and phase of this input. Loss of this input will cause the output to default.

Indicators: 32 character LCD display, Output Overload, Overtemperature Power On, High Voltage Range.

Dimensions: 10.5 inches (26.7 cm) high, 23 inches (58.4 cm) deep and 19 inches (48.3 cm) wide.

Weight lbs (Kg): 175 (79.2)

Material: Aluminum for Front panel, rear panel and top cover. Steel for chassis.

SUPPLEMENTAL SPECIFICATIONS (continued)

Finish:

Front panel - painted gray 26440 per Federal Standard 595
Chassis - zinc plate type 2 class 2.
Rear panel and top cover - iridite.

Air intake/exhaust: Intake from both sides of chassis.
Exhaust to the rear.

Modularity: Oscillator, All amplifiers, DC power supplies, Current Limit Board Assembly, Range-Relay Board, All displays

Connectors

Input Power: Kulka terminal block, 9-85-5 (TB3)

Output Power: Kulka terminal block, 9-85-4 (TB1)

Auxiliary Output Power: Barrier Strip (TB2)

External Sense: AMP connector, 1-480705-0 (J6)

System Interface
(mating connector): 3M Connector 3366-1001 plug

System Interface: 3M connector, 3367-1000 (J7)

IEEE-488 connector: J5

Chassis slides: Zero Manufacturing Company Model CTN-1-20-E94

Operating temperature: 0°C to 50°C

Storage temperature: -40°C to +85°C

Operating altitude: 0 to 6000 Ft.

OPTIONS

Universal Input Power (UP option): 342 to 456 V_{L-L} three phase

Output Voltage Ranges: 156/312 (HV option)
67.5/135 (LV option)
200.0/400.0 (EHV option)

Square Wave (2750L-3PT, 4500L-3PT only) Performance from 50 Hz to 550 Hz:

Rise and Fall Time (10% to 90%): Less than 40 microseconds

Droop: Less than 1%

Overshoot (resistive load): Less than 20%

Mode: Allows power system to be programmed to a 1 or 3 phase output.

Auxiliary outputs (Option AX):

(All specifications at 23°C and verified with TRMS voltmeter. The Phase D sense lines must be connected to the Phase D output.)

Phase D:

Voltage: 26.0 Vrms fixed

Accuracy: ±2%

Current: 3.0 Amps (Max)

Frequency: 360 to 440 (Tracks the main outputs)

Phase: Tracks the Phase A output

Accuracy: ±1 degree. (All outputs at half load, 400 Hz)

Distortion: 1% THD maximum with linear load

Line Regulation: ±0.05% using external sense

Load Regulation: ±0.05% using external sense

Phase E

Voltage: 5.0 Vrms fixed

Accuracy: ±5%

Current: 5.0 Amps (Max)

Frequency: 360 to 440 Hz (Tracks the main outputs)

Phase: Tracks the phase A output with Phase D

Distortion: 1% THD maximum with linear load

Line Regulation: ±0.1% for 10% line change

Load Regulation: ±10% from no-load to full-load

MIL-STD-704D (Option 704D): Performs all tests described by MIL-STD-704D.

2-PHASE (Option 2P): Phase C leads phase A by 90 degrees.

RTCA/DO-160 (Option 160C): Performs all tests described by RTCA/DO-160C.

OPTIONS (continued)

SYSTEMS

MODEL	POWER PER PHASE (35°C)	MAX CURRENT PER PHASE (135V RANGE)
9000L-1PT	10000	74.08
13500L-1PT	15000	111.2
27000L-1PT	30000	222.2
9000L-3P	3333	24.68
13500L-3PT	5000	37.04
27000L-3PT	10000	74.08
9000L-2PT	5000	37.04

CAUTION

Voltages up to 480 VAC are available in certain sections of this power source. This equipment generates potentially lethal voltages.

DEATH

on contact may result if personnel fail to observe safety precautions. Do not touch electronic circuits when power is applied.

SECTION 2

INSTALLATION AND ACCEPTANCE

2.1 UNPACKING

Inspect the unit for any possible shipping damage immediately upon receipt. If damage is evident, notify the carrier. DO NOT return an instrument to the factory without prior approval. Do not destroy the packing container until the unit has been inspected for damage in shipment.

2.2 POWER REQUIREMENTS

The AC Power System has been designed to operate from a three-phase AC line voltage. The 2750L can operate from either a 3-phase or 1-phase input line. The input line voltage may be between 187 volts and 252 volts line-to-line. The frequency may be between 47 Hz and 440 Hz. Select an AC input line and hookup wire to the AC Power System that will deliver 20 amps per phase and still supply a minimum of 187 volts line-to-line (342 volts for UP option). Refer to Figure 2-2 for circuit breaker requirements of all multichassis power system.

2.3 MECHANICAL INSTALLATION

The power system has been designed for rack mounting in a standard 19 inch rack. The unit should be supported from the sides with optional rack slides. See Accessory Equipment/Rack Slides in paragraph 1.3. The cooling fan at the rear of the unit must be free of any obstructions which would interfere with the flow of air. A 2.5 inch clearance should be maintained between the rear of the unit and the rear panel of the mounting cabinet. Also, the air intake holes on the sides of the power source must not be obstructed. See Figure 1-1.

2.4 INPUT WIRING

The AC Power System must be operated from a three-wire three-phase service with a fourth wire for common. The common wire is connected to the chassis of the AC Power System. The mains source must have a current rating greater than or equal to the AC Power System circuit breaker, 20 amps. Refer to Figure 2-1 for the input power connections. Refer to Figure 2-2 for all multichassis power systems.

The 1-phase input for a 2750L must be connected between the øB and øC input terminals of TB3. These terminals are identified as terminals 2 and 3 in Figure 2-1



TB3

PIN	FUNCTION
1	3 PHASE INPUT
2	
3	
5	GROUND

TB1

PIN	FUNCTION
1	C OUTPUT
2	B OUTPUT
3	A OUTPUT
4	NEUTRAL

J6

PIN	FUNCTION
1	A SENSE
2	B SENSE
3	C SENSE
4	NEUT SENSE
5	D SENSE HI
6	D SENSE LO

FIGURE 2-1
2750L/4500L REAR PANEL CONNECTIONS


HI AND LO RESPECTIVELY AT THE LOAD OR AT TB1 THE PROGRAMMED OUTPUT VOLTAGE IS THE VOLTAGE ACROSS THE EXTERNAL SENSE POINT.
WHEN A PT OSCILLATOR IS INSTALLED, THE EXTERNAL SENSE MUST BE TIED DIRECTLY TO TB1
HI
LO
AWG 10 STRANDED WIRE OR LARGER ALL WIRES TO TB1 MUST BE OF EQUAL LENGTH ±1" (STRANDS 37/26)
TORQUE TO 35 IN. LBS. 12 PLACES
HI LO TB2A AC OUTPUT POWER
CABLE ASSY (4009-230-1 FOR 9000L/2-1 & 13500L/3-1) (4009-231-1 FOR 27000L/6-1)
CONNECT TO IEEE-488 CONTROLLER IF USED FOR REMOTE CONTROL
TERMINAL BLOCK (FURNISHED BY CUSTOMER)
AWG 8 STRANDED WIRE OR LARGER, TYP 3 PLACES (STRANDS 133/29)
AWG 10 STRANDED WIRE OR LARGER TYP 12 PLACES (STRANDS 37/26)
AC POWER INPUT
CB1 800AMP
TB1 AC POWER OUT
TB3 AC POWER IN
J7 INTERFACE
J6 EXT SENSE
J5 IEEE-488 (GPIB)
A1 4500L POWER SOURCE WITH OSCILLATOR
A2 4500L POWER SOURCE WITHOUT OSCILLATOR
A3 4500L
A4 4500L
A5 4500L
A6 4500L

SYSTEM	4500L MODELS USED	SYSTEM INTERCONNECT CABLE
4500L-1	A1	NONE
9000L/2-1	A1, A2	4009-230-1
13500L/3-1	A1, A2, A3	4009-230-1
27000L/6-1	A1, A2, A3, A4, A5, A6	4009-231-1

3. FOR 9000L/2-1 & 13500L/3-1 USE 100 AMP CB1. NO CB1 FOR 4500L-1
2. TB2A (9000L/2-1 & 13500L/3-1) MARATHON PART NUMBER 1422570.
   TB2A (27000L/6-1) MARATHON PART NUMBER 1432555.
   (SHIPPED WITH POWER SOURCE SYSTEM) NO TB1 FOR 4500L-1
1. SYSTEM INTERCONNECT SHOWN FOR 27000L/6-1 SYSTEM.
   FOR 13500L/3-1 SYSTEM ELIMINATE POWER SOURCES A4, A5 & A6.
   FOR 9000L/2-1 SYSTEM ELIMINATE POWER SOURCE A3
   ONE CONNECTOR OF CABLE ASSY 4009-230-1
   IS NOT TERMINATED FOR 9000L/2-1

FIGURE 2-2
SYSTEM INTERCONNECT
FOR ALL 1-PHASE SYSTEMS


THE EXTERNAL SENSE INPUT MUST BE CONNECTED TO THE AC OUTPUT POWER HI AND LO RESPECTIVELY AT THE LOAD OR AT TB1 THE PROGRAMMED OUTPUT VOLTAGE IS THE VOLTAGE ACROSS THE EXTERNAL SENSE POINT.
WHEN A PT OSCILLATOR IS INSTALLED, THE EXTERNAL SENSE MUST BE TIED DIRECTLY TO TB1
AWG 10 STRANDED WIRE OR LARGER ALL WIRES TO TB1 MUST BE OF EQUAL LENGTH ±1" (STRANDS 37/26)
ØA ØB ØC NEUT
J6
1 2 3 4
TB1
AC POWER OUT
ØC ØB ØA NEUT
A1
4500L POWER SOURCE WITH OSCILLATOR
EXT SENSE
J7
INTERFACE
J5
IEEE-488 (GPIB)
TB3
AC POWER IN
ØA ØB ØC NEUT GND
CABLE ASSY 4009-231-1
CONNECT TO IEEE-488 CONTROLLER IF USED FOR REMOTE CONTROL
A2
4500L POWER SOURCE WITHOUT OSCILLATOR
A3
4500L POWER SOURCE WITHOUT OSCILLATOR
A4
4500L POWER SOURCE WITHOUT OSCILLATOR
TERMINAL BLOCK (FURNISHED BY CUSTOMER)
TORQUE TO 35 IN. LBS. 17 PLACES
AWG 10 STRANDED WIRE OR LARGER TYP 12 PLACES (STRANDS 37/26)
AWG 8 STRANDED WIRE OR LARGER, TYP 3 PLACES (STRANDS 133/29)
CB1 100AMP
ØA ØB ØC NEUT GND
TB2A TB2B
AC OUTPUT POWER
AC POWER INPUT

SYSTEM	4500L MODELS USED	SYSTEM INTERCONNECT CABLE
4500L-3	A1	NONE
9000L/2-3	A1, A2	4009-230-1
18000L/4-3	A1, A2, A3, A4	4009-231-1

1. TB2A MARATHON PART NUMBER 1423570, TB2B MARATHON PART NUMBER 1422570. (SHIPPED WITH POWER SOURCE SYSTEM)

FIGURE 2-2
SYSTEM INTERCONNECT
4500L-3, 9000L/2-3, 18000L/4-3

THE LUAD UK A1 TB1
THE PROGRAMMED OUTPUT VOLTAGE
IS THE VOLTAGE ACROSS THE EXTERNAL SENSE POINT.
WHEN A PT OSCILLATOR IS INSTALLED, THE EXTERNAL
SENSE MUST BE TIED DIRECTLY TO TB1

ØA ØB ØC NEUT

AWG 10 STRANDED WIRE
OR LARGER ALL WIRES
TO TB1 MUST BE OF
EQUAL LENGTH ±1" TYP 12 PLACES
(STRANDS 37/26)

PART OF
CABLE ASSY
4009-231-1

CONNECT TO
IEEE-488
CONTROLLER
IF USED FOR
REMOTE CONTROL

TB1
AC POWER OUT
ØC ØB ØA NEUT

J6
EXT SENSE
1 2 3 4

J5
IEEE-488
(GPIB)

J7
INTERFACE

A1
4500L POWER SOURCE
WITH OSCILLATOR

A2
4500L POWER SOURCE
WITHOUT OSCILLATOR

A3
4500L POWER SOURCE
WITHOUT OSCILLATOR

TB3
AC POWER IN
ØA ØB ØC NEUT GND

CHASSIS GND
ØC IN
ØB IN
ØA IN

TORQUE TO 35 IN. LBS.
13 PLACES

ØA ØB ØC
TB2A
NEUT GND
TB2B
AC OUTPUT POWER

TERMINAL BLOCK
(FURNISHED BY CUSTOMER)

AWG 6 STRANDED WIRE
OR LARGER TYP 3 PLACES
(STRANDS 133/29)

CB1
200 AMP

AC POWER INPUT
ØA
ØB
ØC
NEUT
GND

ØA IN
ØB IN
ØC IN

CHASSIS GND

AWG 10 STRANDED WIRE
OR LARGER TYP 24 PLACES
(STRANDS 37/26)

A4
4500L POWER SOURCE
WITHOUT OSCILLATOR

A5
4500L POWER SOURCE
WITHOUT OSCILLATOR

A6
4500L POWER SOURCE
WITHOUT OSCILLATOR

SYSTEM	4500L MODELS USED	SYSTEM INTERCONNECT CABLE
13500L/3-3	A1, A2, A3	4009-230-1
27000L/6-3	A1, A2, A3, A4, A5, A6	4009-231-1

1. TB2A MARATHON PART NO. 1423570,
   TB2B MARATHON PART NO. 1432555.
   (SHIPPED WITH POWER SOURCE SYSTEM)

FIGURE 2-2
SYSTEM INTERCONNECT
13500L/3-3, 27000L/6-3


THE EXTERNAL SENSE INPUT MUST BE CONNECTED TO THE AC OUTPUT POWER HI AND LO RESPECTIVELY AT THE LOAD OR AT TB1 THE PROGRAMMED OUTPUT VOLTAGE IS THE VOLTAGE ACROSS THE EXTERNAL SENSE POINT.
WHEN A PT OSCILLATOR IS INSTALLED, THE EXTERNAL SENSE MUST BE TIED DIRECTLY TO TB1
AWG 10 STRANDED WIRE OR LARGER ALL WIRES TO TB1 MUST BE OF EQUAL LENGTH ±1" (STRANDS 37/26)
ØA ØB ØC NEUT
J6
1 2 3 4
A1
4500L POWER SOURCE WITH OSCILLATOR
TB1
AC POWER OUT
ØC ØB ØA NEUT
EXT SENSE
J7
INTERFACE
J5
IEEE-488 (GPIB)
TB3
AC POWER IN
ØA ØB ØC NEUT GND
CONNECT TO IEEE-488 CONTROLLER IF USED FOR REMOTE CONTROL
CABLE ASSY 4009-231-1
A2
4500L POWER SOURCE WITHOUT OSCILLATOR
A3
4500L POWER SOURCE WITHOUT OSCILLATOR
A4
4500L POWER SOURCE WITHOUT OSCILLATOR
TERMINAL BLOCK (FURNISHED BY CUSTOMER)
TORQUE TO 35 IN. LBS. 17 PLACES
AWG 10 STRANDED WIRE OR LARGER TYP 12 PLACES (STRANDS 37/26)
AWG 8 STRANDED WIRE OR LARGER, TYP 3 PLACES (STRANDS 133/29)
CB1 100AMP
ØA ØB ØC NEUT GND
AC POWER INPUT
ØA ØB ØC NEUT GND
TB2A TB2B
AC OUTPUT POWER
THE OUTPUT IS AVAILABLE FROM ØA AND NEUT WHEN THE POWER SYSTEM IS PROGRAMMED FOR 1-PHASE

FIGURE 2-2
SYSTEM INTERCONNECT FOR MODE OPTION
4500L-3, 9000L/2-3, 13500L/3-3, 18000L/4-3

SYSTEM	4500L MODELS USED	SYSTEM INTERCONNECT CABLE
4500L-3	A1	NONE
9000L/2-3	A1, A2	4009-230-1
13500L/3-3	A1, A2, A3	4009-230-1
18000L/4-3	A1, A2, A3, A4	4009-231-1

1. TB2A MARATHON PART NUMBER 1423570, TB2B MARATHON PART NUMBER 1422570. (SHIPPED WITH POWER SOURCE SYSTEM)

2.5 OUTPUT CONNECTIONS

The output terminal block, TB1, is located at the rear of the power system. For a single power source power system, all load connections must be made at TB1. The external sense inputs allow the power system output voltages to be monitored directly at the load and must be connected. The external sense wires are connected at J6 on the rear panel. Refer to Figure 2-2 for all connections.

The output power cables must be large enough to prevent a voltage difference greater than 2 VRMS between the voltage at TB1 and the voltage between External Sense HI and LO input. Table 2-1 shows the maximum length of the output wires. The table assumes the External Sense input is connected at the load.

TABLE 2-1

MAXIMUM LENGTH OF OUTPUT WIRES

WIRE GAGE (AWG)	MAXIMUM LENGTH (ft) OF WIRE BETWEEN OUTPUT (HI) AND LOAD
14	MAX LENGTH (ft) = 2/(MAX CURRENT PER PHASE X 0.0027)
12	MAX LENGTH (ft) = 2/(MAX CURRENT PER PHASE X 0.0017)
10	MAX LENGTH (ft) = 2/(MAX CURRENT PER PHASE X 0.00111)
8	MAX LENGTH (ft) = 2/(MAX CURRENT PER PHASE X 0.00061)

For a single power source 1-phase power system, the output power is available on TB1, pins 3 and 4.

The External Sense inputs must be connected or an AMP FAULT error message will be shown on the display and reported through the remote interface.

Refer to Figure 2-2 for all multiple power source power system hookups.

NOTE:

A special hookup is required for all multiple power source power systems with the MODE option. Refer to Figure 2-2 for the connections. The 1 phase output for a single power source with the MODE option is available from TB1, pins 3 and 4.

2.6 OUTPUT VOLTAGE RANGES

The standard voltage ranges for this AC power system are 135 and 270. Selecting of the 270 volt range causes the front panel "HIGH RANGE" lamp to illuminate. The range may be changed from either the front panel keypad or through the GPIB input. All voltages are programmed line-to-neutral for 3-phase operation.

2.7 FUNCTION TEST

Refer to Figure 2-3 for the test setup.

Perform the following test sequence.

1) Apply the AC line power and turn on the front panel circuit breaker. No loads should be connected to the output terminal block.

2) Verify that the POWER ON lamp is lit.

3) With the front panel keypad program the 270 range with the following key sequences:

   4 ENT To select the Range screen (RNG)

   270 PRG ENT To program the 270 range

4) Verify the HIGH RANGE lamp is lit.

5) Program the output to 270 volts with the following key sequences:

   Depress the MON key 1 time to select the Amplitude screen (AMP).

   270 PRG ENT To program the voltage to 270 volts

6) Verify that the front panel voltmeter indicates approximately 270 volts for all three phases or for phase A for a 1-phase system.

7) Program the AC Power System to the 135 volt range with the following keystrokes:

   4 ENT 135 PRG ENT

8) Program the output to 135 volts:

   5 ENT 135 PRG ENT

9) Observe each of the outputs with the oscilloscope or distortion analyzer. The outputs should be clean sine waves having less than 1.0% distortion.

10) Apply full loads to each phase (LOAD (ohms) = 18225/FULL LOAD VA). Verify that the voltage of each phase remains within 0.67 volts of the no-load voltage. The waveforms shall still appear clean on the oscilloscope and have less than 1% distortion.

11) Program the Current Limit to 5.0 amps:

    8 ENT

    5 PRG ENT

12) The display should show the error message 'CRL FAULT'. The output will default to a programmed value of 0.0 volts with the output relays open.



POWER SYSTEM	FULL LOAD PER PHASE
2750L-1 2750L-3 4500L-3 4500L-1 9000L/2-3 9000L/2-1 13500L/3-3 13500L/3-1 27000L/6-3 27000L/6-1	REFER TO LOAD RES VALUE FROM TABLE 4-1

(1) NOTE: AC DVM MUST BE CONNECTED TO SENSE LINES INSTEAD OF CURRENT CARRYING WIRES.

FIGURE 2-3
FUNCTION TEST SETUP

SECTION 3

OPERATION

3.1 GENERAL

The AC Power System may be programmed from the front panel or through the IEEE-488 remote interface. The rear panel of the AC Power System holds the power input and output terminals external sense connector, system interface connector, IEEE-488 interface connector and the chassis ground stud.

3.2 FRONT PANEL CONTROLS

All front panel controls are shown in Figure 3-1. A voltmeter selector switch is located at the right side of the front panel voltmeter. The three position switch changes the signal applied to the voltmeter from the three output phases.

A three-pole circuit breaker is on the left side of the front panel. The circuit breaker is used to switch power to the unit. When the circuit breaker is switched ON, the amber indicator lamp above the circuit breaker illuminates.

The front panel has a subpanel with a keypad, remote lamp, LCD display and a viewing angle adjustment. The 20-key keypad allows the power source to be manually programmed at the front panel. The knob labeled VIEW ANGLE may be turned to adjust the contrast of the front panel display. The remote lamp illuminates when the AC Power System has been addressed through the IEEE-488 interface (GPIB).

3.3 FRONT PANEL INDICATORS

A lamp is located just above the input circuit breaker. It illuminates when power is applied and the circuit breaker is on.

An analog voltmeter, that indicates from 0 to 300 volts, shows the actual voltage of the phase A, B and C outputs. The phase is determined by a three position toggle switch at the right side of the meter.

An OVERTEMP lamp illuminates when the temperature of the power amplifier heatsinks has surpassed a maximum set level. When the fault is detected, the outputs are disabled and must be reprogrammed after the overtemperature condition has been eliminated.

An OVERLOAD lamp illuminates when the output current exceeds the programmed current limit value. The outputs will default to 0.0 volts and the output relays will open shortly after the condition occurs.

A HIGH RANGE lamp illuminates when the AC Power System is programmed to the high voltage range.



FIGURE 3-1
FRONT PANEL CONTROLS AND INDICATORS

An LCD digital display shows the numeric value of all programmed output parameters. It also shows all error messages and measured values.

A REMOTE lamp illuminates when the AC Power System has been addressed from the IEEE-488 interface.

3.4 REAR PANEL CONNECTIONS

(Refer to Figure 3-2 for all rear panel connections.)

3.4.1 POWER INPUT

TB3 is the terminal block for the 3-phase input voltage. Terminals 1, 2 and 3 connect to each leg of the 3-phase input. Terminal 5 is the chassis connection which should be connected to the input mains ground.

3.4.2 POWER OUTPUT

TB1 is the power output terminal block. Refer to Table 3-1 for identification of the TB1 terminals. Terminal 3 and 4 are used for a 1-phase system. Refer to Figure 2-2 for the output of all multiple power source power systems.

TB1	DESCRIPTION
1	Phase C Output HI
2	Phase B Output HI
3	Phase A Output HI
4	Output Neutral

TABLE 3-1

3.4.3 EXTERNAL SENSE

J6 is the external sense input connector. The external sense input of the master 4500L must be connected to the respective AC Power System output. If the inputs are not connected, an AMP FAULT error message will be generated. Table 3-2 identifies the pins of connector J6.

J6	DESCRIPTION	
1	Phase A Sense HI	Phase A Output HI
2	Phase B Sense HI	Phase B Output HI
3	Phase C Sense HI	Phase C Output HI
4	Neutral Sense	Neutral Output
5	Phase D sense HI	Phase D Output HI
6	Phase D sense LO	Phase D Output LO

TABLE 3-2



TB3

PIN	FUNCTION
1	3 PHASE INPUT
2	
3	
5	GROUND

TB1

PIN	FUNCTION
1	C OUTPUT
2	B OUTPUT
3	A OUTPUT
4	NEUTRAL

J6

PIN	FUNCTION
1	A SENSE
2	B SENSE
3	C SENSE
4	NEUT SENSE
5	D SENSE HI
6	D SENSE LO

FIGURE 3-2
2750L/4500L REAR PANEL CONNECTIONS

3.4.4 IEEE-488 CONNECTOR

J5 is the IEEE-488 (GPIB) connector for the 2750L or the master 4500L only.

3.4.5 SYSTEM INTERFACE

J7 is the System Interface connector. Table 3-3 identifies the pins of the System Interface connector.

J7	Description
1	Analog Common
2	MR B, Phase B amplifier input signal
3	Analog Common
4	CS B, Phase B current sum
5	CT Common, Current Transformer Common
6	OS B, Oscillator Phase B output
7	Analog Common
8	CL B, Phase B DC current limit
9	External Modification input
10	$\overline{\text{OVR TEMP}}$, Overtemperature indication
11	$\overline{\text{CNF}}$, Output relay
12	FLT C, Phase C current limit fault
13	FLT A, Phase A current limit fault
14	F STB LO, Function Sync output LO
15	EX SYNC LO, External Sync input LO
16	No connection
17	No connection
18	No connection
19	MR C, Phase C amplifier input signal
20	MR A, Phase A amplifier input signal
21	CS C, Phase C current sum
22	CS A, Phase A current sum
23	OS C, Oscillator Phase C output
24	OS A, Oscillator Phase A output
25	CL C, Phase C DC current limit
26	CL A, Phase A DC current limit
27	D COM, Digital Common
28	$\overline{\text{RNG HI}}$, High Voltage range
29	
30	FLT B, Phase B current limit fault
31	F STB HI. Function Sync output HI
32	EX SYNC HI, External Sync input HI

TABLE 3-3

SYSTEM INTERFACE CONNECTOR (J7)

J7-1 ANALOG COMMON: This is the common for all analog signals on the connector.

J7-2 MR B: This is the input signal to the phase B amplifier from the internal oscillator drive signal. Make no connection to this pin except for troubleshooting.

J7-3 ANALOG COMMON: See J7-1.

J7-4 CS B: Current sum for the phase B output. Make no connections to the pin.

J7-5 CT COMMON:

J7-6 OS B: This is the output from the internal phase B oscillator. Use this pin as an input if an oscillator is not installed. A 5.0 VRMS signal will generate a full-scale output voltage.

J7-7 ANALOG COMMON: See J7-1.

J7-8 CL B: A DC level from the oscillator used to set the current limit for phase B. Make no connection to the pin.

J7-9 External modulation input. A 5 VRMS signal input will amplitude modulate the output 11% of the programmed output voltage. Use J7-1 for common.

J7-10 $\overline{\text{OVR TEMP}}$: A logic low output to indicate an overtemperature condition. Make no connection to the pin.

J7-11 $\overline{\text{CNF}}$: Output relay control indication. This is an output logic line that indicates the state of the output relay. A logic low indicates the output relay is open. Make no connection to the pin.

J7-12 FLT C: Make no connections.

J7-13 FLT A: Make no connections.

J7-14 F STB LO: Function Sync Low signal. This is the emitter lead of an optically isolated NPN transistor. The internal power controller turns this transistor on to indicate a change of programmed values.

J7-15 EX SYNC LO: External Sync Low signal. This is the ground return for the TTL external sync input. It connects to the cathode of an LED at the input of an optocoupler. Refer to J7-32.

J7-16 No connection.

J7-17 No connection.

J7-18 No connection.

J7-19 MR C: This is the input signal to the phase C amplifier from the internal oscillator drive signal. Do not make any connection to this pin except for troubleshooting.

J7-20 MR A: This is the input signal to the phase A amplifier from the internal oscillator drive signal. Do not make any connection to this pin except for troubleshooting.

J7-21 CS C: Current sum for the phase C output. Make no connection to this pin.

J7-22 CS A: Current sum for the phase A output. Make no connection to this pin.

J7-23 OS C: This is the output from the internal phase C oscillator. Use this pin as an input if an oscillator is not installed. 5.0 VRMS on this pin will generate a full-scale output voltage.

J7-24 OS A: This is the output from the internal phase A oscillator. Use this pin as an input if an oscillator is not installed. 5.0 VRMS on this pin will generate a full-scale output voltage.

J7-25 CL C: A DC level from the oscillator used to set the current limit for phase C. Make no connection to the pin.

J7-26 CL A: A DC level from the oscillator used to set the current limit for phase A. Make no connection to the pin.

J7-27 D COM: Digital common.

J7-28 $\overline{\text{RNG HI}}$: A logic output from the internal oscillator to control the ramp relays. A logic low on this pin indicates the high voltage range. If the power system is used without an oscillator, this pin is a logic input.

J7-29 Make no connection.

J7-30 FLT B: Make no connection.

J7-31 F STB HI: Function Sync High signal. This is the collector lead of an optically isolated NON transistor. The internal power controller turns this transistor on to indicate a change of programmed values. This output will sink more than 2 milliamps to a TTL low logic output level (<.4 volts). The output is an open, collector optocoupler output. A pullup resistor to a + VDC must be connected to J7, pin 31. J7, pin 14, is the common output. Refer to Figure 3-3.

J7-32 EX SYNC HI: External Sync Low signal. This is an input that can be used to synchronize the outputs of the AC Power System. This input requires a logic high level of at least +4.5 VDC at 5 mA. The input should have a duty cycle 50 ±30%. J7-15 is the common input. The External Sync input is optically isolated. It must also be enabled from the SNC screen.

J7-36 Make no connection.

3.4.6 AUXILIARY OUTPUT (AX Option)

TB2 is the terminal block for the optional Auxiliary outputs. The Auxiliary outputs are fixed 26V rms, Phase D, and a 5V rms, Phase E, output voltages. Refer to Figure 3-2 for the terminal identification for TB2.

J6 pins 5 and 6 are the External Sense input for the Phase D output. For the specified load regulation at the load, the External Sense input should be connected across the Phase D load.

3.4.7 CLOCK

J1 is for an option that is not available for any PT power system.

3.4.8 LOCK

J2 is for an option that is not available for any PT power system.

3.4.9 DFI

J3 is for an option that is not available for any PT power system.



Figure 3-3

FUNCTION SYNC CONNECTIONS

3.5 FRONT PANEL PROGRAMMING

3.5.1 KEYPAD

The front panel keypad is enabled whenever the REMOTE light is not lit. The AC Power System may be manually programmed by using the keypad and observing the front panel LCD display.

Figure 3-4 shows the front panel keypad. Table 3-4 lists the key and a brief description. While viewing any Output Parameter screen (Ref. Table 3-5), the screens may be viewed in increasing order by depressing the MON key and in decreasing order by depressing the PRG key. While viewing the Measurement Screens, the MON and PRG keys work in a similar fashion. For example, if the AMP parameter screen is displayed, the FRQ screen may be displayed by pressing the MON key one time. The display will be switched back to the AMP screen by pressing the PRG key.



FIGURE 3-4

KEYPAD

KEY	DESCRIPTION
SNW/0	Inputs the value "0" for all output parameters or to select screen "0" when followed by the ENT key. Also used to select the sine wave waveform.
SQW/1	Inputs the value "1" for all output parameters or to select screen "1" when followed by the ENT key. Also used to select the square wave waveform.
INT/2	Inputs the value "2" for all output parameters or to select screen "2" when followed by the ENT key. Also used to select the Internal Synchronize or Internal Clock modes of operation.
EXT/3	Inputs the value "3" for all output parameters or to select screen "3" when followed by the ENT key. Also used to select the External Synchronize or External Clock modes of operation.
4 through 9	Inputs the indicated numeric value for all output parameters or to select the corresponding screen when followed by the ENT key.
MNU/.	Selects the Menu screens that show all display screens and the corresponding numeric value. The decimal point function of this key is enabled after any numeric key is depressed.
A	Used to direct any parameter change to phase A. Also used to update any quantity in the display identified as A=.
B	Used to direct any parameter change to phase B. Also used to update any quantity in the display identified as B=.
C	Used to direct any parameter change to phase C. Also used to update any quantity in the display identified as C=.
↑/REG	Used to increment the value in any output parameter screen or calibration screen. Also used to load the program register into any register identified by the preceding numeric value.
↓/REC	Used to decrement the value in any output parameter screen or calibration screen. Also used to recall the program register identified by the preceding numeric value.

TABLE 3-4

KEYPAD KEY DESCRIPTION

KEY	DESCRIPTION
CLR/SRQ	Used to clear the numerical inputs for the display screen.
MON	Used to display programmed output parameter values. Used repeatedly, it will cause the display screens of increasing numeric numbers to be displayed.
PRG	Used to program setup values in the Program Register. Used repeatedly, it will cause the display screens of decreasing numeric numbers to be displayed.
ENT	Used to transfer the contents of the program register to the actual output parameters.

TABLE 3-4 (continued)

KEYPAD KEY DESCRIPTION

3.5.2 DISPLAY SCREENS

A display of data on the front panel LCD display is called a screen. There are five types of screens: menu, output parameter, measurement, calibration and configuration screens.

Menu screens display the screen abbreviation with its equivalent number. The numeric value for each item in a menu screen is the code that may be used to select the screen. Tables 3-5 through 3-8 show the numeric values for all screens. Without the aid of the tables the MNU key may be used. The menu screens will display only the programmable features that are enabled and their associated screen number.

Table 3-5 shows all of the available Output Parameter screens. While viewing any of the screens, the associated output parameter may be changed from the keyboard.

Table 3-6 shows all of the Measurement screens. When accessing some Measurement screens up to three seconds may be required to display the screen.

Table 3-7 shows all of the screens for calibrating the output and measurement functions. A special code is required to access these screens. Refer to Section 4, Calibration.

Table 3-8 shows all of the Configuration screens. The only value that is user programmable is the IEEE-488 (GPIB) Listen Address.

NO.	SCREEN NAME	EXTENSIONS	ARGUMENT	ACTION TAKEN
The following are for changing the output:				
0	THD		0 - 20	Set the output distortion.
1	SNC		INT, EXT	Selects phase A to be synchronized to an external input.
2	DRP	A, B, C	1 - 5	Set the number of Drop Cycle. PHZ A value will define the start point of the drop cycle.
*3	WVF	A, B, C	SNW, SQW	Sets the output waveform.
4	RNG		Range limit	Selects the output voltage range. Range limit values of 135 and 270 are standard.
5	AMP	A, B, C	0-RNG limit	Sets the output voltage amplitude.
6	FRQ		45-550.0	Sets the output frequency.
7	PHZ	A, B, C,	0-±999.9	Sets the output phase angle.
8	CRL	A, B, C	0 to MAX Current	Sets the output current limit.
9	RMP A	DLY	0.001-9999	Sets the Delay between ramp steps in seconds. Four decade resolution from 0.001 to 9999 seconds.
		STP		Sets the step size of ramp parameter.
		VAL		Sets the final value of the parameter ramped.
	RMP B	STP		Same as RMPA
		VAL		Same as RMPA
*30	MOD		PHS1 or PHS3	Selects output to be 1 phase or 3 phase.

*Optional screen.
NOTE: RMPA and RMPB screens are not accessible until AMP, FRQ, CRL or PHZ are programmed (PRG) but not yet entered (ENT).

TABLE 3-5
OUTPUT PARAMETER SCREEN

NO.	SCREEN NAME	EXTENSIONS	ARGUMENT	ACTION TAKEN
The following are for measured values.				
11	ELT	H, M, S	Hrs,Min,Sec	Reports the total accumulated run time up to 9,999 hours.
21	VLT	A, B, C	0-400.0	Measures the TRMS output voltage.
22	CUR	A, B, C	0.0-200.0 or 0.00-20.00	Measures the TRMS output current in Amps. Range depends on maximum current per phase.
23	PWR	A, B, C	0.00-27.00KW or 0-2000 watts	Measures the True output power. Range depends on output VA per phase.
24	PWF	A, B, C	0-1.000	Measures the power factor of the load.
25	APW	A, B, C	0.00-27.00KVA or 0-2000 VA	Measures the apparent output power. Range depends on output VA per phase.
26	FQM		40-550.0	Measures the output frequency in hertz.
27	PZM	A, B, C	0-359.9	Measures the phase angle of the output voltage relative to phase A and phase A relative to an external input.

TABLE 3-6

MEASUREMENT SCREENS

NO.	SCREEN NAME	EXTENSIONS	ARGUMENT	ACTION TAKEN
13	CAL VLT	A, B, C	Actual output voltage	Calibrates the measured voltage to be the same as argument
14	CAL CUR	A, B, C	Actual output current (amps)	Calibrates the measured current to be same as argument.
15	CAL PWR	A, B, C	Actual output power	Calibrates the measured power to be same as argument. The argument is in KW for power systems of more than 2000 VA per phase.
20	POF	A, B, C	0-±359.9	Calibrates the programmed output phase angle.

TABLE 3-7

CALIBRATION SCREEN

NO.	SCREEN NAME	EXTENSIONS	ARGUMENT	ACTION TAKEN
16	CFG	A(LSN)	0-30	Sets the IEEE-488 (GPIB) Listen Address.
		B(CFG)	*156	Defines the features enabled for Power Source compatibility.
		C(PHZ)	*120	Defines the phase C initial value for power system configuration.
17	ALM	A(RNG)	0	Code that defines the default voltage range.
		B(LLM)	*135	Defines the upper limit of the lower voltage range.
		C(HLM)	*270	Defines the upper limit of the higher voltage range.
18	FLM	A(FRQ)	60	Defines the default frequency.
		B(LLM)	*45	Defines the low frequency limit.
		C(HLM)	*550	Defines the high frequency limit.
19	CLM	A(RNG)	Max Current	Defines the maximum current limit value.
		B(PRS)	*0	Defines the decimal point location for measured power.
		C(CRS)	*2	Defines the decimal point location for measured current.
29	INI	A(AMP)	0-5	Defines default voltage.
		C(CRL)	0-Max current	Defines default current limit.

*NOT USER PROGRAMMABLE. THE VALUES SHOWN ARE FOR A STANDARD 3-PHASE SYSTEM

TABLE 3-8

CONFIGURATION SCREENS

3.5.3 TO PROGRAM OUTPUT VOLTAGE AMPLITUDE (AMP=5)

NOTE

The external sense lines must be connected to J6 on the rear panel of the AC Power System. If they are not properly connected an AMP FAULT message will result when the output relay is closed. Refer to Figure 2-3.

The output voltage Amplitude may be programmed independently or simultaneously for each phase.

Select the Amplitude (AMP) screen by entering keystrokes:

5 ENT

The display now shows the AMP parameter screen:

AMP MON A = 0.0
B = 0.0 C = 0.0

NOTE: The B and C values are optional and they are only displayed with either a two or three-phase configuration.

Program all outputs to 115.5 volts with the keystrokes:

115.5 PRG ENT

Program phase A to 130.0, phase B to 110.0 and phase C to 90.0 volts simultaneously.

130 A PRG 110 B PRG 90 C PRG ENT

Slowly increase the output amplitude of phase B only:

B PRG ↑ (Hold until desired value is obtained.)

The output frequency can be programmed between 17 and 45 Hz. For operation between these frequencies, the output voltage Amplitude (AMP) is limited to values less than that described by the following formula:

AMP = Voltage Range * (FRQ)/45

3.5.4 TO PROGRAM FREQUENCY (FRQ=6)

Select the Frequency (FRQ) screen by entering the keystrokes:

6 ENT

Program the output to 60.23 hertz:

60.23 PRG ENT

To incrementally increase the output frequency to a desired value:

↑ (Hold until desired frequency is reached.)

The output frequency may be programmed down to 17 Hz if the programmed voltage amplitude (AMP)is less than the full scale voltage range. The low frequency limit can be determined from the following formula:

FRQ = 45 * (AMP)/Voltage Range

3.5.5 TO PROGRAM OUTPUT PHASE ANGLE (PHZ=7)

Select the Phase (PHZ) screen by entering:

7 ENT

Program phase C to .5 degree relative the phase A:

0.5 C PRG ENT

To enable the External Sync input and to program phase A to 90.0 degrees relative to the External Sync input, perform the following sequence:

1. Select the SNC screen:

   1 ENT

2. Program EXT:

   EXT PRG

At this point the phase screen must be accessed by repeatedly depressing either the MON or PRG keys. After the Phase (PHZ) screen is displayed, enter the following key sequence to simultaneously enable the External Sync and program phase A to 90 degrees:

9 0 A PRG ENT

The up (↑) and down (↓) keys may be used to increment or decrement any or all output phases.

NOTE

The PHZ A value is maintained in nonvolatile memory. The last programmed value is retained at power-up.

3.5.6 TO PROGRAM CURRENT LIMIT (CRL=8)

The Current Limit can be programmed independently or simultaneously for each phase of the AC Power system.

1. Select the Current Limit screen by entering:

   8 ENT

2. Program all phases to 5 amps:

   5 PRG ENT

3.5.7 TO PROGRAM VOLTAGE RANGE (RNG=4)

The RNG screen has two purposes; to select a range defined by the range pair selected in the Amplitude Limit (ALM) screen and to select an upper voltage limit less than that specified by the ALM screen, LLM or HLM values. If the range pair 135/270 has been selected in the ALM screen with LLM=135 and HLM=270, the 135 range of the power source will be programmed by the RNG screen for any value of 135 or less. The value programmed will then be the maximum value allowed to be programmed in the Amplitude (AMP) screen.

To select the 270 range and set a program amplitude limit of 250 volts, perform the key sequence below:

4 ENT 250 PRG ENT

3.5.8 TO PROGRAM RAMP OR STEP FUNCTIONS (RMP=9)

The Ramp (RMP) function allows any programmable parameter (AMP, FRQ, PHZ, THD, CAL or CRL) to be Stepped (STP) with a Delay (DLY) for each step to a final value (VAL). There are three types of programs that may be specified by the RMP screen; a ramp and two types of step programs.

The step function will program the output parameter value specified by a previous screen for the time specified for the DLY value in seconds. The parameter will then return to a final value specified by the VAL value.

The ramp function will step the output parameter value specified by a previous screen with the STP value, the DLY time per step and the final VAL setup in the RMP screen. The ramp will increment if the VAL value is larger than the parameter value. It will decrement if it is less than the parameter value.

NOTE

The DLY, STP or VAL parameters must be specified (A, B or C key depressed) before the number value for the parameter is entered.

When ramping frequency, an error message will result with an attempt to step the frequency with greater resolution than that possible by the initial or final values.

The step program may also be used to generate a dropout to zero volts on phase A at any point on the waveform. This type of program is selected by setting the AMP value to zero before setting the DLY and VAL parameters. The point on the waveform at which the dropout occurs is specified by setting the A value in the (PHZ) screen.

The following key sequence will program 130V for 2.5 seconds and then return to a final value of 115V.

1. Select the AMP screen and enable 130 volts to be programmed:

   5 ENT 130 PRG (*)

2. Select the RMP screen, program a DLY of 2.5, a final VAL of 115 volts and run the program:

   9 ENT A 2.5 PRG C 115 PRG ENT

The next example will illustrate a ramp program. The following sequence will ramp the frequency from 60 hertz to 400 hertz in .1 hertz steps with a delay (DLY) for each step of .003 seconds. The total time for this ramp will be = [(VAL- FRQ)/STP]DLY or 10.2 seconds.

1. Select the FRQ screen and set the starting frequency at 60 Hz:

   6 ENT 60 PRG

2. Select the RMP screen, set a DLY of .003, set the STP of .1, set the final VAL of 400 and run the program:

   9 ENT A 0.003 PRG B 0.1 PRG C 400 PRG ENT

The following program will illustrate a dropout to zero volts. The program will drop the output to zero volt at 90 degrees for .002 seconds and return to 115 volts. This example will cause the clock to stop for 0.002 seconds. Example, the output waveform will start at the same point that it stopped.

1. Select the AMP screen and program output to 115 volts:

   5 ENT 115 PRG ENT

(*)If the ENT key is depressed at this point, the AMP would be programmed to and remain at 130 volts.

2. Select the PHZ screen and program A to 90:

   7 ENT 90 A PRG

3. Select the AMP screen and program the dropout voltage to zero volt:

   5 ENT 0 PRG

4. Select the RMP screen. Set a delay of .002 seconds and a return value of 115 volts:

   9 ENT A 0.002 PRG C 115 PRG

5. Execute the program by depressing the ENT key.

Two output parameters may be ramped simultaneously. The parameter programmed just prior to entering the RMP A screen will be the independent parameter and will be identified in that screen. The parameter loaded prior to the independent parameter will be the dependent parameter.

The following example will ramp frequency from 360 to 440 Hz at a rate of .2 Hz per .2 second, while each .2 Hz step causes the amplitude to go from 10 volts to 210 volts in .5 volt steps.

1. Select the AMP screen (dependent parameter) and program the start to 10 volts:

   5 ENT 10 PRG

2. Select the FRQ screen (independent parameter) and program the start frequency of 360 Hz:

   6 ENT 360 PRG

3. Select the RMPA screen and program the independent ramp parameters of STP = .2, and DLY = .2 and VAL = 440:

   9 ENT A 0.2 PRG B 0.2 PRG C 440 PRG

4. Select the RMPB screen and program the dependent (AMP) ramp parameters of STP = .5:

   10 ENT B 0.5 PRG

5. Start the program by pressing the ENT key.

The final value of the dependent parameter, AMP, will be determined by the number of steps of the independent parameter and the STP value, .5V specified in RMP B.

FINAL VALUE = INITIAL VALUE + (RMP B STP) (NO. STEPS)
NO. STEPS = (DEP. PAR.) (FINAL VALUE - INITIAL VALUE)/STEP SIZE

In this example:

NO. STEPS = (440 - 360)/.2 = 400

FINAL AMP VALUE = 10 + .5 X 400 = 210 Volts

If the final value exceeds the RNG value, an error message will be generated.

NOTE

Any ramp may be terminated at any time by depressing the ENT key.

3.5.9 TO PROGRAM THE OUTPUT WAVEFORM (WVF=3) (SQW Option)

The waveform selection is an option for the AC Power system. If the screen cannot be selected the option is not enabled.

The WVF screen displays the type of waveform selected, sine wave (SNW) or square wave (SQW), for each of the three outputs. To program a square wave, depress the SQW or any odd number key followed by any combination of the A, B or C key, the PRG key and ENT key. If no phase key is depressed, the new waveform will be programmed for all outputs.

To program phase A and C to square wave:

SQW A C PRG ENT

To select the sine wave waveform for any phase depress the SNW or any even number key followed by the key sequence described above.

3.5.10 TO PROGRAM EXTERNAL SYNCHRONIZATION (SNC=1)

The SNC screen displays whether the external or internal SNC mode of operation has been selected. While viewing this screen to select the external SNC mode depress the EXT key followed by the PRG and ENT key:

Example: EXT PRG ENT

While operating in the EXT SNC mode, the FRQ screen will display the frequency of the External Sync signal. The signal must be between 45 Hz and 550 Hz.

NOTE

When viewing the SNC, CLK or WVF screens the MON or PRG keys must be used to sequence to another screen. The MNU key can also be used to return to the menu then followed by any screen selection.

To return to the internal SNC mode of operation, depress the INT key or any even numeric key followed by the PRG and ENT key while viewing the SNC screen.

Example: INT PRG ENT

If the External Sync signal is not between 45 Hz and 550 Hz, the message will be 'EXT SYNC ERROR'.

In the EXT SNC mode the A value on the PHZ screen represents the angle of the A output leading the External Sync input. If the zero degree point of the power source does not match the zero degree point of the External Sync input, the POF screen may be used for calibration. Select the POF screen and enter a value for calibration.

3.5.11 TO PROGRAM THE DROP CYCLES (DRP=2)

Select the phase (PHZ) screen by entering the keystrokes:

7 ENT

The display will show the PHZ parameter screen

PHZ MON A = 0.0 B = 240.0 C = 120.0

To drop the Phase A output waveform starting at 90 degrees, enter the keystrokes 90 A PRG.

Select the Drop screen (DRP=2) by entering the keystroke 2 ENT.

The display will show the DRP parameter screen.

DRP MON A = 0 B = 0 C = 0

To drop the output waveform for phase A for 3 cycles enter, the keystrokes:

3 A PRG ENT

Verify that phase A drops at the 90 degree point of the sine wave for 3 periods of the programmed output frequency.

3.5.12 TO PROGRAM TOTAL HARMONIC DISTORTION (THD=0)

The Total Harmonic Distortion screen is used to program the output distortion. The program range is from 0 to 20% with 1% program resolution.

The following example will program the output voltage to 115 volts with a 10% distortion for 1 second.

Select the THD screen with the key sequence:

0 ENT

Enable 10% distortion with the key sequence: 10 PRG.

Select the AMP screen and enable the output to be set to 115.0 volts with the key sequence:

5 ENT 115 PRG

Select the RMPA screen and specify the output distortion and voltage time of 1 second and final value of 115.0 volts with the key sequence:

9 ENT A 1 PRG C115 PRG

Recall a register where the undistorted waveform will be specified. Register 1 will be used in the example. Store the operation in register 0 with the key sequence: 1 REC 0 REG ENT

Enable the waveform to be undistorted and remain at 115 volts for 10 seconds before dropping to 0.0 volts with the key sequence:

0 ENT 0 PRG 5 ENT 115 PRG 9 ENT A 10 PRG C 0 PRG 1 REG ENT

At this point the program may be performed by the key sequence:

0 REC ENT

3.5.13 TO PROGRAM REGISTERS AND RAMPS

The AC Power System has 16 registers that can be used to store setups. All of the data stored in the registers will be retained during power-down. Register operation may be chained to another register by adding the REC and register number to any setup sequence. The REC and REG keys are used for register operations. Any of the previous examples may be stored in a register by adding the extra step of entering the register number followed by depressing the PRG key. This extra step must be entered before the last ENT keystroke.

The following program will program 135 volts and 60 hertz on all outputs for 10 seconds before reducing the output to 115 volts and store the test in register 0.

1. Select the FRQ screen and program 60 hertz:

6 ENT 60 PRG

2. Select the AMP screen and program 135 volts:

5 ENT 135 PRG

3. Select the RMP screen and program DLY = 10 and VAL = 115

9 ENT A 10 PRG C 115 PRG

4. Store the program in register 0:

0 REG

To recall and perform the register operation, simply enter the register number followed by depressing the REC and ENT keys.

3.5.14 REGISTER LINKING

Any number of registers may be linked together by using the REC key prior to loading the register operation.

The following program will ramp the voltage from 115 volts and 60 hertz to 135 volts with .1 volts per 10 millisecond steps, remain at 135 volts for 10 seconds, return to 115 volts at the same rate but at 62 Hz. Store the program in Registers 1 and 2.

1. Select the FRQ screen and program 60 Hz:

6 ENT 60 PRG

2. Select the AMP screen and program 115 volts:

5 ENT 115 PRG

3. Select the RMP screen and program DLY = 0.01, STP = 0.1 and VAL = 135:

9 ENT A 0.01 PRG B 0.1 PRG C 135 PRG

4. Link this program to Register 2:

2 REC

5. Store this program in Register 1:

1 REG ENT

The second portion of the program will be stored in Register 2.

6. Select the FRQ screen and program 62 Hz:

6 ENT 62 PRG

7. Select the AMP screen and program 135 volts:

    5 ENT 135 PRG

8. Select the RMP screen and program DLY = 0.01, STP = 0.1 and VAL = 115:

9. Store this program in Register 2:

    2 REG ENT

To initiate the program:

    1 REC ENT

3.5.15 TO PROGRAM SIMULTANEOUS RAMPS

Two outputs may be simultaneously ramped or stepped by enabling two parameter screens. The screen first selected will be the dependent parameter. The last parameter screen selected before entering the ramp (RMP) screen is the independent parameter. The independent parameter is used to specify the number of steps in a ramp. Since the dependent parameter has as many steps as the independent parameter, the step (STP) size must be calculated so the dependent parameter will not exceed its maximum value. The following example will specify frequency as the independent parameter and voltage amplitude as the dependent parameter. Refer to paragraph 3.5.8 for more information.

The following example will ramp frequency from 360 to 440 Hz at a rate of .2 Hz per .2 second, while each .2 Hz step causes the amplitude to go from 10 volts to 210 volts in .5 volt steps.

1. Select the AMP screen and specify the starting voltage of 10 volts:

    5 ENT 10 PRG

2. Select the FRQ screen and specify the starting frequency of 360 Hz.

    6 ENT 360 PRG

3. Select the RMP A screen and specify the ramp parameters of the independent parameter, FRQ, of DLY = .2 seconds, STP = .2 Hz and VAL = 440 Hz:

    9 ENT A 0.2 PRG B 0.2 PRG C 440 PRG

4. Select the RMP B screen and specify the ramp parameter of the dependent parameter, AMP, of STP = .5 volts:

    10 ENT B 0.5 PRG

5. At this point the program may be executed by depressing the ENT key or stored in a register.

3.5.16 ERROR MESSAGES

Table 3-9 shows all of the possible error messages displayed on the front panel display. The cause of the error message is also shown.

ERROR MESSAGE	CAUSE
CRL FAULT	Indicate output current exceeds program current.
AMP (1) FAULT	Incorrect sense line connection. Overload on indicated output.
TEMP (1) FAULT	Amplifier overtemperature
CPU MEMORY FAULT	CPU failed self-test
DMA OVERFLOW	Remote message greater than 256 bytes.
EXT SYNC ERROR	No external sync input at System Interface connector. Signal is not between 45 and 550 Hz.
BUS LOCAL ERROR	Remote message sent while AC Power System is in local.
SYNTAX ERROR	Incorrect syntax received from IEEE-488 ,,Remote Interface
AMP RANGE ERROR	Attempt to program AMP value greater than RNG value.
FRQ RANGE ERROR	Attempt to program FRQ less than 45 (2) or greater than 550.
PHZ RANGE ERROR	Attempt to program PHZ greater than ±999.9
CRL RANGE ERROR	Attempt to program CRL greater than the maximum current allowed for the voltage range.
RNG RANGE ERROR	Attempt to program RNG greater than 270.0 or other optional high voltage range.
RMPA RANGE ERROR	Attempt to program STP, DLY or VAL greater than the maximum.
DIV ERROR	Consult factory.
OVERFLOW ERROR	Consult factory.

(1) May be any combination of A, B or C.

(2) May be down to 17 Hz with reduced output voltage.

FRONT PANEL DISPLAY ERROR MESSAGES

TABLE 3-9

3.5.17 TO PROGRAM FREQUENCY, VOLTAGE, VOLTAGE RANGE AND CURRENT LIMIT DEFAULT VALUES

The default values are the values that appear at power-up and after the GPIB Device Clear command.

To set any of the default values, perform the following steps:

1. Depress the MNU key several times until the first menu screen is displayed as illustrated below:

```
 SNC = 01      *CLK = 02
*WVF = 03       RNG = 04
```

NOTE (*) May not be displayed. Depends on options.

2. Enter the key sequence: 9 5 9 ENT

3. Depress the MNU key several times until the configuration menu screen is displayed as illustrated below:

```
 CFG = 16      ALM = 17
 FLM = 18      CLM = 19
```

To program the default frequency enter the key sequence:

1 8 ENT A

Next enter the default frequency followed by depressing the PRG and ENT key.

To program the default voltage range, perform step 1 through 3. Next enter the key sequence:

17 ENT A

At this point if 0 is entered the default voltage range is the Low Range

If an 8 is entered the default voltage range will be the High Range.

To make High Range the default, continue the key sequence with:

8 PRG ENT

To program the default voltage, perform steps 1 through 3. Next enter the key sequence:

2 9 ENT A

At this point the default voltage from 0 to 5 may be entered. If a value of less than 5 volts is entered, the output may fault when a voltage is programmed to a value that is less than 50% of full scale.

To make 5 volts the default voltage, continue the key sequence with:

5 PRG ENT

To program the default Current Limit, perform steps 1 through 3. Next enter the key sequence:

2 9 ENT C

At this point any value may be entered up to the maximum current available per phase.

To make 5 Amps the default value, continue the key sequence with:

5 PRG ENT

3.5.18 TO PROGRAM 1 OR 3 PHASE MODE (MOD=30) (MODE OPTION)

The MOD selection is an option for the AC Power System. When the option is installed, the AC Power System may be programmed to either be a 1-phase or a 3-phase power system.

The MOD screen displays the output configuration of the power system, 1-phase (PHS1) or 3-phase (PHS3).

To program the power system to the 3-phase output mode, enter the following key sequence:

Select the MOD screen: 3 0 ENT

Program the 3-phase mode: 3 PRG ENT

The last mode programmed for the power source will be the default mode at power-up.

3.5.19 TO PROGRAM THE START-UP POINT

The power system can be programmed to change the AC waveform at a specified phase angle. The PHZ A value in the Phase screen will define the point in the sine wave where the voltage change will occur. The following example will change the voltage to 115 volts at the 90 degree point of the waveform.

7 ENT 9 0 PRG 5 ENT 115 PRG 9 ENT C 115 PRG ENT

3.6 TO MEASURE THE OUTPUT

Seven measurement screens display the output voltage, current, power, apparent power, power factor phase and frequency. The phase A, B and C output values are shown simultaneously for 3-phase systems.

While viewing any measurement screen, except ELT, any other measurement screen may be displayed by repeatedly depressing either the MON or PRG key. The screen may also be displayed by entering its equivalent screen number followed by depressing the ENT key. Refer to Table 3-6 for all measurement screen numbers.

3.6.1 TO MEASURE THE OUTPUT VOLTAGE (VLT=21)

The voltage screen displays the actual TRMS output voltage with 0.1 volt resolution. This voltage is the voltage at the External Sense connector of the AC Power System. To access the voltage screen, depress the keys:

1 ENT

3.6.2 TO MEASURE THE OUTPUT CURRENT (CUR=22)

The current screen displays the actual TRMS load current. The resolution is 0.01 amp for the 4500L-3PT and 2750L-3PT. The resolution is 0.1 amp per phase for all other PT power systems.

3.6.3 TO MEASURE THE OUTPUT POWER (PWR=23)

The power screen displays the actual true power delivered to the load. The resolution is 1 watt for the 4500L-3PT and 2750L-3PT. The resolution is 0.01 KW per phase for all other PT power systems.

3.6.4 TO MEASURE THE OUTPUT POWER FACTOR (PWF=24)

This screen displays the power factor from 0 to 1.000 with 0.001 resolution. The PWF screen will read unity for loads less than 10 digits of apparent power on the Apparent Power (APW) screen. When this screen is displayed after another screen, it takes approximately two seconds to update the screen.

3.6.5 TO MEASURE THE OUTPUT APPARENT POWER (APW=25)

This screen is accessed by its screen number, 25. It displays VOLT-AMPERES with a resolution of 1 VA for 4500L-3PT and 2750L-3PT. The resolution is 0.01 KVA per phase for all other PT power systems.

3.6.6 TO MEASURE THE OUTPUT FREQUENCY (FQM=26)

This screen is accessed by its screen number, 26. It displays the output frequency with a resolution of 0.01 Hz or 0.1 Hz up to 99.99 Hz or 550.0 Hz, respectively.

3.6.7 TO MEASURE THE OUTPUT PHASE ANGLE (PZM=27)

This screen is accessed by its screen number, 27. It displays phase A relative to an external synchronizing input and phase B and C relative to phase A. The resolution is 0.1 degree.

3.6.8 ELAPSED TIME (ELT =11)

This screen displays the total run time accumulated on the AC Power System up to 99,999 hours.

H = Hours M = Minutes S = Seconds

3.7 REMOTE CONTROL

Remote programming through the IEEE-488 Interface (GPIB) consists of sending the unit address and the proper ASCII alphanumeric characters to identify the parameter and the numerical value or other argument. The description of the abbreviations for GPIB messages used in this section are listed in Table 3-10. These abbreviations must not be confused with the device dependent abbreviations used to describe the AC Power System operating parameters (ex. FRQ=Frequency, etc.).

3.7.1 UNIT ADDRESS

This is the A value (LSN) set in the CFG screen. The Unit Address 0 through 30 corresponds to the HEX value 20 through 3E. Refer to Table 3-11 for the equivalent HEX, Binary, ASCII and Decimal equivalents. The Unit Address is set at the factory to 1 but may be changed by selecting the CFG Configuration screen and setting a new value.

To select the CFG screen repeatedly depress the MNU key until menu screen #1 is displayed as illustrated below:

```
THD = 00        SNC = 01
DRP = 02       *WVF = 03
```

Enter the key sequence: 959 ENT

Repeatedly depress the MNU key until the menu screen #5 is displayed as illustrated below:

```
CFG = 16        ALM = 17
FLM = 18        CLM = 19
```

Enter the key sequence: 16 ENT

The CFG screen will now be displayed. Depress the A key to display the present Unit Address. It may be changed to any value from 0 to 30 and will be stored in non-volatile memory. The new unit address will not be updated until power is shut off and reapplied to the power system.

NOTE(*): WVF is an option screen.

The following key sequence will change the unit address to 16:

16 PRG ENT

3.7.2 MESSAGE FORMAT

The message sent to the AC Power System must have the following format for each parameter:

HHHDXXX----------E±NND

where

H = Three letter mnemonic for each message header.

D = Optional header extension (A, B or C) to specify output (ref. Table 3-5 through 3-8)

X = Alpha, numeric or # for message header argument.
E = Optional ASCII E for exponent identification
± = Exponent sign
N = Exponent value 0 to ±63
D = Message string delimiter, (CR) (LF) or (LF)

More than one message header with its corresponding argument may be sent in one setup string with a common delimiter.

TABLE 3-10.
COMMONLY USED GPIB ABBREVIATIONS

ABBREVIATION	DEFINITION
ATN	Attention. A logic line on the GPIB asserted only by the controller to indicate the data on the bus represents a bus message.
CR	An ASCII carriage return.
DCL	Device Clear. A universal bus message to initialize all instruments to their power-on states..
END	End. A message conveyed when a talker uses the EOI line with the last data byte of a data string.
EOI	End or Identify. A logic line on the GPIB asserted by a talker to indicate the last byte of a data string.
EOS	End of String. A delimiter message that consists of a data byte(s) to indicate the end of a data string.
GET	Group Execute Trigger. A GPIB message to trigger an addressed instrument.
GTL	Go To Local. A GPIB message to put an addressed instrument in the local control mode.
IFC	Interface Clear. A logic line on the GPIB asserted by the controller to clear all interfaces (ex., default to unlisten and untalk).
LF	An ASCII line feed.
LLO	Local Lockout. A GPIB message, when asserted, will inhibit the instrument from going to local if the CLR/LOC key is pressed.
REN	Remote Enable. A logic line on the GPIB asserted by the controller. REN enables an instrument to go to local when addressed.
SDC	Selected Device Clear. A GPIB message to initialize an addressed instrument to it Power-on state.

TABLE 3-11.

UNIT ADDRESS GROUP

LISTEN ADDRESS	HEX	BINARY						DECIMAL	ASCII
			A5	A4	A3	A2	A1		
0	20	001	0	0	0	0	0	32	SP
1	21	001	0	0	0	0	1	33	!
2	22	001	0	0	0	1	0	34	"
3	23	001	0	0	0	1	1	35	#
4	24	001	0	0	1	0	0	36	$
5	25	001	0	0	1	0	1	37	%
6	26	001	0	0	1	1	0	38	&
7	27	001	0	0	1	1	1	39	'
8	28	001	0	1	0	0	0	40	(
9	29	001	0	1	0	0	1	41	)
10	2A	001	0	1	0	1	0	42	*
11	2B	001	0	1	0	1	1	43	+
12	2C	001	0	1	1	0	0	44	'
13	2D	001	0	1	1	0	1	45	-
14	2E	001	0	1	1	1	0	46	.
15	2F	001	0	1	1	1	1	47	/
16	30	001	1	0	0	0	0	48	0
17	31	001	1	0	0	0	1	49	1
18	32	001	1	0	0	1	0	50	2
19	33	001	1	0	0	1	1	51	3
20	34	001	1	0	1	0	0	52	4
21	35	001	1	0	1	0	1	53	5
22	36	001	1	0	1	1	0	54	6
23	37	001	1	0	1	1	1	55	7
24	38	001	1	1	0	0	0	56	8
25	39	001	1	1	0	0	1	57	9
26	3A	001	1	1	0	1	0	58	:
27	3B	001	1	1	0	1	1	59	;
28	3C	001	1	1	1	0	0	60	<
29	3D	001	1	1	1	0	1	61	=
30	3E	001	1	1	1	1	0	62	>
UNL	3F	001	1	1	1	1	1	63	?

3.7.3 NUMERIC DATA FIELD

Parameter values may be sent as an unsigned value with a decimal point or a decimal point with an exponent. The phase value may be sent as a signed value.

The Decimal Point for numeric data values may be either sent or inferred. The two following ASCII strings will represent 115 volts.

```
AMP115
AMP115.0
```

There may be any number of digits following the decimal point, not to exceed the 256 byte DAM buffer, but only the Least Significant Digit (LSD) of resolution will be recognized. The LSD for amplitude is tenths of volts. The LSD for frequency is either hundredths or tenths for up to 99.99 Hz or 550.0 Hz respectively.

Any parameter's numeric value may be of a mixed form with a decimal point and exponent. The exponent may be a numeric, with or without leading zeros, up to a value of ±63. The following ASCII strings will represent 15 volts:

```
AMP1.15E2
AMP1.15E+2
AMP1.15E+02
AMP1150E-1
```

A positive exponent value is represented by either an ASCII "+" or an unsigned value.

3.7.4 PROGRAM HEADERS

A Program Header is a mnemonic of a series of three ASCII characters used to select a function or identify the data it precedes. The header is an abbreviation of the program function it identifies. The header may be followed by a header extension to separately program each output (phase A, B or C) to different values. If an extension is not added to the header all outputs will be programmed to the header's argument. See Table 3-12 for the definition of the Program Headers and their related arguments.

Any header that is sent without an argument will cause the front display to show the corresponding screen. Refer the Figure 3-5 for a summary of all possible command sequences.

TO PROGRAM OUTPUT PARAMETERS:



TO RAMP OR STEP ONE OUTPUT PARAMETER:



TO RAMP OR STEP TWO OUTPUT PARAMETERS:



TO REQUEST TALKING OF CALIBRATION COEFFICIENTS:



TO PROGRAM THE OUTPUT MODE:

FIGURE 3-5

REMOTE COMMAND SEQUENCES

TO SPECIFY THE SERVICE REQUEST INTERRUPT:



TO CALIBRATE OUTPUT:



TO CALIBRATE MEASUREMENT:



TO REQUEST TALKING A PROGRAMMED PARAMETER OR MEASURED VALUE:



TO RECALL A REGISTER:



* Represents either an IEEE-488 END or EOS message. The EOS message may be either an ASCII Carriage Return(CR), Line Feed(LF) or just LF.

n Represents a numeric value.

FIGURE 3-5 (continued)

REMOTE COMMAND SEQUENCES

TABLE 3-12
PROGRAM HEADERS

HEADER	EXTENSION	ARGUMENT	DEFINITION
AMP	A, B, C	# or numeric from 0.0 to RNG value.	Amplitude in volts.
CAL VLT	A, B, C	Actual voltage	Calibrated measured voltage at external sense point.
CAL CUR	A, B, C	Actual current	Calibrate measured current.
CAL PWR	A, B, C	Actual power	Calibrate measured power.
CRL	A, B, C	0 to maximum	Current limit in amps current per phase
DLY		0.000 to 9999	Delay in seconds used as a seconds ramp parameter
FRQ		45.00 to 550.0	Frequency in hertz.
PHZ	A, B, C	0 to 999.04	Phase angle in degrees.
PRG		0 through 15	Load register with preceding data.
REC		0 through 15	Recall register or specify link register if it is preceded by program argument followed by PRG and register number.
REG		0 through 15	Register load
RNG	A, B, C	0.0 to 270 or other optional range value	Amplitude range and limit value in volts
SNC		INT,EXT	Synchronize
DRP	A, B, C	1 through 5	Number of Drop cycles
THD	A, B, C	0 through 20	Programmable output distortion

TABLE 3-12 (CONT.)

PROGRAM HEADERS

HEADER	EXTENSION	ARGUMENT	DEFINITION
HLD		0 through 1 sec in 10 msc inc.	Hold time before a response to current limit fault.
SRQ		0, 1 or 2	Service Request disable, enable or at completion of program and measurements.
STP		From parameter minimum to maximum value	Define step size in ramp.
TLK		Any header	Set up to talk argument value or measured value when addressed to talk.
TRG			Execute (Trigger) set-up parameters on GPIB "GET" message.
VAL		From parameter minimum to maximum value	Final ramp or step value in volts, hertz, amps, degrees, sine wave or square wave.
WVF	A, B, C	SNW,SQW	Waveform
OPN			Open output relays
CLS			Close output relays
VLT	A, B, C		Used with TLK to request measurement of the output voltage.
ELT			Used with TLK to request total accumulated run-time.
CUR	A, B, C		Used with TLK to request measurement of the output load current.
MOD	PHS	1 or 3	Program the output phase configuration

TABLE 3-12 (CONT.)

PROGRAM HEADERS

HEADER	EXTENSION	ARGUMENT	DEFINITION
PWR	A, B, C		Used with TLK to request measurement of the True output power.
APW	A, B, C		Used with TLK to request measurement of the Apparent output power.
PWF	A, B, C		Used with TLK to request measurement of the output power factor.
PZM	A, B, C		Used with TLK to request measurement of the output phase angle.
FQM			Used with TLK to request measurement of the output frequency.

NOTE: If Extension does not follow the header, the argument will be applied to all phases.

3.7.5 TO PROGRAM OUTPUT VOLTAGE AMPLITUDE (AMP)

The AMP header with the optional A, B or C extension is used to identify the amplitude command. The argument is a numeric data field from 0.0 to the limit set by the RNG value. An attempt to program a value higher than this value will generate an error and a SRQ on the GPIB.

The following ASCII strings will program the voltage given in the left column:

A,B,C 0.0 volts	AMP0	or	AMPA0AMPB0AMPC0		
A,B,C 10.5 volts	AMP10.5	or	AMP1.05E1	or	AMP105E-1
A,B,C 100 volts	AMP100	or	AMP100.0	or	AMP1E2
A,B = 110.5, C = 115	AMPA110.5AMPB110.5AMPC115 or AMP110.5AMPC115				

3.7.6 TO PROGRAM FREQUENCY (FRQ)

The FRQ header is used to identify the following numeric data as frequency.

The following string will program the frequency to 60.56 Hz.

```
FRQ 60.56
```

3.7.7 TO PROGRAM PHASE ANGLE (PHZ)

The PHZ header with the optional A, B or C extension is used to identify the following numeric data as phase. The PHZ header sent with no extension will program the B and C outputs in phase with phase A. The phase of the A output will lead the EXT SNC signal by the value programmed.

The following example will program the phase A output to 90 degrees relative to an external sync signal when operating in the EXT SNC mode:

```
PHZA 90
```

The following example will program phase B to 240.5 degrees and phase C to 119.3 degrees leading phase A.

```
PHZB 240.5 PHZ C 119.3
```

The PHZA value can be used to control the point of the phase A waveform where the change will occur. The following string will drop the phase A waveform at 90 degrees for one (1) period of programmed frequency:

```
PHZA 90 DRPA 1
```

The following example will program the phase A output voltage to 135 volts for 0.017 seconds starting at the 90 degree point of the waveform. The voltage will return to 115 volts after the transient.

```
PHZA 90 AMPA 135 DLY .017 VAL 115
```

3.7.8 TO PROGRAM CURRENT LIMIT (CRL)

The CRL header with the optional A, B or C extension is used to identify the Current Limit Command. The argument is a numeric data field from 0.0 to the maximum rated current of the power system.

The following string will program a current limit of 10.5 amps for all three phases:

```
CRL 10.5
```

3.7.9 TO PROGRAM DROP CYCLE (DRP)

The DRP header is used to identify the Drop Command. The argument is a numeric data field from 1 to 5. The following string will drop the output voltage for phase B for five complete cycles and start at 0 degree of the wave form

```
PHZ 0 DRP B 5
```

3.7.10 TO PROGRAM TOTAL HARMONIC DISTORTION (THD)

The THD header is used to identify the total Harmonic distortion. The argument is a numeric data field from 0 to 20. The following string will program the output for 115 volts and the total harmonic distortion for 10% for phase C:

```
AMP 115 THD C 10
```

3.7.11 TO PROGRAM HOLD OFF COMMAND (HLD)

The HLD header is used to identify the hold off command. The hold off command is accessible through the GPIB only. It will delay the response to a fault condition resulting from the output current exceeding the program current when the output voltage is programmed. The hold off command has a maximum value of 1 second in 10 ms increments. The default value is 100 msec.

3.7.12 TO PROGRAM RAMP OR STEP OPERATIONS

The DLY header is used with a parameter that has a numeric argument (ex. AMP, FRQ, PHZ, CRL, CAL) in a single step program. The numeric argument is in seconds with four decade resolution from 0.001 to 9999 seconds.

The STP header with VAL may be used with DLY to completely specify a ramp program.

The following string will first step the voltage to 125 volts for 2.55 seconds and return to 115 volts.

```
AMP 125 DLY 2.55 VAL 115
```

The following string will ramp the voltage from 10 volts to 115 volts with 1.5 volt/.5 sec. steps:

```
AMP 10 DLY .5 STP 1.5 VAL 115
```

When an AMP header with an argument of 0 is used, the waveform will stop and drop to zero volts at the point specified by the PHZ A value.

The following ASCII string will stop the waveform at 0 degrees for .01 seconds and return to 115 volts:

```
PHZ A 0 AMP 0 DLY .01 VAL 115
```

The STP header is used to identify the following argument numeric value as the increment or decrement value for a FRQ, CRL, AMP, PHZ, THD, or CAL ramp.

The following example will ramp all outputs from 130 volts in 1.5 volt/.5 sec. steps to 10 volts.

```
AMP130 DLY.5 STP1.5 VAL10
```

The header VAL is used to identify the following numeric argument as the final Value of a ramp or step. If the VAL argument is larger than the initial value for the parameter to be ramped, the ramp will increment with step size defined by STP and DLY. With the VAL argument less than the initial value, the ramp will decrement from the initial parameter.

A ramp or step operation can be started at anytime by the GPIB message Group Execute Trigger (GET). The operation will wait for the Group Execute Trigger when the TRG header is added to the string.

The following example will decrement the output amplitude of phase A only from 120 in .1 volt/.2 sec steps to 100 volts after a Device Trigger.

```
AMP A 120 DLY.2 STP.1 VAL100 TRG
```

The following example will simultaneously ramp the Frequency from 400 to 5000 Hz at a rate of 10 Hz per second and the Amplitude from 5 volts in increments of .5 volts per step:

```
RNG270 AMP5 FRQ400 STP10 DLY1 VAL5000 STP.5
```

A GPIB Service Request will be generated at the end of a ramp if SRQ2 is included in the setup string.

A ramp or step operation can be stopped at anytime by the GPIB Group Execute Trigger.

3.7.13 TO PROGRAM A REGISTER (REG)

The REG header is used to load the register specified by the following numeric data with the preceding data. The numeric value is from 0 to 15. The PRG header is identical to the REG header and is included to standardize other AC power controllers.

The following example will load a ramp program that will step the voltage from 10 to 115 volts with 1 volt/.5 sec steps at 400 Hz into register 0.

```
FRQ400 AMP10 DLY.5 STP1 VAL115 REG0
```

3.7.14 TO RECALL A REGISTER (REC)

The REC header is used to recall previously loaded data from a register identified by the following register number (0 to 15).

The following example recalls and outputs the parameters stored in register 0 by an example in paragraph 3.7.13.

```
REC0
```

The following example recalls the parameters in register 0 and outputs the parameters after the IEEE-488 "GET" message.

```
REC0 TRG
```

The following is an example of register linking. The voltage and frequency is maintained at 115 volts and 60 Hz for 5 seconds and then the program contained in register 0 is recalled and executed. The program is stored in register 1.

```
FRQ60 AMP115 DLY5 VAL115 REC0 REG1
```

The program is initiated by the following ASCII string:

```
REC1
```

3.7.15 TO PROGRAM VOLTAGE RANGE (RNG)

The RNG header is used to select a range. The numeric value following the RNG header will also define the upper limit for the AMP value. The RNG value will select the higher range if the value is greater than the lower range value defined by the ALM screen which is 135 for the standard voltage range. If the range and voltage amplitude are to be programmed by the same data string the RNG header and argument must precede the AMP header or a syntax error will be generated.

The following example will select the 270 range from the 135/270 range pair with an upper amplitude limit of 210 volts.

```
RNG210
```

3.7.16 TO PROGRAM EXTERNAL SYNCHRONIZATION (SNC)

The SNC header is used with the EXT argument to synchronize the phase A output to an external sync input. The phase A output will be phase referenced to the sync input with the displacement equal to the PHZ A value.

The following ASCII string will program the phase A output to 0 degree relative to the external sync input and select the external sync mode.

```
PHZA0 SNC EXT
```

Sending the ASCII string SNC INT will disable the sync input.

3.7.17 TO TRIGGER AN OPERATION (TRG)

The TRG header has no argument. When the TRG mnemonic is included in a setup string, it will delay execution of the string until the GPIB Device Trigger message is sent by the bus controller. The TRG header may also be used to trigger register operations by including the TRG header with the string used to recall a register. The following example will delay execution of the program in register 1 until an IEEE-488 Device Trigger is received:

```
REC1 TRG
```

The Trigger mode may also be enabled in the local mode by programming setup parameters without depressing the ENT key. The setup values will then be programmed in the remote mode when the Device Trigger is received.

3.7.18 TO PROGRAM THE OUTPUT WAVEFORM (WVF) (Optional)

The header WVF with the optional A, B or C extension is used to identify the following argument as the Sine Wave (SNW) or Square Wave (SQW) function of the Waveform.

The following example will program all outputs to the square wave function.

```
WVF SQW
```

The following example will program only output B to the square wave function:

```
WVFB SQW
```

3.7.19 TO OPEN (OPN) AND CLOSE (CLS) THE OUTPUT RELAY

The OPN and CLS headers open and close the output relays in the power source. There is no argument associated with these headers. When the OPN or CLS headers is received the output voltage will be programmed to zero volts for 50 milliseconds before the output relays open or close.

3.7.20 TO PROGRAM THE DEFAULT FREQUENCY (FLM A)

The default frequency is the output frequency after power-up or after an IEEE-488 Device Clear.

The following example will program the default frequency to 400 Hz.

```
FLM A 400
```

3.7.21 TO PROGRAM THE DEFAULT OUTPUT VOLTAGE (INI A)

The default voltage is the output voltage after power-up, IEEE-488 Device Clear or an Amplitude fault.

The following example will program the default voltage to 5 volts.

```
INI A 5
```

NOTE

If the default voltage is programmed to a value less than 5 volts, the settling time will increase. In addition, there may be an amplitude fault when the voltage is programmed from the default voltage to a value less than 50% of full scale.

3.7.22 TO PROGRAM THE DEFAULT CURRENT LIMIT (INI C)

The default current limit is the value after power-up or IEEE-488 Device Clear.

The following example will program the default current limit to 10 amps.

```
INI C 10
```

3.7.23 TO PROGRAM THE DEFAULT VOLTAGE RANGE (ALM A)

The default voltage range is the voltage range after power-up or IEEE-488 Device Clear. A value of 0 designates the low-range. A value of 8 designates the high range.

The following example will program the default voltage range to the high range.

```
ALM A 8
```

3.7.24 TO PROGRAM 1 OR 3 PHASE MODE (MOD)

The MOD header with the required PHS extension is used to identify the mode command. The argument is either a 1 or a 3 to specify the 1-phase or 3-phase mode respectively. A mode change by the AC Power System will cause the output voltage to go to the default value.

The following string will set the AC Power System to the 3-phase mode:

```
MOD PHS 3
```

3.7.25 TO TALK (TLK) MEASURED AND PROGRAMMED DATA

The TLK header will setup the AC Power System to talk data. The TLK header will setup the AC Power System to report a programmed output parameter if the program header is the argument for the TLK header.

To setup the AC Power System to report a measured value, attach a measurement header as the TLK argument. The measurement headers are VLT, CUR, PWR, APW and PWF with an A, B or C extension and FQM with no extension.

The following string will setup the AC Power System to measure the phase A power output when it is talk addressed:

```
TLK PWR A
```

All arguments for the TLK header are shown in Table 3-13. Table 3-14 shows an example response for all TLK arguments with no A, B or C extension. For 1-phase systems, all responses will only include the phase A value. For 3-phase systems, if the TLK argument includes the A, B or C extension, the response message will be only for the indicated phase.

A GPIB Service Request (SRQ) will be generated at the completion of a measurement if the SRQ2 header is included with the TLK string. The following string will cause the Service Request to be generated when the power system is ready to report the power factor measurement.

```
TLK PWF SRQ2
```

3.7.26 TO TALK THE MEASURED OUTPUT VOLTAGE (TLK VLT)

VLT may be used as an argument to the header TLK with an A, B or C extension. When used as an argument, it will set up the AC Power System to measure the output voltage with 0.1 volt resolution.

When VLT is used as a header in a string with no argument, it will cause the front panel to display the measured output voltage.

3.7.27 TO TALK THE MEASURED OUTPUT CURRENT (TLK CUR)

CUR may be used as an argument to the header TLK with an A, B or C extension. When used as an argument, it will set up the AC Power System to measure the output current in amps with 0.01 amp resolution for the 4500L-3PT and 2750L-3PT. The resolution is 0.1 amps for all other models.

When CUR is used as a header in a string with no argument, it will cause the front panel to display the output current.

3.7.28 TO TALK THE MEASURED OUTPUT POWER (TLK PWR)

PWR may be used as an argument to the header TLK with an A, B or C extension. When used as an argument, it will set up the AC Power System to measure the output power in watts with 1 watt resolution for the 4500L-3PT and 2750L-3PT. The power is measured in kilowatts with 0.01 KW resolution for all other models.

When PWR is used as a header in a string with no argument, it will cause the front panel to display the output power.

TABLE 3-13

TLK ARGUMENTS

ARGUMENT	EXTENSION	DATA REPORTED	DEFINITION
ALM	A B C	0000 *135.0 *270.0	Default voltage range code Low Voltage Range High Voltage Range
AMP		0 to 270.0	Programmed voltage Amplitude value in volts.
APW	A,B,C	0 to 2000 or 0.00 to 20.00	Output VA (4500L-3PT and 2750L-3PT) Output KVA (All other models)
CFG	A B C	0 to 30 * 156 * 120	IEEE-488 Listen Address Configuration Code Phase C initial Value. 0 for 1ø
CLM	A B C	See MAXIMUM CURRENT TABLE 0 or 2 2 or 1	Defines the maximum current per phase Defines the power decimal point (0 = 4500L-3PT and 2750L-3PT, 2= all others) Defines the current decimal point (2 = 4500L-3PT and 2750L-3PT, 1 = all others)
CRL	A,B,C	0 to MAX CURRENT see table	Programmed output current limit.
CUR	A,B,C	0.00 to 20.0 or 0.0 to 100.0	Output current (4500L-3PT and 2750L-3PT) (All other models)
ELT	A B C	0000 to 9999 00 to 59 00 to 59	Total accumulated hours (H) Accumulated minutes (M) Accumulated seconds (S)
FLM	A B C	60 45 550	Default frequency Low frequency limit High frequency limit
FQM	None	45.00 to 550.0	Measured output frequency
FRQ	None	45.00 to 550.0	Programmed frequency
INI	A C	0000 to 005.0 0 to CRL	Default voltage Default current limit

(*) Standard values shown. Values will be different for other ranges, output power and options.

NOTE: If the A, B or C Extension is not sent with the argument, all phases will be reported.

TABLE 3-13 (continued)

TLK ARGUMENTS

ARGUMENT	EXTENSION	DATA REPORTED	DEFINITION
SNC	None	INT or EXT	Programmed external sync mode
WVF	A, B, C	INT or EXT	Programmed waveform
PHZ	A, B, C	0.0 to 359.9	Programmed output phase angle
PWR	A, B, C	0 to 2000 or 0.00 to 27.00	Output watts (4500L-3PT or 2750L-3PT) Output KW (all other models)
PZM	A, B, C	0 to 359.9	Measured phase B and C output phase angle relative to A. A is always 0.0
REG	0 to 15	Contents of Reg	Talk contents of register
RNG	None	0 to 270.0	Programmed range and limit
SRQ	None	0, 1 or 2	Programmed SRQ status
VLT	A, B, C	0.0 to 400.0	Measured output voltage
THD	A, B, C	0 to 20	Programmed total harmonic distortion

NOTE: If the A, B or C Extension is not sent with the argument, all phases will be reported

	VOLTAGE RANGE PAIR			
MODEL	135/270	156/312	67.5/135	200/400
2750L-3PT	7.40	6.40	14.82	5.00
2750L-1PT	22.22	19.24	44.44	15.00
4500L-3PT	12.34	10.68	24.70	8.34
4500L-1PT	37.04	32.06	74.08	25.00
9000L/2-3PT	24.68	21.36	49.38	16.66
9000L/2-2PT	37.04	32.06	74.08	25.0
9000L/2-1PT	74.08	64.12	148.2	50.0
13500L/3-3PT	37.04	32.06	74.08	25.0
13500L/3-1PT	111.2	96.18	222.2	75.0
27000L/6-3PT	74.08	64.12	148.2	50.0
27000L/6-1PT	222.2	192.4		150.0

MAX CURRENT

TABLE

TABLE 3-14

EXAMPLE TALK RESPONSE (3-PHASE SYSTEM)

ASCII STRING SENT	RESPONSE AFTER ADDRESSED TO TALK		
TLK ALM	ALMA0000	B135.0	C270.0
TLK AMP	AMPA000.0	B000.0	C000.0
TLK APW	APWA1003	B0985	C1507
TLK CFG	CFGA0001	B0028	C0120
TLK CRL	CRLA11.12	B11.12	C11.12
TLK CUR	CURA06.14	B05.12	C06.71
TLK ELT	ELTH0147	M0051	S0033
TLK FLM	FLMA0060	B0045	C0550
TLK FQM	FQM59.97		
TLK FRQ	FRQ60.00		
TLK SNC	SNC INT		
TLK PHZ	PHZA000.0	B240.0	C120.0
TLK PWF	PWFA1.000	B1.000	C1.000
TLK PWR	PWRA0.737	B0.620	C0.806
TLK PZM	PZMA000.0	B242.1	C118.9
TLK REG0	ACTUAL CONTENTS OF REGISTER 0		
TLK RNG	RNGA 135.0	B135.0	C135.0
TLK VLT	VLTA120.1	B119.8	C120.0
TLK WVF	WVFA SNW	B SNW	C SNW (*)
TLK THD	THDA0005	B0010	C0015

3.7.29 TO TALK THE MEASURED OUTPUT POWER FACTOR (TLK PWF)

PWF may be used as an argument to the header TLK with an A, B or C extension. When used as an argument, it will set up the AC Power System to measure the output power factor from 0 to 1.000.

When PWF is used as a header in a string with no argument, it will cause the front panel to display the output power factor.

3.7.30 TO TALK THE MEASURED OUTPUT APPARENT POWER (TLK APW)

APW may be used as an argument to the header TLK with an A, B or C extension. When used as an argument, it will set up the AC Power System to measure the Apparent Power output in VA with 1 VA resolution for the 4500L-3PT and 2750L-3PT. The apparent power is measured in KVA with 0.01 KVA resolution for all other models.

When APW is used as a header in a string with no argument, it will cause the front panel to display the measured output Apparent Power.

3.7.31 TO TALK THE MEASURED OUTPUT FREQUENCY (TLK FQM)

FQM may be used as an argument to the header TLK. There are no extensions for this argument. When FQM is used as an argument, it will set up the AC Power System to measure the output frequency in hertz.

When FQM is used as a header, it will cause the front panel to display the measured output frequency.

3.7.32 TO TALK THE MEASURED OUTPUT PHASE ANGLE (TLK PZM)

PZM may be used as an argument with an extension A, B or C for the header TLK. When used as an argument, PZM will set up the AC Power System to measure the phase angle of phase B and C relative to phase A. The measurement is made at the External Sense terminals. Phase A is the reference phase and will always be reported as 000.0 degrees unless the AC Power System is operating in the external sync mode.

When PZM is used as a header, it will cause the front panel to display the phase measurement screen.

3.7.33 MESSAGE SEPARATORS

A complete message consists of a header and an argument. Since more than one message can be sent in a setup string, message separators included in the string between the message will make it more readable to the human operator. Three message separators are recognized: the comma (,), semicolon (;) and a space. Since these separators are ignored, they may be dispersed throughout a setup string.

The following are two examples of ASCII strings with separators:

```
PHZA90;FRQ60;AMP115

CRL,90;FRQ50;AMP,120
```

3.7.34 SERVICE REQUEST

After power-up the GPIB Service Request (SRQ) will be generated after any error (example. syntax, output fault, etc.). This SRQ output can be inhibited by the SRQ header followed by the single digit "0". The SRQ can be reenabled by the SRQ header followed by 1. Sending SRQ2 causes an SRQ to be generated after the execution of a setup string or when data is available after request of measurements. The setup string can be of any type: ramp, calibration, etc.

The following example disables GPIB SRQ.

```
SRQ0
```

The following example will cause the SRQ to be generated when the APW measurement data is available:

```
TLK APW SRQ 2
```

3.7.35 SERIAL POLL STATUS BYTE

Once the bus controller has detected the SRQ, it must determine the instrument needing service by the Serial Poll. During the polling routine the instrument needing service will return a Status Byte (STB) greater than decimal 63. The Status Byte values for various faults are given in Table 3-15.

3.7.36 END OF STRING

The End of String (EOS) delimiter recognized by the AC Power System is the ASCII Line Feed (LF). Carriage Return (CR) followed by Line Feed may also be used for EOS. The End or Identify (EOI) IEEE-488 message END will also be recognized. The END message is sent by setting the IEEE-488 End or Identify line true with the last data byte.

3.7.37 ERROR MESSAGES

Table 3-15 shows all of the possible error messages that can be generated by the AC Power System. These messages will also be displayed on the front panel of the AC Power System.

3.7.38 GROUP EXECUTE TRIGGER

The trigger mode is enabled when the mnemonic TRG is added to a setup string. The trigger command may be inserted anywhere in the string. When the mnemonic is detected, it will delay execution of the new setup values until the GPIB Device Trigger is sent by the bus controller.

A GPIB Device Trigger will also terminate a programmed ramp or other program.

The following setup string will recall the values from register 9 and delay execution until the GET message is received. (Note: GET is the abbreviation for the GPIB Group Execute Trigger message and does not represent a series of ASCII characters. (See Table 3-10).

```
REC9TRG
```

TABLE 3-15

STATUS BYTE VALUES

SRQ 1	SRQ 0	REPORTED MESSAGE	CAUSE
STATUS BYTE			
64	0	AMP A FAULT	Overload or sense line fault
65	1	AMP B FAULT	Overload or sense line fault
66	2	AMP AB FAULT	Overload or sense line fault
67	3	AMP C FAULT	Overload or sense line fault
68	4	AMP AC FAULT	Overload or sense line fault
69	5	AMP BC FAULT	Overload or sense line fault
70	6	AMP ABC FAULT	Overload or sense line fault
71	7	CRL FAULT	Output current exceeds program value
72	8	TEMP A FAULT	Amplifier overtemperature
73	9	TEMP B FAULT	Amplifier overtemperature
74	10	TEMP AB FAULT	Amplifier overtemperature
75	11	TEMP C FAULT	Amplifier overtemperature
76	12	TEMP AC FAULT	Amplifier overtemperature
77	13	TEMP CB FAULT	Amplifier overtemperature
78	14	TEMP ABC FAULT	Amplifier overtemperature
90	26	RNG RANGE ERROR	RNG value greater than highest range
91	27	AMP RANGE ERROR	AMP value greater than RNG value
92	28	FRQ RANGE ERROR	FRQ value is less than 45 or greater than 550.0
93	29	PHZ RANGE ERROR	PHZ value greater than ±999.0
94	30	CRL RANGE ERROR	CRL value greater than maximum value
95	31	RMPA RANGE ERROR	DLY, STP or VAL values wrong
96	32	SYNTAX ERROR	Wrong string SYNTAX
97	33	BUS LOCAL ERROR	Remote message sent while in local mode
98	34	EXT SYNC ERROR	No external sync input or signal not between 45 and 550 Hz
99	35	CPU MEMORY FAULT	CPU failed self-test
100	36	DMA OVERFLOW ERROR	Remote message greater than 256 bytes
63			The response after SRQ2 is included in a setup string and the execution of the string or measurement is completed.
	40	STA OK	No problems

TABLE 3-16

HP SERIES 80 CONTROLLER STATEMENTS

CLEAR	Universally sets all instruments to their power-on states by sending the GPIB message DCL.
CLEAR 701	Sets only instrument with listen address "1" to its power-on state by sending the GPIB message SDC.
LOCAL 7	Universally sets all instruments into their local control mode by deasserting REN.
LOCAL 701	Sets only instrument with listen address "1" to its local control mode by sending the GTL message.
LOCAL LOCKOUT 7	Universally sets all instruments to disable their local control.
REMOTE 7	Sets REN true.
REMOTE 701	Sets instrument with listen address "1" to remote.
ABORTIO 7	Clears all instrument interfaces to unlisten and untalk by toggling IFC.
RESUME 7	Sets ATN false.
OUTPUT 701; "AMP"; V	Sends the data string AMP followed by the numerical value of variable V to the instrument with listen address "1".
STATUS 7,1;A	This statement reads the SR1 register of the series 80 controller for the interrupt cause. This statement is necessary to clear the Service Request flag in the controller.
ENABLE INTR	This statement allows the series 80 controller program to be interrupted when a GPIB instrument generates SRQ.
ON INTR 7 GOSUB100	This statement causes the program to go to an interrupt subroutine at 100.
TRIGGER 7	This statement triggers all addressed instruments by sending the GET message.
TRIGGER 701	This statement triggers only the instrument with listen address "1" by sending the GET message.
A=SPOLL (7)	Sets variable A equal to the decimal value of the Status Byte of an instrument previously addressed to talk.
A=SPOLL (701)	Sets variable A equal to the decimal value of the Status Byte of the instrument with listen address "1".

3.7.39 HEWLETT PACKARD SERIES 80 PROGRAM EXAMPLES

For the following program examples, the listen address is "1" and the controller interface is select code "7".

Table 3-16 lists some of the Series 80 Controller statements that may be useful in programming the AC Power System on the GPIB. For additional statements and their descriptions, refer to the Hewlett Packard I/O programming guide for the series 80 Computer.

The following program will step the program voltage from 0 volt to 130 volts in .1 volt steps:

```
10 REMOTE 7
20 FOR V=0 TO 130 STEP .1
30 OUTPUT 701; "AMP"; V
40 NEXT V
50 END
```

The following program will load the parameters of 115 volts and 400 hertz. The Model AC Power System will output the parameters only after the K1 special function key of the Series 80 Controller is depressed to send the GET message.

```
10 REMOTE 701
20 OUTPUT 701 ; "AMP115 FRQ 400 TRG"
30 ENABLE KBD 32+64 ! ENABLE PAUSE AND SPECIAL FUNCTION KEYS
40 ON KEY # 1 GOTO 100 ! USE KEY K1 FOR DEVICE TRIGGER
50 GOTO 40

100 TRIGGER 701
110 END
```

The program example for SRQ uses the statements STATUS, ON INTR, ENABLE INTR, AND SPOLL.

The STATUS statement in line 20 is necessary to clear the Controller status register from any possible previous Service Request (SRQ) interrupts. The HP I/O Programming Manual is not clear on the use of the STATUS statement but it must be used after every SRQ and before enabling or reenabling the SRQ interrupt to prevent false SRQ indication. Line 30 causes the program to go to the interrupt subroutine at line 100.

The ENABLE INTR statement in line 40 enables the SRQ to generate an interrupt. A setup string in line 60 causes an SRQ to be generated. The SRQ interrupt subroutine is between lines 100 and 150.

The STATUS statement in line 120 clears the SRQ.

Line 130 generates a Status Byte from the AC Power System with listen/talk address "1".

```
10  REMOTE 701 ! PUT INSTRUMENT#1 INTO REMOTE
20  STATUS 7,1,;Z! READ STATUS TO CLEAR HP SERIES 80 STATUS
    REGISTER.
30  ON INTR 7 GOSUB 100! ON SRQ GO TO ROUTINE AT LINE 100.
40  ENABLE INTR 7;8! ENABLE HP SERIES 80 FOR SRQ INTERRUPT.
50  ! THE FOLLOWING SETUP STRING WILL GENERATE AN SRQ AFTER COM-
    PLETION.
60  OUTPUT 701; AMP105 DLY10 VAL115 SRQ2.
70  WAIT 20000!
80  DISP "SETUP STRING DIDN'T GENERATE AN SRQ".
90  END
100 ! SERVICE REQUEST FOR DEVICE 1
110 ! USE SERIAL POLL TO DETERMINE STATUS BYTE
120 STATUS 7,1;Z ! READ STATUS TO CLEAR SRQ
130 A=SPOLL (701)
```

CAUTION

Voltages up to 480 VAC are available in certain sections of this power source. This equipment generates potentially lethal voltages.

DEATH

on contact may result if personnel fail to observe safety precautions. Do not touch electronic circuits when power is applied.

SECTION 4

CALIBRATION PROCEDURE

4.1 GENERAL

The calibration is divided into two categories; a periodic and a nonperiodic calibration. The periodic calibration should be performed at a 1 year interval. The nonperiodic calibration should only be performed if the periodic calibration cannot be performed or if an adjustable subassembly is replaced.

The following is a listing of paragraphs that may be performed to fix an indicated problem. Any AC Power System with a 1-phase output or that has more than one chassis will have paralleled amplifiers.

PARAGRAPH	TITLE
4.3.1	OUTPUT VOLTAGE CALIBRATION
	This is a periodic calibration of the output voltage.
4.3.2	VOLTAGE MEASUREMENT CALIBRATION
	This is a periodic calibration of the voltage measurement function.
4.3.3	CURRENT MEASUREMENT CALIBRATION
	This is a periodic calibration of the current measurement function.
4.3.4	POWER MEASUREMENT CALIBRATION
	This is a calibration of the power measurement function.
4.3.5	REMOTE MEASUREMENT CALIBRATION
4.4.1	OUTPUT FREQUENCY CALIBRATION
	This is a nonperiodic calibration of the output frequency.
4.4.2	AMPLIFIER GAIN BALANCE ADJUSTMENT
	These are nonperiodic adjustments of the output amplifier assembly 4009-416. The adjustments may have to be performed for the following reasons:

1. An output amplifier has been repaired.

2. For all power systems except 4500L-3PT and 2750L-3PT, unable to obtain rated output current.

3. There is an output current from an amplifier used in any power system, except 4500L-3PT and 2750L-3PT, when there is no load on the system output.

4.4.3 CURRENT TRANSFORMER ADJUSTMENT

These are nonperiodic adjustments. The adjustments are required if it is impossible to perform the current or power measurement calibration (Ref. Paragraph 4.3.3 and/or 4.3.4).

4.4.4 LOAD BALANCE ADJUSTMENT

This is a nonperiodic adjustment. The adjustment is required if the rated output current is not available from an AC Power System.

4.4.5 CURRENT LIMIT CALIBRATION

This is a nonperiodic calibration. The calibration is required if the available output current is not equal to the programmed current limit value. The available output current may exceed the programmed value by 10%.

4.4.6 OUTPUT PHASE ANGLE CALIBRATION

This is a nonperiodic calibration. The calibration is required if there is an error in the phase B or C output phase angle relative to phase A.

4.2 TEST EQUIPMENT

The following equipment or their equivalents are required to completely test the AC Power System.

TEST EQUIPMENT FOR PERIODIC CALIBRATION

1. Digital Voltmeter: Fluke Model 8840A (modified per CIC005) or equivalent.

2. 100 Amp Current Transformer: Pearson Model 3468

3. Resistive Loads: See LOAD RES value from Table 4-1

ADDITIONAL TEST EQUIPMENT

1. Two additional Digital Voltmeters
2. Frequency Counter: Philips PM 6671
3. Phase Angle Meter: Krohn-Hite 6500A



FIGURE **4-1**

INTERNAL ADJUSTMENTS AND JUMPER LOCATIONS

	MODEL	4500L/1-3	9000L/2-3	4500L/1-1 9000L/2-2 13500L/3-3	9000L/2-1 27000L/6-3	13500L/3-1	27000L/6-1
	VA Per Phase	1667	3333	5000	10000	15000	30000
135/270 RANGE	LOAD RES	10.9	5.46	3.64	1.82	1.21	0.607
"	CURRENT LIMIT:						
	PROGRAM VALUE	10	20	30	60	90	180
	SET VALUE	10.7	21.5	32	64.5	96.8	194
156/312 RANGE	LOAD RES	14.59	7.3	4.86	2.43	1.62	0.811
"	CURRENT LIMIT:						
	PROGRAM VALUE	7.4	15	22.4	44.9	67.3	154
	SET VALUE	8	16.1	24	48.3	72.4	165
67.5/135 RANGE	LOAD RES	2.73	1.36	0.91	0.455		
"	CURRENT LIMIT:						
	PROGRAM VALUE	20	41	61	121		
	SET VALUE	21.4	43.8	65.2	129.4		
200/400 RANGE	LOAD RES	24	12	8	4	2.66	1.33
	CURRENT LIMIT:						
	PROGRAM VALUE	6.6	13.3	20	40	60	120
	SET VALUE	7	14	21.4	42.8	64	129

SETUP LOAD VALUES

TABLE 4-1

	MODEL	2750L/1-3	2750L/1-1
	VA Per Phase	1667	3333
135/270 RANGE	LOAD RES	18.2	6.07
"	CURRENT LIMIT:		
	PROGRAM VALUE	6	18
	SET VALUE	6.4	19.3
156/312 RANGE	LOAD RES	24.3	8.1
"	CURRENT LIMIT:		
	PROGRAM VALUE	4.5	13.5
	SET VALUE	4.8	14.4
67.5/135 RANGE	LOAD RES	4.55	1.51
"	CURRENT LIMIT:		
	PROGRAM VALUE	12	36
	SET VALUE	12.8	38
200/400 RANGE	LOAD RES	40	13.3
	CURRENT LIMIT:		
	PROGRAM VALUE	4	12
	SET VALUE	4.3	13

SETUP LOAD VALUES

TABLE 4-1 (continued

4.3 PERIODIC CALIBRATION

The following periodic calibration adjustments should be performed on a 1 year interval.

4.3.1 VOLTAGE CALIBRATION

For the following adjustments, remove all loads from the output. The "External Sense" inputs must be connected to the Master Power Source. Refer to Figure 4-2.

1) Connect the AC DVM to the phase A output of the Master Power Source.

2) Program 135.0 volts and 400 Hz. Adjust R109 on the Current Limit Board of the master power source for 135.0 ±0.1V rms.

3) Program 60 Hz. Adjust R39 on the phase A board of the oscillator for 135.0 ±0.05V rms.

4) Repeat steps 2) and 3) until the output is within 135.0 ±0.1V rms without readjustment.

Continue for all 3-phase power systems.

5) Connect the AC DVM to the phase B output (B of Master for 4500l-3 and 9000L/2-3, A output of first phase B source for all others).

6) Program 135.0 volts and 400 Hz. Adjust R110 on the Current Limit Board of the Master Power Source for 135.0 ±0.1V rms.

7) Program 60 hz. Adjust R48 on the phase B and C board of the oscillator for 135.0 ±0.05V rms.

8) Repeat steps 6) and 7) until the output is within 135.0 ±0.1V rms without adjustment.

9) Connect the AC DVM to the phase C output (output of the 2750L-3P, the Master for 4500L-3 and 9000L/2-3, A output of the first phase C source for all others).

10) Program 135.0 volts and 400 Hz. Adjust R111 on the Current Limit Board of the Master Power Source for 135.0 ±0.1V rms.

11) Program 60 Hz. Adjust R47 on the phase B and C board of the oscillator for 135.0 ±0.05V rms.

12) Repeat steps 10) and 11) until the output is within 135.0 ±0.1V rms without readjustment.

4.3.2 VOLTAGE MEASUREMENT CALIBRATION

For calibration of voltage measurement first perform the output voltage calibration and then perform the followings steps:

1. Remove the load from the AC Power System and program 60 Hz and 135.0 volts.

2. Depress the MNU key several times until the Menu screen is displayed as illustrated below:

```
THD = 00     SNC = 01
DRP = 02    *WVF = 03
```

*May not be displayed. Depends on configuration.

3. Enter the key sequence: 959 ENT.

4. Depress the MNU key several times until the configuration menu screen is displayed.

```
CFG = 16     ALM = 17
FLM = 18     CLM = 19
```

5. Enter the key sequence 13 ENT to access the CAL VLT screen.

6. If all phases of the voltage measurement are to be calibrated to 135.0, enter the key sequence:

   135 PRG ENT

   After about 5 seconds, the volt measurement function will be calibrated for all three phases.

   If only one phase is to be calibrated to 135.0 volts (ex., phase A) enter the key sequence:

   135 A PRG ENT



FIGURE 4-2

EQUIPMENT HOOKUP FOR PERIODIC CALIBRATION

4.3.3 CURRENT MEASUREMENT CALIBRATION

For calibration of current measurement perform the following steps:

1. Program 60 Hz, 135.0 volts and the maximum Current Limit value.

2. If any calibration screen is already displayed, the Current Calibration screen (CAL CUR) may be displayed by repeatedly depressing either the MON or PRG keys and then skip to step 6. If a calibration screen is not displayed, press the MNU key several times until the screen shown below is displayed:

   ```
   THD = 00    SNC = 01
   DRP = 02   *WVF = 03
   ```

   * Option

3. Enter the key sequence: 959 ENT

4. Depress the MNU key several times until the configuration menu screen is displayed, as shown below:

   ```
   CFG = 16        ALM = 17
   FLM = 18        CLM = 19
   ```

5. Enter the key sequence: 14 ENT to access the CAL CUR screen.

6. Determine the full load resistive value from the LOAD RES value from Table 4-1. Apply the load to the phase A output only. Measure the phase A output current with the AC Digital Voltmeter and Current Transformer.

7. On the keypad enter the key sequence:

   (Measured phase A current. Example 11.05) A PRG ENT

   After about 5 seconds the current measurement function for phase A will be calibrated.

8. Repeat step 6 for phase B.

9. Repeat step 7 except enter the key sequence:

   (Measured phase B current) B PRG ENT

10. Repeat step 6 for phase C.

11. Repeat step 7 except enter the key sequence:

    (Measured phase C current) C PRG ENT

4.3.4 POWER MEASUREMENT CALIBRATION

For calibration of power measurement perform the following steps:

1. Program 60 Hz and 135.0 volts and the maximum Current Limit value.

2. If any calibration screen is already displayed, the Power Calibration screen (CAL PWR) may be displayed by depressing either the MON or PRG keys and then skip to step 6. If a calibration screen is not displayed, depress the MNU key several times until the screen shown below is displayed:

    ```
    THD = 00    SNC = 01
    DRP = 02   *WVF = 03
    ```

    * Option

3. Enter the key sequence: 959 ENT

4. Depress the MNU key several times until the configuration menu screen is displayed as shown below:

    ```
    CFG = 16    ALM = 17
    FLM = 18    CLM = 19
    ```

5. Enter the key sequence 15 ENT to access the CAL PWR screen.

6. Apply the LOAD RES value from Table 4-1 to the phase A output only. Measure the phase A output current with the AC Digital Voltmeter and Current Transformer. Measure the phase A voltage from the phase A sense to neutral sense. Multiply the voltage and current values to determine the power value. (Note: The load must be resistive for the correct power value.)

7. On the keypad enter the key sequence:

    (Measured phase A power) A PRG ENT

8. Repeat step 6 for phase B.

9. Repeat step 7 except enter the key sequence:

    (Measured phase B phase) B PRG ENT

10. Repeat step 6 for phase C.

11. Repeat step 7 except enter the key sequence:

    (Measured phase C power) C PRG ENT

4.3.5 REMOTE MEASUREMENT CALIBRATION

The measurement function of the AC Power System may be remotely calibrated. The equipment hookup is the same as before except an IEEE-488 Controller must be used to program the AC Power System. The values for the VLT, CUR and PWR strings must be derived from the external AC Digital Voltmeters and Current Transformer.

To calibrate the measured voltage, first program the AC Power System to 135.0 volts and 60 Hz. Send the following calibration string:

CAL VLT (1) (Desired voltage value for phase (1))

To calibrate the measured current send the following string:

CAL CUR (1) (Desired current value for phase (1))

To calibrate the measured power value send the following string:

CAL PWR (1) (Desired power value for phase (1))

NOTE: (1) May be blank or include an A, B or C extension.

4.4 NONPERIODIC CALIBRATION

If adjustments are required for these nonperiodic calibrations, the top cover of the AC Power System will have to be removed. A nonperiodic calibration will only be required if a related assembly is repaired or if the performance is out of specification.

4.4.1 OUTPUT FREQUENCY CALIBRATION

Connect the Frequency Counter to the phase A output. Program the output to 135.0 volts and 400.0 Hz. Engage the low-pass filter on the Frequency Counter to obtain the output frequency.

If the Frequency Counter does not indicate 400.000 ±0.004 Hz, adjust C43 for the correct frequency. Refer to Figure 4-1.

4.4.2 GAIN BALANCE ADJUSTMENT

CAUTION

The Gain Balance Adjustment should not be made unless an amplifier assembly has been repaired. Each amplifier has been adjusted at the factory for an exact full scale output voltage (135, 67.5, 156 or 200 volts for standard, LV, HV or EHV voltage ranges) with a 5.000 VRMS amplifier input voltage. The amplifier input voltage may be checked at TP4, TP5 and TP6 on the Current Limit Board for Phase A, B and C amplifiers respectively. TP1 is the reference test point.

The following adjustment is for all power system models except the 2750L-3PT and 4500L-3PT. The 2750L-3PT and 4500L-3PT do not require a gain balance adjustment. Before performing the adjustment, the top cover of each power source must be removed. Remove the Current Limit Board and temporarily remove jumper W2, if it is installed.

If the output of any 4500L is connected to the output of any other 4500L (ex. 9000L/2-1, 9000L/2-3, 13500L/3-1, 27000L/6-3, 27000L/6-1) remove the connection.

The External Sense input to the master 4500L must remain connected. Refer to Figure 2-2 and 2-3 for the proper External Sense connections.

The following steps will verify that the amplifiers to be paralleled have been adjusted to the same gains. In order to perform this, the AC DVM input LO will be connected to the first amplifier output of a given phase. This output is referred to as ALO, BLO or CLO for the respective phase A, B or C output. The AC DVM HI will be connected to each amplifier's output. The amplifiers output is referred to as AHI, BHI or CHI on the AMPLIFIER GAIN BALANCE table.

1. Use the AMPLIFIER GAIN BALANCE table to check all of the amplifiers for the system being tested.

   For the output from each amplifier of a given phase, the AC DVM should display less that 0.25 VAC while the DVM is on the 200 VAC range.

2. If any measurement from the GAIN BALANCE check is out of specification, the gain of the amplifier with the AC DVM input LO test lead connected must first be checked.

   To check the gain of the amplifier, connect the AC DVM between the Output Neutral and Output High of the corresponding output. Connect an additional AC DVM HI input test point of the Current Limit Board indicated below. Connect the LO input to TP1.

OUTPUT	TEST POINT	ADJUSTMENT
A	TP4	R105 PHASE A AMP
B	TP5	R105 PHASE B AMP
C	TP6	R105 PHASE C AMP

3. Program the output to 135.0 or the maximum voltage allowed on the corresponding Voltage Range.

4. With exactly 135.0 volts, or the maximum voltage allowed on the range, the Current Limit test point must be 5.000 ±1mV.

5. Adjust R105 so that the voltage at the test point is 5.000 volts or = Vout(5/Vmax) if Vmax is not 135 volts.

6. Repeat step 1) and adjust R105 of the amplifier for the respective output so that the output balance voltage is at a minimum.

7. Remove the input power and reinstall jumper W2 (if it was removed) on the Current Limit Board in all 4500Ls and 2750Ls.

8. Reconnect the outputs as shown in Figures 2-2 and 2-3.

SYSTEM	MASTER			SLAVE #1			SLAVE #2		
	A	B	C	A	B	C	A	B	C
2750L-1 4500L-1	ALO	AHI	AHI						
9000L/2-1	ALO	AHI	AHI	AHI	AHI	AHI			
9000L/2-3	ALO	BLO	CLO	AHI	BHI	CHI			
13500L/3-1 27000L/6-1	ALO	AHI	AHI	AHI	AHI	AHI	AHI	AHI	AHI
	[Additional slaves same as Slave #1]								
9000L/2-2	ALO	AHI	AHI	AHI	AHI	AHI	AHI	AHI	AHI
13500L/3-3	Additional A Slaves same as Master except A output measured as AHI								
27000L/6-3	Additional B Slaves same as Master except A output measured as BHI								
	Additional C Slaves same as Master except A output measured as CHI								

AMPLIFIER GAIN BALANCE TABLE

4.4.3 CURRENT TRANSFORMER ADJUSTMENT

The following adjustments must be made with jumper W2, on the Current Limit Assembly, removed. If the output of any 4500L is connected to the output of any other 4500L (ex. 9000L/2-1, 9000L/2-3, 13500L/3-1, 27000L/6-3, 27000L/6-1) remove the connection.

The External Sense input to the Master 4500L must remain connected.

For the following adjustments a load resistor must be connected to each output of every 4500L in the system. The load resistor must be capable of loading an amplifier to approximately 9 amps. Only one amplifier at a time needs to be loaded.

1. Monitor the phase A output current with the Current Transformer and AC DVM. Measure the phase A voltage between TP10 and TP1 on the Current Limit Assembly.

2. Turn on the AC input to the AC Power System. Program 60 Hz and an output voltage that generates an output circuit of approximately 9 amps (5 amps for the 2750L).

3. Apply the resistive load to the output. Adjust R4 on the Range Relay assembly for the correct voltage at TP10 for the load current: (1 volt = 10 Amps). Remove the load before loading the next output to be calibrated.

4. Repeat steps 1 through 3 for A, B and C outputs of all power sources. Refer to the following table for the adjustments and test points.

CURRENT TRANSFORMER ADJUSTMENTS

OUTPUT	ADJUSTMENT (Range Relay Assy)	TEST POINTS (TP1 is Gnd.) (Current Limit Assy)
A	R4	TP10
B	R10	TP2
C	R16	TP3

5. Reinstall jumper W2 on all Current Limit Assemblies if it has been removed. Reconnect all outputs as shown in Figures 2-2 and 2-3.

4.4.4 LOAD BALANCE ADJUSTMENT

CAUTION

> The Load Balance Adjustment should not be made unless an amplifier assembly has been repaired. Each amplifier has been adjusted at the factory for an output regulation of -1.48% with a 1500 watt load.

The following adjustment procedure is for all power systems except the 4500L-3PT and 2750L-3PT. The power system must be connected as shown in Figure 2-2. A load resistor, see LOAD RES in Table 4-1, must be connected to the phase A, B or C output of the power system.

For the following adjustments, two external AC DVMs must be used. The DVMs must be connected to test points on the Current Limit Board, A9. The input LO for the DVM is TP1 of the respective Current Limit Board. For all test points and adjustments, refer to Table 4-2 for the respective power system.

1. Program the output to the low voltage range and the output voltage to 80% of range. Program the frequency to 200 Hz and the maximum Current Limit. Apply the LOAD RES identified in Table 4-1 for the respective power system. Check that voltages listed in Table 4-2. Check that the voltage at the respective test points are within ±0.1 volts of the reference test point.

2. Program the output to the maximum voltage and recheck the Table 4-2 test points. If they differ by more than ±0.2 volts from the reference, readjust the adjustments at this full load current.

SYSTEM	LOAD	SOURCE	TEST POINT (Current Limit Board)	ADJUSTMENT IF NEEDED	ADJUST FOR: (±0.1V)
4500L-1 2750L-1	A	MASTER	TP10	None	Monitor voltage for reference
	"	"	TP2	R1 AMP B	Same voltage as TP10
	"	"	TP3	R1 AMP C	"
9000L/2-1	A	MASTER	TP10	None	Monitor voltage for reference
	"	"	TP2	R1 AMP B	Same voltage as MASTER TP10
	"	"	TP3	R1 AMP C	"
	"	SLAVE	TP10	R1 AMP A	Same voltage as MASTER TP10
	"	"	TP2	R1 AMP B	"
	"	"	TP3	R1 AMP C	"
9000L/2-3, and 18000/4-3	A	MASTER	TP10	None	Monitor voltage for reference
	"	SLAVES	TP10	R1 AMP A	Same voltage as MASTER TP10
	B	MASTER	TP2	None	Monitor voltage for reference
	"	SLAVES	TP2	R1 AMP B	Same voltage as MASTER TP2
	C	MASTER	TP3	None	Monitor voltage for reference
	"	SLAVES	TP3	R1 AMP C	Same voltage as MASTER TP3

TABLE 4-2

AMPLIFIER GAIN BALANCE ADJUSTMENT

SYSTEM	LOAD	SOURCE	TEST POINT (Current Limit Board)	ADJUSTMENT IF NEEDED	ADJUST FOR: (±0.1V)
13500L/3-1	A	MASTER	TP10	None	Monitor voltage for reference
	"	"	TP2	R1 AMP B	Same voltage as MASTER TP10
	"	"	TP3	R1 AMP C	" "
	"	SLAVE #1	TP10	R1 AMP A	Same voltage as MASTER TP10
	"	"	TP2	R1 AMP B	" "
	"	"	TP3	R1 AMP C	" "
	"	SLAVE #2	TP10	R1 AMP A	Same voltage as MASTER TP10
	"	"	TP2	R1 AMP B	" "
	"	"	TP3	R1 AMP C	" "
13500L/3-3	A	MASTER	TP10	None	Monitor voltage for reference
9000L/2-2	"	"	TP2	R1 AMP B	Same as MASTER TP10
	"	"	TP3	R1 AMP C	" "
Not for	B	SLAVE #1B	TP10	None	Monitor voltage for reference
9000L/2-2	"	"	TP2	R1 AMP B	Same as SLAVE 1B TP10
	"	"	TP3	R1 AMP C	" "
	C	SLAVE #1C	TP10	None	Monitor voltage for reference
	"	"	TP2	R1 AMP B	Same as SLAVE 1C TP10
	"	"	TP3	R1 AMP C	" "

TABLE 4-2 (continued)

AMPLIFIER GAIN BALANCE ADJUSTMENT

SYSTEM	LOAD	SOURCE	TEST POINT (Current Limit Board)	ADJUSTMENT IF NEEDED	ADJUST FOR: (±0.1V)
27000L/6-1	A	MASTER	TP10	None	Monitor voltage for reference
	"	"	TP2	R1 AMP B	Same voltage as MASTER TP10
	"	"	TP3	R1 AMP C	" "
	"	SLAVE #1	TP10	R1 AMP A	" "
	"	"	TP2	R1 AMP B	" "
	"	"	TP3	R1 AMP C	" "
	"	SLAVE #2	TP10	R1 AMP A	" "
	"	"	TP2	R1 AMP B	" "
	"	"	TP3	R1 AMP C	" "
	"	SLAVE #3	TP10	R1 AMP A	" "
	"	"	TP2	R1 AMP B	" "
	"	"	TP3	R1 AMP C	" "
	"	SLAVE #4	TP10	R1 AMP A	" "
	"	"	TP2	R1 AMP B	" "
	"	"	TP3	R1 AMP C	" "
	"	SLAVE #5	TP10	R1 AMP A	" "
	"	"	TP2	R1 AMP B	" "
	"	"	TP3	R1 AMP C	" "

TABLE 4-2 (continued)

AMPLIFIER GAIN BALANCE ADJUSTMENT

SYSTEM	LOAD	SOURCE	TEST POINT (Current Limit Board)	ADJUSTMENT IF NEEDED	ADJUST FOR: (±0.1V)
27000L/6-3	A	MASTER	TP10	None	Monitor voltage for reference
	"	"	TP2	R1 AMP B	Same voltage as MASTER TP10
	"	"	TP3	R1 AMP C	" "
	"	SLAVE #1A	TP10	R1 AMP A	" "
	"	"	TP2	R1 AMP B	" "
	"	"	TP3	R1 AMP C	" "
	B	SLAVE #1B	TP10	None	Monitor voltage for reference
	"	"	TP2	R1 AMP B	Same voltage as SLAVE #1B TP10
	"	"	TP3	R1 AMP C	" "
	"	SLAVE #2B	TP10	R1 AMP A	" "
	"	"	TP2	R1 AMP B	" "
	"	"	TP3	R1 AMP C	" "
	C	SLAVE #1C	TP10	None	Monitor voltage for reference
	"	"	TP2	R1 AMP B	Same voltage as SLAVE #1C TP10
	"	"	TP3	R1 AMP C	" "
	"	SLAVE #2C	TP10	R1 AMP A	" "
	"	"	TP2	R1 AMP B	" "
	"	"	TP3	R1 AMP C	" "

TABLE 4-2 (continued

AMPLIFIER GAIN BALANCE ADJUSTMENT

4.4.5 CURRENT LIMIT CALIBRATION

1. Remove jumper W5 from the Current Limit Board of each power source. Select the Current Limit (CRL) screen (Screen 8) and program the Current Limit PROGRAM VALUE from Table 4-1.

2. Monitor the power system phase A output current with the external current transformer and AC DVM. Connect an oscilloscope to the output.

3. Program the low voltage range and the voltage to 80% of range. Program the frequency to 60 Hz.

4. Apply the LOAD RES value from Table 4-1 to the power system phase A output only.

5. Increase the output amplitude slowly until the external AC current transformer indicates SET VALUE from Table 4-1. Slowly turn A9-R17 on the Current Limit Assembly in a counterclockwise direction until the output OVERLOAD indicator starts to illuminate.

6. Slowly readjust R17 in a clockwise direction just to a point that the OVERLOAD extinguishes. Repeat this step for all ADJUSTMENTS listed in Table 4-3 for phase A.

7. Remove the load for phase A and repeat steps 2) through 6) for phase B and C. Adjust the controls specified in Table 4-3 for phase B and C. Turn off all circuit breakers and install all W5 jumpers.

8. Turn on the circuit breakers. Program the CRL value to 5 amps and full voltage. Verify the output faults when any phase has the LOAD RES load value.

SYSTEM	PHASE LOADED	ADJUSTMENT	POWER SOURCE
2750L-3, 4500L-3	A	R17	MASTER
	B	R46	"
	C	R72	"
4500L-1,	A	R17	MASTER & SLAVES
9000L/2-1,13500L/3-1,	A	R46	" "
27000L/6-1	A	R72	" "
9000L/2-3	A	R17	MASTER & SLAVES
	B	R46	" "
	C	R72	" "
13500L/3-3,	A	R17	MASTER
27000L/6-3	A	R46	MASTER
9000L/2-2	A	R72	MASTER
	B	R17	ALL SLAVES FOR øB
	B	R46	" "
	B	R72	" "
	C	R17	ALL SLAVES FOR øC
	C	R46	" "
	C	R72	" "

TABLE 4-3

CURRENT LIMIT ADJUSTMENT

4.4.6 OUTPUT PHASE ANGLE CALIBRATION

The phase calibration values for phases B and C are entered on the Phase Offset (POF) screen.

To calibrate the output phase angle, connect either a Phase Meter or an oscilloscope between the phase to be calibrated and the phase A output. Program the phase B or C value to be calibrated from the Phase screen (PHZ). If an oscilloscope is used the calibration is best performed with a programmed angle of 0 degrees.

To calibrate the output phase angle, program 120.0 volts and 60 Hz.

To access the POF screen perform the following key sequences:

1. Access the Phase screen (PHZ).

2. Depress the MNU key several times until the following screen is displayed:

```
THD = 00        SNC = 01
DRP = 02        WVF = 03
```

3. Enter the key sequence: 959 ENT

4. Depress the MNU key several times until the Configuration menu screen is displayed:

```
CFG = 16        ALM = 17
FLM = 18        CLM = 19
```

5. To display the POF screen enter the key sequence: 20 ENT

If an oscilloscope is used and the respective phase is programmed to 0 degrees and 200 Hz, a 3 degree error is represented by 41 microseconds of the 0 volt point of the two signals.

The POF values may be either a positive or negative value. A negative value is entered by depressing the period key (.) two times after the numerical value is entered before the PRG key is depressed.

SECTION 5

THEORY OF OPERATION

5.1 GENERAL

An explanation of the circuits within the AC Power System is given in this section. Refer to Figure 5-1 for a block diagram of the AC Power System.

5.2 OVERALL DESCRIPTION

Input power from the rear panel is routed through the circuit breaker to the Input Power Supply (A5). DC voltages from the Input Power Supply are routed to the Power Mother Board (A4), the Control Mother Board (A8) and the Auxiliary Power Supply (A7).

The Programmable Oscillator assembly (A11) generates the oscillator waveforms and power source control and measurement signals. The oscillator assembly is connected to the rest of the power source through the Control Mother Board, A10.

The three amplifier modules are A1, A2 and A3. They take their DC supply voltages and input signal from the Power Mother Board, A4. They produce the high power outputs for the primary of the output transformers, T1, T2 and T3. The outputs are routed through the Power Mother Board to the output transformers.

The Range Relay Board is identified as A6. This board assembly configures the secondaries of the output transformers for the correct output voltage range. The outputs from the AC Power System are taken from the Range Relay Board. This board also has relays that switches the output to the 1-phase mode and opens the outputs. There is also a circuit on the board that senses for incorrect sense line connections.

The board assemblies are described in more detail in the following paragraphs.

5.3 INPUT POWER SUPPLY

This assembly is identified as A5. It generates the high power +300 VDC supply. This supply voltage is connected to the filter capacitor, C1, and to the Power Mother Board. C1 is mounted on the bottom cover of the AC Power System.

The Input Power Supply also has circuits that generate the DC voltages identified as $\pm$18V, $\pm$15VSW, +8VSW and +8V.

The $\pm$18V supplies are used for the Oscillator Module and the current Limit Board. The +8V supply is used for the Oscillator Module. the $\pm$15VSW and +8VSW supplies are used for the three Amplifier Modules.



FIGURE 5-1
AC POWER SYSTEM BLOCK DIAGRAM

5.4 AUXILIARY POWER SUPPLY

The Auxiliary Power Supply receives the +300 supply voltage from the Input Power Supply. The +300 supply voltage is then changed to the +50 VDC supply voltage for operating the fans and relays. In addition to the +50 VDC supply, +15VSW1 is also generated. This supply voltage is used for the gate drive signal in the Amplifier Modules.

5.5 CURRENT LIMIT BOARD

The Current Limit Board receives the oscillator signals identified as OSC A, B and C from the Oscillator Module. Analog switches on this board direct the oscillator signals to the respective amplifier module. The analog switches switch the OSC A signal to the three amplifier inputs during 1-phase operation. For 3-phase operation, OSC A, B and C are switched to the amplifiers A, B and C inputs respectively. Gain adjustments are located on this board to match the gains of the 3 Amplifier Modules.

The current limit circuits are also located on the Current Limit Board. These circuits receive a DC signal from the Oscillator Module, CLA, B and C, that is proportional to the current limit value. This DC signal is compared to the output current. The output current signal is identified as TA, TB and TC. This signal is routed to the Current Limit Board from current transformers on the Range Relay Board. If the output current exceeds the programmed value, an attenuator will limit the output voltage to a value that will cause the AC Power System to operate at a constant current. If the output current limits the output voltage to 10% of the programmed voltage amplitude value, the output will default and an AMP FAULT error message will be displayed. The error message will also be reported through the IEEE-488 (GPIB) interface.

The Current Limit Board has analog switches and summing amplifiers that are used for current measurements. The outputs from the summing amplifiers, CT A, B and C, are routed to the Oscillator Module for measurement. In the 1-phase mode the current from all 3 output current transformers are summed together for measurement. This signal is identified as CT A.

5.6 INDICATOR BOARD

The Indicator Board has the reference designator, A12. This board has LED indicators for the HI RANGE, OVERTEMP and OVERLOAD conditions.

A front panel selector switch is mounted on the Indicator Board. This switch is used to connect the front panel analog meter, M1, to either the phase A, B or C output.

5.7 RANGE RELAY BOARD

The Range Relay Board has all of the AC Power System relays. These Relays are operated from +50 VDC. The output relay is opened by a logic low on the CNF control line. The range relay is switched to the high voltage range by a logic low on the $\overline{\text{RNG HI}}$ control line. The output is in the 1-phase mode when the PARALLEL control line is driven to approximately +10 VDC.

There are three current transformers on the Range Relay board. These transformers generate an AC voltage that is proportional to the output current. The voltages are identified as TA, TB and TC. A 10 amp load current is represented by a 1.00 VAC signal in the 3-phase mode.

5.8 AMPLIFIER MODULES

The AC Power System has three Amplifier Modules. In the 3- phase mode, one amplifier is used for each of the three outputs. In the 1-phase mode, the three outputs are paralleled at the secondaries of the output transformers.

The Amplifier Modules operate in a switch mode to obtain high efficiency. These switch mode amplifiers operate at 200 KHz.

Each Amplifier Module obtains its input signal from the Current Limit Board. These three input signals are identified as ØA SIG ØB SIG and ØC SIG. A 5.00 VRMS input signal will generate a full scale output voltage at the output of the AC Power System and 100.0 Vrms on the primary of the output transformer.

Each Amplifier Module requires +300 DC, ±15 VSW, and the +15 VSW1 supplies. The +300 VDC supply comes from the Input Power Supply through a 15 amp fuse on the Power Mother Board.

The Amplifier Module has a thermoswitch mounted on its heatsink. If the heatsink temperature reaches 100°C, a control signal is sent to the Oscillator Module. A logic low on the $\overline{\text{OVER TMP}}$ control line will cause the error message TEMP FAULT to be generated.

5.9 OSCILLATOR MODULE

The Oscillator Module is identified with the reference designator, A11. The module consists of three printed circuit assemblies. These three assemblies are interconnected with a small mother board, A11A2. The oscillator Display Assembly connects to the Oscillator Module with a short ribbon cable. The Display Assembly is mounted on the front panel. The block diagram of the Oscillator Module is shown in Figure 5-2.



FIGURE 5-2
PROGRAMMABLE OSCILLATOR MODULE

5.10 CPU/GPIB BOARD

The CPU/GPIB board, A11A3, provides the control and measurement functions of the module. A microprocessor circuit accepts commands from the GPIB on the front panel keyboard. It sends digital programming information to set the output parameters of the power source. Data from measurement circuits is accepted and reported to the display and GPIB. Measurement calibration coefficients are stored in a memory backed up by a battery. The battery has a 10 year life expectancy.

Measurement circuits on the CPU/GPIB board monitor voltage, current, power, frequency, and phase angle. Voltage from the rear panel sense connector is scaled, converted to a DC voltage by a true-rms-converter, and sent to the microprocessor by the analog-to-digital converter.

Current sensed by internal current transformers is scaled, converted to a DC voltage by a true-rms-converter, and sent to the microprocessor by the analog-to-digital converter.

The scaled voltage and current waveforms are applied to the inputs of a multiplier. The multiplier output is filtered to a DC level and digitized by the analog-to-digital converter.

Frequency is computed from the measured time intervals between zero crossings of the Phase A waveform. Phase is computed from the differences of measured zero crossings between the Phase A signal and the Phase B or Phase C signal.

A digital-to-analog converter on the CPU/GPIB board sets the DC voltages that are used for the programmable current limit function.

5.11 PHASE A/REF BOARD

The Phase A/Ref Board, A11A5, serves several purposes. A programmable clock sets the output frequency of the power source. Digital-to-analog converters program references to set the output amplitude of Phases A, B and C. A sine wave generator creates a 1024 step waveform which is filtered to provide the Phase A oscillator signal. A external sense amplifier controls the Phase A output amplitude.

5.12 PHASE B/C BOARD

The Phase B/C Board, A11A4, uses the DC voltage references and programmable clock from the Phase A/Ref board to generate the Phase B and C oscillator waveforms. External sense circuits control the Phase B and C output amplitudes.

5.13 DISPLAY MODULE

The Display Board, A11A13, is held to the power source by a small panel and is connected through a short ribbon cable. It holds the 20 button keyboard and a 32 character LCD display. A knob on the board allows the display viewing angle to be adjusted.

CAUTION

Voltages up to 480 VAC are available in certain sections of this power source. This equipment generates potentially lethal voltages.

DEATH

on contact may result if personnel fail to observe safety precautions. Do not touch electronic circuits when power is applied.

SECTION 6

MAINTENANCE AND TROUBLESHOOTING

6.1 GENERAL

This section describes the suggested maintenance and troubleshooting procedures. Table 6-1 lists the paragraph titles and page numbers for the Troubleshooting section. If the AC Power System does not appear to function normally, use this section to isolate the problem. If the problem cannot be found using these steps, consult the factory.

TABLE 6-1

PARAGRAPH	PROBLEM	PAGE
6-2	Poor Voltage Accuracy	111
6-3	Poor Output Voltage Regulation	111
6-4	Overtemperature Lamp On	112
6-5	Overload Lamp On	112
6-6	Can't Program AC Power System on GPIB	113
6-7	Distorted Output	113
6-8	No Output	113

6.2 POOR VOLTAGE ACCURACY

If the power source exhibits poor programmed voltage accuracy, the following item may be at fault:

1. The calibration is incorrect.

   SOLUTION: Calibrate the output. Refer to Paragraph 4.3.1.

6.3 POOR OUTPUT VOLTAGE REGULATION

If the AC Power System exhibits poor voltage regulation the following item may be at fault:

1. The External Sense lines are not connected at the same point monitored by the external voltmeter used for load regulation check.

   SOLUTION: Connect AC voltmeter to External Sense lines.

6.4 OVERTEMPERATURE LAMP ON

If the power source OVERTEMP lamp is on, the following may be at fault:

1. Ambient temperature is too high.

   SOLUTION: Operate power source between 0 and 35° C.

2. Fan or ventilation holes are blocked.

   SOLUTION: Remove obstructions.

3. Fan not working.

   SOLUTION: Replace fan. Consult factory.

6.5 OVERLOAD LAMP ON

The OVERLOAD lamp comes on when the output load current has exceeded the programmed current limit value. For all power systems except the 4500L-3PT and the 2750L-3PT, mis-adjustment of either the Amplifier Gain or Load Balance will cause the OVERLOAD Lamp to illuminate. If the AC Power System OVERLOAD lamp is on, the following items may be at fault:

1. The output is overloaded.

   SOLUTION: Remove the overload.

2. The programmable current limit level is set too low for the load being driven.

   SOLUTION: Compute and reprogram the correct programmable current limit level.

3. The programmable current limit is incorrectly calibrated.

   SOLUTION: Perform the calibration in paragraph 4.4.5.

4. The adjustment of the Amplifier Gain Balance or Load Balance is incorrect.

   SOLUTION: Perform the adjustments in paragraph 4.4.2 and 4.4.4.

5. Incorrect AC Power Source configuration. Check the ELT screen. It should show more than 24 hours of operation. If it shows less than 24 hours consult the factory.

6.6 CAN'T PROGRAM AC POWER SYSTEM ON GPIB

If the power source does not respond to IEEE-488 GPIB programming, the following items may be at fault:

1. The power source unit address is wrong.

   SOLUTION: Update address. See paragraph 3.7.1.

2. GPIB cable is loose at power source rear panel.

   SOLUTION: Check connection, tighten jack screws.

3. The oscillator has failed.

   SOLUTION: Replace the oscillator. See Paragraph 6.10.

6.7 DISTORTED OUTPUT

The AC Power System output may have a distorted sine wave from the following causes:

1. The power source output is overloaded.

   SOLUTION: Remove the overload or program the current limit to a higher value. Observe power source capabilities. See Section 1.

2. The crest factor of the load current exceeds 2.5. With this condition the distortion will be much higher at frequencies above 100 Hz.

   SOLUTION: Reduce the load or program the current limit to a higher value.

6.8 NO OUTPUT

If the AC Power System has no output at the rear panel terminal block, TB1, the following items may be at fault:

1. If the External Sense lines are not connected correctly, there will be no output. The error message AMP FAULT will also be generated.

   SOLUTION: Correctly connect the sense lines. Refer to Paragraph 2.5.

2. When the output is overloaded an error message will be generated and the output relays will open. The error message would be CRL FAULT.

SOLUTION: Remove the overload. Observe the output power capabilities. Refer to Section 1.

3. There is no input to the power amplifiers from the oscillator. Check the oscillator signals at the system interface connector:

   J7-24 Oscillator Phase A
   J7-6 Oscillator Phase B
   J7-23 Oscillator Phase C
   J7-7 Oscillator common/return

   Program 135.0 volts on the 135 volt range. The three signals should be 5.0 ±0.10 VAC.

   SOLUTION: If there is no signal at the Systems Interface connector replace the oscillator. Refer to paragraph 6.9.

   SOLUTION: If the signal at the System Interface connector is greater than 5.0 VAC, it may be necessary to replace the respective amplifier. Refer to paragraph 6.11.

4. One of the internal fuses, F1, F2 or F3 has failed.

   SOLUTION: Replace the fuse. Remove the input power and discharge capacitor C1 before replacing the fuse. Refer to paragraph 6.11.

6.9 MODULE REMOVAL

Figure 6-1 shows the location of the internal modules and assemblies. The figure shows the Amplifier Modules, A1, A2 and A3, with the insulator removed.

6.10 OSCILLATOR MODULE REMOVAL/REPLACEMENT

If a fault is found that requires the replacement of the Oscillator Module (assembly 4009-425) follow the following steps and refer to Figure 6-1 for the module locations:

1. Turn off the front panel circuit breaker.

2. Remove the power system's top cover.

3. Remove the Keyboard/Display assembly by loosening the two captive screws on its front panel.

4. Unplug the ribbon cable from the Keyboard/Display assembly.

5. Remove the Oscillator Module, A11, by pulling up the package of PC assemblies.

6. The module is now removed. To replace the module follow these steps in reverse order. Make sure the ribbon cable that plugs into the Keyboard/Display assembly runs between PC assembly, A12, and the front panel.

6.11 AMPLIFIER REMOVAL/REPLACEMENT

If a fault has been found that indicates the failure of an amplifier module (assembly 4009-423), check the condition of the +300 VDC fuses before replacing the amplifier. Refer to Figure 6-1 for the location of the fuses. Fuse F1 is for phase A, F2 for phase B and F3 is for phase C.

CAUTION

Capacitor C1 may have up to +350 VDC after the input circuit breaker has been turned off. Before inspecting fuses F1, F2 and F3, discharge C1. C1 may be discharged through a 5 ohm power resistor.

If it is determined that an amplifier module must be replaced perform the following procedure:

1. Turn off the input circuit breaker.

2. Remove the AC Power System top cover.

3. Remove the four #6 screws that hold the insulator that covers the amplifier module, A1, A2 and A3.

4. Remove any of the three amplifiers by sliding it up and over the guide posts.

5. The amplifier may be replaced by following this procedure in reverse order.

6. Check the amplifiers associated 10 amp fuse and replace it if necessary. Refer to Figure 6-1 for the location of the fuse. F1, F2 and F3 are for the phase A, B and C amplifiers respectively.

7. After an amplifier has been replaced, readjust its gain and the 1-phase adjustment. Refer to Section 4.



FIGURE 6-1
MODULE LOCATION

SECTION 7

REPLACEABLE PARTS

7.1 GENERAL

This section contains ordering information and a complete list of replaceable parts. The parts are listed by their major assembly in alpha-numeric order by their reference designators. The list includes the parts description, manufacturers' identification (see Appendix A for list of manufacturers), and California Instruments' part numbers.

7.2 ORDERING INFORMATION

In order to ensure prompt, accurate service, please provide the following information, when applicable, for each replacement part ordered.

a. Model number and serial number of the instrument.

b. California Instruments part number for the subassembly where component is located (PARENT ITEM NO.).

c. Component reference designator (SEQ NO.).

d. Component description (DESCRIPTION TRUNCATED).

e. Component manufacturer's FSCM number (VENDOR).

f. California Instruments part number (COMPONENT ITEM NO.).

All replacement part orders should be addressed to:

California Instruments
Attention: Parts Department
9025 Balboa Avenue
San Diego, California 92123-1509

TOP ASSEMBLY REPLACEABLE PARTS
FOR 4500L-3PT AND 2750l-3PT
TOP ASSEMBLY NO: 4009-422-1

SEQ NO.	COMPONENT ITEM NO.	DESCRIPTION	VENDOR	QTY
A1	4009-423-1	HEATSINK ASSY, SW AMP	16067	1.0
A2	4009-423-1	HEATSINK ASSY, SW AMP	16067	1.0
A3	4009-423-1	HEATSINK ASSY, SW AMP	16067	1.0
A4	4009-724-1	PC ASSY, MOTHER	16067	1.0
A5	4009-706-1	PC ASSY, POWER SUPPLY	16067	1.0
A6	4009-733-1	PC ASSY, RANGE	16067	1.0
A7	4009-735-1	PC ASSY, AUX POWER SUPPLY	16067	1.0
A8	4009-732-1	PC ASSY, MOTHER, CTRL	16067	1.0
A9	4009-728-1	PC ASSY, CURRENT LIMIT	16067	1.0
A11	4009-425-4	MODULE ASSY, OSC	16067	1.0
A12	4009-707-1	PC ASSY, INDICATOR	16067	1.0
B1	241178	FAN, 6", 48VDC, .45A	63227	1.0
B2	241175	FAN, 4", 48VDC,	23936	1.0
C1	611295	CAP, AL, 3900μF, 400V	80031	1.0
A4F1	270167	FUSE, 15A, 250V	71400	1.0
A4F2	270167	FUSE, 15A, 250V	71400	1.0
A4F3	270167	FUSE, 15A, 250V	71400	1.0

SECTION 8

MIL-STD-704D

8.1 GENERAL

The MIL-704D option is capable of performing all sections of MIL-STD-704D. It will perform all tests in the order listed below or part of the test. There is a 5 second delay between tests to allow the operator to evaluate the result of the test.

8.2 INITIAL SETUP

Nominal parameters for the AC Power Source shall be as follows:

OUTPUT VOLTAGE:	115 L-N
OUTPUT FREQUENCY:	400
OUTPUT PHASE ANGLE:	B 240 C 120

8.3 TEST PERFORMED

8.3.1 Steady state test. (Refer to MIL-704D Doc. Table 1)

1. Voltage per Figure 1, page 129
2. Voltage unbalance per Figure 2, page 129
3. Voltage phase difference per Figure 3, page 129
4. Waveform distortion factor per Figure 4, page 129
5. Frequency per Figure 5, page 129

8.3.2 Transient

1. Voltage Transient (Refer to MIL-704D Doc. Figure 5.)
   High voltage Transient per Figure 6, page 130
   Low voltage Transient per Figure 7, page 130

2. Frequency Transient (Refer to MIL-704D Doc. Figure 6)
   High frequency Transient per Figure 8, page 131
   Low frequency Transient per Figure 9, page 131

8.3.3 Abnormal operation

1. Abnormal voltage (Refer to MIL-704D Doc. Figure 7).
   Overvoltage per Figure 10, page 132
   Undervoltage per Figure 11, page 132

2. Abnormal frequency (Refer to MIL-704D Doc. Figure 8)
   Overfrequency per Figure 12, page 133
   Underfrequency per Figure 13, page 133

8.3.4 Emergency operation (Refer to MIL-704D Doc. 5.2.5)

1. Voltage per Figure 14, page 134
2. Frequency per Figure 15, page 134

8.4 KEYPAD ENTRY (Refer to page 127 for Keyboard flow chart)

To perform a test from the key board, the following key sequence is required:

704 ENT

The following screen will appear:

MIL704D:SelA,B,C
ENT=all CLR=EXIT

Pressing the A, B, C or any combination selects the phase in test. Press ENT without the phase select for simultaneous three-phase test.

The following screen appears for a short time.

TEST A,B,C
CLR to Reselect

The next screen is:

Apply Nom Output
Press ENT

When ENT is selected the following screen appears:

Press MNU to
Select Test

The MNU screen has two lines of selection shown at a time.

There are 3 different types of operations that can be selected from a MENU acreen. If the word MENU appears for the item selected, another MENU screen will be displayed. If the word TEST appears fir the item selected, the test will start. The display will return to the previous screen if the word RETURN appears for the item selected.

The Main Menu will appear as follows:

```
1=Steady St Menu
2=Transient Menu
3=Abnormal Menu
4=Emergency Menu
5=MIL704D Test
6=Return
```

If key 1 is selected "Steady State: from the Main Menu, the following Menu will appear:

```
1=Voltage Test
2=Unbalance Test
3=Phase dif Test
4=Wave dist Test
5=Frequency Test
6=Steady St Test
7=Return
```

If key 2 is selected "Transient" from the Main Menu, the following Menu will appear:

```
1=Volt Trns Menu
2=Freq Trns Menu
3=Transient Test
4=Return
```

If key 1 is selected from the Transient Menu the following Menu will appear:

```
1=High Volt Test
2=Low Volt Test
3=Volt Trns Test
4=Return
```

If key 2 is selected from the Transient Menu the following Menu will appear:

```
1=High Freq Test
2=Low Freq Test
3=Freq Trns Test
4=Return
```

If key 3 is selected "Abnormal" from the Main Menu, the following Menu will appear:

```
1=Abnl Volt Menu
2=Abnl Freq Menu
3=Abnormal Test
4=Return to Main Menu
```

If key 1 is selected from the "Abnormal" Menu, the following Menu will appear:

```
1=Overvolt Test
2=Undervolt Test
3=Abnl Volt Test
4=Return
```

If key 2 is selected from the "Abnormal" menu, the following Menu will appear:

```
1=Overfreq Test
2=Underfreq Test
3=Abnl Freq Test
4=Return
```

If key 4 is selected "Emergency" from the Main Menu, the following Menu will appear:

```
1=Emrg Volt Test
2=Emrg Freq Test
3=Emergency Test
4=Return
```

8.5 GPIB OPERATION (Refer to page 128 for syntax diagram)

The following command will be used to execute the appropriate part of all of the test.

```
MIL704D[A][B][C]                    Test all MIL704D Sections
MIL704D[A][B][C] :STEady state
MIL704D[A][B][C] :STEady state :VOLTage
MIL704D[A][B][C] :STEady state :VOLTage :UNBalance
MIL704D[A][B][C] :STEady state :PHASe :DIFFerence
MIL704D[A][B][C] :STEady state :WAVeform :DISTortion
MIL704D :STEady state :FREQuency

MIL704D[A][B][C] :TRANsient
MIL704D[A][B][C] :TRANsient :VOLTage
MIL704D[A][B][C] :TRANsient :VOLTage :HIGH
MIL704D[A][B][C] :TRANsient :VOLTage :LOW
MIL704D :TRANsient :FREQuency
MIL704D :TRANsient :FREQuency:HIGH
MIL704D :TRANsient :FREQuency:LOW

MIL704D[A][B][C] :ABNormal
MIL704D[A][B][C] :ABNormal :VOLTage
MIL704D[A][B][C] :ABNormal :VOLTage :OVER
MIL704D[A][B][C] :ABNormal :VOLTage :UNDer
MIL704D :ABNormal :FREQuency
MIL704D :ABNormal :FREQuency :OVER
MIL704D :ABNormal :FREQuency :UNDer

MIL704D[A][B][C] :EMERgency
MIL704D[A][B][C] :EMERgency :VOLTage
MIL704D :EMERgency :FREQuency
```

All lower case letters are option. [A],[B],[C] represent phase A, B, C. They are optional if they are omitted; the test will be applied to all three phases.

8.6 TEST SPECIFICATION

8.6.1 STEADY STATE

1. Steady state voltage test (Figure 1).

   MIL704D[A][B][C] :STEady state :VOLTage

   This test will change the output voltage simultaneously from 115 volts to 108 volts for 5 seconds to 118 volts for 5 seconds. The unselected phases will remain at 115 volts.

2. Steady state voltage unbalance test (Figure 2).

   MIL704D[A][B][C] :STEady state :VOLTage :UNBalance

   This test will change the output for phase A from 115 volts to 112 volts for 5 seconds and to 118 volts for 5 seconds. The test will repeat itself for phase B and phase C if they are selected.

3. Steady state voltage phase difference test (Figure 3).

   MIL704D[A][B][C] :STEady state :PHASe :DIFFerence

   This test will change phase B program phase angle, if it is selected, from 240 degrees to 236 degrees for 5 seconds and to 244 degrees for another 5 seconds. The test will be repeated for phase C, if it is selected.

4. Steady state waveform distortion (Figure 4).

   MIL704D[A][B][C] :STEady state :WAVeform :DISTortion

   This test will generate a 5% distortion on the selected phase for 5 seconds.

5. Steady state frequency test (Figure 5).

   MIL704D :STEady state :FREQuency

   This test will change the programmed frequency from 400 Hz to 393 Hz for 5 seconds then to 407 Hz for 5 seconds.

6. Steady state test

MIL704D[A][B][C] :STEady state

This test will perform all the above five tests in the same order above. A 5 second pause between tests is asserted.

8.6.2. TRANSIENT

1. Transient high voltage test (Figure 6).

MIL704D[A][B][C] :TRANsient :VOLTage :HIGH

This test requires a 180 volts range. A range change will take place if the power source is not set for the high range. The output voltage will drop temporarily to allow for range change and after 5 seconds the test will begin.

The output will go to 180 volts for 10 msec and will drop gradually to 115 volts in 81.25 msec. After 5 seconds, a range change will take place to the original setup. This is a simultaneous test to all selected phases.

2. Transient low voltage test (Figure 7).

MIL704D[A][B][C] :TRANsient :VOLTage :LOW

The output voltage will drop to 80 volts for 10 msec. It will gradually rise to 115 volts in 81.25 msec. This test is a simultaneous test to all selected phases.

3. Transient voltage test

MIL704D[A][B][C] :TRANsient :VOLTage

This test will combine High voltage transient and Low voltage transient. There will be a pause of 5 seconds between tests. If the voltage range is below 180 volts, the High voltage transient test will not take place.

4. Transient high frequency test (Figure 8).

MIL704D :TRANsient :FREQuency:HIGH

This test will step up the frequency from 400 Hz to 425 Hz. The frequency will step down to 400 Hz in the following sequence:

425 Hz for 1 second
420 Hz for 4 seconds
410 Hz for 5 seconds
407 Hz for 4 seconds

5. Transient low frequency test (Figure 9).

   MIL704D :TRANsient :FREQuency:LOW

   This test will step down the frequency from 400 Hz to 375 Hz. The frequency will step up to 400 Hz in the following sequence:

   375 Hz for 1 second
   380 Hz for 4 seconds
   390 Hz for 5 seconds
   393 Hz for 4 seconds

6. Transient frequency test

   MIL704D :TRANsient :FREQuency

   This test will combine the high frequency transient and the low frequency transient. There is a pause of 5 seconds between tests.

8.6.3. ABNORMAL

1. Abnormal overvoltage test (Figure 10).

   MIL704D[A][B][C] :ABNormal :VOLTage :OVER

   This test requires a 180 volt range. A range change will take place if the power source is not set for the high range. The output voltage will drop temporarily to allow for the range change and after 5 seconds the test will begin.

   The output will go to 180 volts for 50 msec and will drop gradually to 125 volts in 450 msec. The output voltage will remain at 125 volts for 9.5 seconds before it drops to 115 volts. After 5 seconds, a range change will take place to the original setup. This is a simultaneous test to all selected phases.

2. Abnormal undervoltage test (Figure 11).

   MIL704D[A][B][C] :ABNormal :VOLTage :UNDer

   The output voltage will drop to 0 volts for 7 seconds. It step up to 100 volts for 3 seconds before it will go to 115 volts. This is a simultaneous test for all selected phases.

3. Abnormal voltage test

MIL704D[A][B][C] :ABNormal :VOLTage

This test will combine Abnormal overvoltage and Abnormal undervoltage. There will be a pause of 5 seconds between tests. If the voltage range is below 180 volts the Abnormal overvoltage test will not take place.

4. Abnormal overfrequency test (Figure 12)

MIL704D :ABNormal :FREQuency :OVER

This test will step up the frequency from 400 Hz to 480 Hz. The frequency will step down to 400 Hz in the following sequence:

480 Hz for 5 seconds
425 Hz for 5 seconds

5. Abnormal underfrequency test (Figure 13)

MIL704D :ABNormal :FREQuency :UNDer

This test will step down the frequency from 400 Hz to 0 Hz. The frequency will step up to 400 Hz in the following sequence:

0 Hz for 5 seconds
375 Hz for 5 seconds

6. Abnormal frequency test

MIL704D :ABNormal :FREQuency

This test will combine the Abnormal overfrequency and the Abnormal underfrequency . There is a pause for 5 seconds between tests.

8.6.4. EMERGENCY

1. Emergency voltage test (Figure 14).

MIL704D[A][B][C] :EMERgency :VOLTage

This test will step down the voltage to 104 volts for 5 seconds. Also it will step up the voltage to 122 volts for another 5 seconds.

2. Emergency frequency test (Figure 15).

MIL704D :EMERgency :FREQuency

This test will step down the frequency to 360 Hz for 5 seconds then will step up the frequency to 440 Hz for 5 seconds.

3. Emergency test

MIL704D[A][B][C] :EMERgency

This test will combine the voltage emergency test and the frequency emergency test. A pause of 5 seconds between tests is asserted.

8.6.5 MIL704D TEST

MIL704D[A][B][C]

This test will combine all the tests listed above in one test in the sequence listed. A 5 second time delay separate the parts of the test. Tests will be performed on the selected phases only.



All returns return to previous screen



MIL704D SYNTAX FLOW

Steady state

Voltage figure 1



Voltage Unbalance figure 2



Voltage Phase difference figure 3



Distortion factor figure 4

Frequency figure 5



all time interval are 5 seconds



Voltage transient
figure 6,7



Frequency Transient
figure 8,9



Abnormal operation
figure 10,11



Abnormal Frequency
figure 12,13

Emergency Voltage figure 14



Emergency Frequency figure 15



all time interval are 5 seconds

SECTION 9

2-PHASE OPTION (2P)

9.1 GENERAL

The output appears from the Phase A and Phase C output terminals for this option. Phase C leads Phase A by 90 degrees.

SECTION 10.0

RTCA/DO-160C

10.1 GENERAL

The RTCA/DO-160C option is capable of performing all sections of RTCA/DO-160C for the AC Source signal.

10.2 INITIAL SETUP

Nominal parameters for the AC Power source shall be as follows:

Output Voltage	115V L-N
Output Frequency	400 Hz
Output Phase Angle	B 240V
	C 120V

10.3 TEST PERFORMED

10.3.1 NORMAL STATE

1. Normal State Voltage and Frequency test
2. Voltage Unbalance test
3. Waveform Distortion test
4. Voltage Modulation test
5. Frequency Modulation test
6. Momentary Power Interrupt (Undervoltage) test
7. Voltage Surge (Overvoltage) test

10.3.2 EMERGENCY TEST

1. Emergency Voltage and Frequency test
2. Voltage Unbalance test

10.3.3 ABNORMAL TEST

1. Abnormal Voltage and Frequency test
2. Momentary Undervoltage test
3. Voltage Surge test

10.4 KEYPAD ENTRY (Refer to Figure 1 for Keyboard Flow Chart)

To perform a test from the keyboard, the following key sequence is required:

160 ENT

The following screen will appear:

DO160C: Sel A, B, C
ENT = all CLR = EXIT

Pressing the A, B, C or any combination selects the phase in test. Press ENT without the phase select for simultaneous three phase test.

The following screen appears for a short time:

Test A, B, C
CLR to Reselect

The next screen is:

Apply Nom output
Press ENT

When ENT is selected the following screen appears;

Press MNU to
Select Test

The MNU screen has two lines of selection shown at a time.

There are three different types of operations that can be selected from the MENU screen. If the word MENU appears for the items selected, another MENU screen will be displayed. If the word Test appears for the item selected, the test will start. The display will return to the previous screen if the word RETURN appears for the item selected.

The Main Menu will appears as follows:

1 = Normal Menu
2 = Emergency Menu
3 = Abnormal Menu
4 = Return

If Key 1 is selected "Normal Menu" from the Main Menu, the following Menu will appear:

```
1 = Volt/Freq Menu
2 = Unbalance Test
3 = Volt Mod Test
4 = Power Int Test
5 = Volt Surge Test
6 = Wave Dist Test
7 = Freq Mod Test
8 = Return
```

If Key 2 is selected "Emergency Menu" from the Main Menu, the following Menu will appear:

```
1 = Emg V/F Menu
2 = Emg Unbal Test
3 = Return
```

If Key 3 is selected "Abnormal Menu" from the Main Menu, the following Menu will appear:

```
1 = Ab Volt Menu
2 = Ab Vunder Test
3 = Ab Vsurge Test
4 = Return
```

If Key 1 is selected "Volt/Freq Menu" from the Normal Menu, the following Menu will appear:

```
1 = Under Volt Test
2 = Over Volt Test
3 = Return
```

If Key 1 is selected "Volt/Freq Menu" from the Emergency Menu, the following Menu will appear:

```
1 = Emg Vunder Test
2 = Emg Vover Test
3 = Return
```

If Key 1 is selected "Volt Menu" from the Abnormal Menu, the following Menu will appear:

```
1 = Ab Vunder Test
2 = Ab Vover Test
3 = Return
```

If Key 3 or Key 7 is selected from the "Normal Menu", another screen will appear as follows:

Enter Modulation
Rate in Hz and ENT.

The numeric value must be within the limits for the test performed. See Figure 2 and Figure 3.

If Key 4 is selected from the "Normal Menu", the following screen will appear as follows:

Enter Test
Number 1 to 15 and ENT (see Table 1)

10.5 GPIB OPERATION

The following command will be used to execute the appropriate section of DO-160C.

Remote Command

DO160[A][B][C] :NORMal state :VOLT_FREQ :MINinum
DO160[A][B][C] :NORMal state :VOLT_FREQ :MAXimum
DO160[A][B][C] :NORMal state :VOLTage :UNBalance
DO160[A][B][C] :NORMal state :WAVe form :DISTortion
DO160[A][B][C] :NORMal state :VOLTage :MODulation <numeric>
DO160[A][B][C] :NORMal state :FREQency :MODulation <numeric>
DO160[A][B][C] :NORMal state :VOLTage :UNDer<numeric>
DO160[A][B][C] :NORMAL state :VOLTage :OVER

DO160[A][B][C] :EMERgency :VOLT_FREQ :MINimum
DO160[A][B][C] :EMERgency :VOLT_FREQ :MAXimum
DO160[A][B][C] :EMERgency :VOLTage :UNBalance

DO160[A][B][C] :ABNormal stage :VOLTage :MINimum
DO160[A][B][C] :ABNormal state :VOLTage :MAXimum
DO160[A][B][C] :ABNormal stage :VOLTage :UNDer
DO160[A][B][C] :ABNormal state :VOLTage :OVER

10.6 TEST SPECIFICATION

10.6.1 NORMAL STATE

10.6.1.1 Normal State Minimum Voltage and Frequency Test

DO160[A][B][C] :NORMal state :VOLT_FREQ :MINimum

This test will change the output voltage for single phase from 115V to 104V and for three-phase from 115V to 105.5V and the frequency from 400 Hz to 380 Hz. The test will last for 30 minutes. The CLR Key in local operation will terminate the test at any time. Group execute trigger will terminate the test remotely. The unselected phases will remain at 115 volts.

10.6.1.2 Normal State Maximum Voltage and Frequency Test

DO160[A][B][C] :NORMal state :VOLT_FREQ :MAXimum

This test will change the output voltage for single phase from 115V to 122 volts and from 115V to 120.5 volts for three-phase and the frequency from 400 Hz to 420 Hz. The test will last for 30 minutes. The CLR Key in local operation will terminate the test at any time. Group execute trigger will terminate the test remotely. The unselected phase will remain at 115 volts.

10.6.1.3 Normal State Voltage Unbalance

DO160[A][B][C] :NORMal state :VOLTage :UNBalance

This test will change the output voltage for each phase from 115 volts to 112 volts and to 118 volts. The test for all three phases will last 30 minutes. The test can be terminated at any time.

10.6.1.4 Normal State Waveform Distortion

DO160[A][B][C] :NORMal state :WAVe form :DISTortion

This test will generate a 5% distortion on the selected phase. The test will last for 30 minutes. This test can be terminated at any time.

10.6.1.5 Normal State Voltage Modulation

DO160[A][B][C] :NORMal state :VOLTage :MODulation <numeric>

This test requires a numeric value equal to the modulation rate in Hz. See Figure 2. The amplitude modulation is calculated based on the modulation rate. This test will last for 2 minutes.

10.6.1.6 Normal State Frequency Modulation

DO160[A][B][C] :NORMal state :FREQency :MODulation <numeric>

This test requires a numeric value equal to the modulation rate in Hz. See Figure 3. The frequency modulation is calculated based on the modulation rate. This test will last for two minutes.

10.6.1.7 Normal State Power Interrupt

DO160[A][B][C] :NORMal state :VOLTage :UNDer<numeric>

This test requires a numeric value equal to the test number. There are 15 tests. See Table 1.

10.6.1.8 Normal State Voltage Surge

DO160[A][B][C] :NORMAL state :VOLTage :OVER

This test requires a power source with 160 volt output. If the power source has a dual voltage range, the test will select the high voltage range to complete the test.

The output voltage will remain at 115 volts for 5 minutes before it rises to 160 volts for 20 msec then drops to 60 volts for 30 msec before returning to 115 volts.

10.6.2 EMERGENCY TEST

This test could be performed in addition to the Normal State test for equipment designed to operate under emergency electrical system.

10.6.2.1 Emergency State Minimum Voltage and Frequency Test

DO160[A][B][C] :EMERgency :VOLT_FREQ :MINimum

This test is similar to the test at 6.1.1 except the output frequency changes from 400 Hz to 360 Hz.

10.6.2.2 Emergency State Maximum Voltage and Frequency Test

DO160[A][B][C] :EMERgency :VOLT_FREQ :MAXimum

This test is similar to the test at 5.1.2 except the output frequency changes from 400 Hz to 440 Hz.

10.6.2.3 Emergency State Voltage Unbalance

DO160[A][B][C] :EMERgency :VOLTage :UNBalance

This test is similar to the test at 6.1.3 except the output voltage changes from 115 volts to 111 volts and from 115 volts to 119 volts.

10.6.3 ABNORMAL STATE

10.6.3.1 Abnormal State Minimum Voltage

DO160[A][B][C] :ABNormal stage :VOLTage :MINimum

This test will drop the output to 97 volts for 5 minutes

10.6.3.2 Abnormal State Maximum Voltage

DO160[A][B][C] :ABNormal state :VOLTage :MAXimum

This test will raise the output voltage from 115 volts to 135 volts for 5 minutes.

10.6.3.3 Abnormal State Undervoltage

DO160[A][B][C] :ABNormal stage :VOLTage :UNDer

This test will drop the output voltage from 115 volts to 60 volts for 7 seconds.

10.6.3.4 Abnormal State Voltage Surge

DO160[A][B][C] :ABNormal state :VOLTage :OVER

This test requires an output voltage range of 180 volts. If the power source is a dual voltage range, this test will select the upper voltage range if the lower voltage ranges is less than 180 volts.

The output voltage will rise to 180 volts for 100 msec and will drop to 148 volts for 1 sec before it returns to 115 volts.



FIGURE 1

All returns return to previous scre



FREQUENCY CHARACTERISTICS OF AC VOLTAGE MODULATION ENVELOPE

FIGURE 2



CHARACTERISITICS OF AC FREQUENCY MODULATION

FIGURE 3



NOTES: 1. Definitions

T1 – Power interrupt time.
T2 – Time it would take for the applied voltage to decay from V (nom) to zero volts>
T3 – Time it would take for the applied voltage to rise from zero to V (nom) volts.
V MIN – The minimum level (expressed as a percentage of V NOMINAL) to which the applied voltage is permitted to decay.

2. Tolerance to T1, T2 and V MIN = ±10%

TEST CONDITION NO.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
T1 (MILLISECONDS)	2	10	25	50	75	100	200	1000	10	25	50	75	100	200	1000
T2 (MILLISECONDS)	<1	20*	20	20	20	20	20	20	50*	50*	50	50	50	50	50
T3 (MILLISECONDS)	<1	8	5	5	5	5	5	5	20	20	20	20	20	20	20
% OF V NOMINAL (V MIN)	0	50	15	10	5	0	0	0	20	50	0	15	5	0	0

* VOLTAGE WILL NOT REACH ZERO IN THIS TEST CONDITION.

TABLE 1

Appendix A

Number	Vendor Name	City	State
0000A	Electricord	Westfield	PA
0000C	Jackson Bros.	Woodley-Surrey	GB
0000S(28564)	OPCDA (Refac Elect. Corp.)	Winsted	CT
0000W	Milton Ross Co.	Southampton	PA
0000Z(52745)	Timco	Los Angeles	CA
000AC	Itac	Santa Clara	CA
000AD(55112)	Plessey (Westlake Cap, Inc.)	Westlake Village	CA
000AG	LaFrance	Philadelphia	PA
000AH(54363)	Jan Crystal	Ft. Myers	CA
000AL(53495)	Data Components, Inc.	Gardena	CA
000AM	Kraus & Reimer	Santa Monica	CA
000AM	Ritz Instrument Transformer	Redondo Beach	CA
000AS	Switches Incorporated	Mt. View	CA
000AT(62643)	United Chemi-Con	Rosemont	IL
000AU	JMJ Technical Prod. Inc.	Kendall Park	NJ
000AV(61837)	Semi Processes, Inc.	San Jose	CA
000AW	Hirose	Chatsworth	CA
000AX(63878)	Apetronics	Mentor	OH
000AY	Silicon Power Cube Corp.	Long Beach	CA
000AZ(61271)	Fujitsu	Santa Clara	CA
000BA(61964)	Omron Electronics, Inc.	Schaumburg	IL
000BB	Hallmark Metals, Inc.	Glendora	CA
000BC	Toshiba America, Inc.	Tustin	CA
000BD(55982)	Electronic Essentials	Woodside	NY
000BE(57856)	Kel-Am	Eldon	MO
000BF(55285)	Berquist	Minneapolis	MN
000BG	Panasonic	Secaucus	NY
000BH	Century Components	Canyon Country	CA
000BI(54186)	Micro Power Systems	Santa Clara	CA
000BJ(06776)	Robinson Nugent	New Albany	IN
000BL(13150)	Beau Products (Vernitron)	Laconia	NH
000BM(91725)	Corebinder (Gerrard AJ & Co.)	Des Plaines	IL
000BO	Mitsubishi Electronics Amer.	Sunnyvale	CA
000BP	Silicon Power Cube	Long Beach	CA
000BR	Secap	Bagnolet	France
000BS	Panel Components Corp.	Santa Rosa	CA
00544	Metal-Cal Div., Avery Prod.	Inglewood	CA
00779	AMP Inc.	Harrisburg	PA
00853	Sangamo Electronic Co.	Pickens	SC
00866	Goe Eng. Co., Inc.	City of Industry	CA
01002	G.E. Co., Ind. & Pwr. Cap. Dept.	John St. Hudson Falls	NY
01121	Allen-Bradley Co.	Milwaukee	WI
01139	G.E. Co., Silicone Prod.	Waterford	NY
01295	Texas Instruments	Dallas	TX
01961	Pulse Engineering, Inc.	San Diego	CA
02111	Spectrol Electronics	City of Industry	CA
02113	Coilcraft, Inc.	Cary	IL
02335	Fairchild Controls Corp.	Hicksville,LI	NY
02375	American Insulating Mach. Co.	Philadelphia	PA
02536	Texas Electronics Co.	Dallas	TX
02660	Amphenol Corporation	Broadview	IL
02768	Illinois Tool Works, Inc.	Des Plains	IL
02799	Use Code #72136		
03507	General Electric Company	Syracuse	NY
03508	General Electric Company	Syracuse	NY
03797	Eldema Corporation	Compton	CA
03888	Pyrofilm Resistor Co., Inc.	Cedar Knolls	NJ
03911	Claires Corporation	New York	NY
04009	Arrow-Hart and Hegeman Elec.	Hartford	CT
04099	Capco, Inc.	Grand Junction	CO
04713	Motorola Semiconductor Prod.	Phoenix	AZ
04729	Universal Components Corp.	Green Brook	NJ
04963	J-W	St. Paul	MN
05245	Corcom Inc.	Chicago	IL
05276	Pomona Electronics., Inc.	Pomona	CA
05397	Kemet, Union Carbide Corp.	Cleveland	OH
05791	Lyn-Tron, Inc.	Rockbank	CA
05820	Wakefield Engineering, Inc.	Wakefield	MA
05972	Loctite Corp.	Newington	CT
06383	Panduit Corp.	Tinley Park	IL
06514	Stantron, Myco Metal Prod.	N. Hollywood	CA
06540	Amaton Elect. Hardware	New Rochelle	NY
06665	Precision Monolithics Inc.	Santa Clara	CA
06776	Robinson Nugent, Inc.	New Albany	IN
06915	Richco Plastics, Co.	Chicago	IL
07088	Kelvin Electric Company	Van Nuys	CA
07263	Fairchild Camera & Instr.	Mt. View	CA
07387	Birtcher Corporation	Los Angeles	CA
07556	Umitact Calabro Plastics	Upper Darby	PA
07633	Epoxy Prod. Co., Allied Prod. Corp.	New Haven	CT
07707	USM Corp. (USM Fastener Div)	Shelton	CT
07716	IMC Incorporated	Burrington	IA
07910	Use Code #13818		
08028	Loctite (Auto & Consumer Grp)	Mtn View	CA
08057	Spang Ind. (Magnetics Div)	Sandy Lake	PA
08065	Accurate Rubber and Plastics	San Diego	CA
08261	Spectra Strip (Amphenol)	Garden Grove	
08289	Blinn Delbert Co.	Pomona	CA
08353	Bristol Co. of Canada	Toronoto, Ont	Canada
08730	Oakby & Barton (Vemaline Prod. Div.)	Warwick	RI
08779	Signal Transformer	Brooklyn	NY
09214	GE (Semiconductor Prod. Div)	Auburn	NY
09353	C & K Components	Newton	MA
09922	Burndy Corp.	Norwack	CT
10389	Chicago Switch	Chicago	IL
11015	Cherry/Textron (Fastener Div)	Santa Ana	CA
12408	Elpac Electronics	Santa Ana	CA
12697	Clarostat Mfg.	Dover	NH
13103	Thermalloy Company	Dallas	TX
13150	Vernitron Corp (Beau Prod.)	Laconia	NH
13404	Sperry Corp. Elec. Systems	Great Neck	NY
13919	Burr-Brown	Tucson	AZ
14099	Semtech Corporation	Newbury Park	CA
14604	Elwood Sensors Inc.	Cranston	RI
14655	Cornell-Dubilier Elect. Corp.	Newark	NJ
14726	Bollingworth Co.	Phoenixville	PA
14752	Electro Cube, Inc.	San Gabriel	CA
14908	Electronic Instrument and Specialty Corp.	Stoneham	MA
15238	ITT Semiconductors	Lawrence	MA
15454	Ametek Znk (Rodan Div)	Anaheim	CA
15636	Elec-trol	Northridge	CA
15801	Fenwell Electronics	Framingham	MA
15818	Amelco Teledyne, Inc.	Mt. View	CA
15912	Amsley	Los Angeles	CA
16067	California Instruments Co.	San Diego	CA
16758	Delco Radio Div., Gen. Mtrs.	Kokomo	IN
16954	Dennison	Framingham	MS
17856	Siliconix, Inc.	Santa Clara	CA
18076	Umpco	City of Industry	CA
18178	Vactec, Inc.	Maryland Heights	MO
18310	Concord Electronics Corp.	New York	NY
18324	Signetics	Sunnyvale	CA
18612	Vishay Instruments, Inc.	Malvern	PA
18677	Scambe Mfg. Co. (Iero Corp.)	Monterey Park	CA
18722	RCA	Mountaintop	PA
18736	Voltronics Corp.	Hanover	NJ
19080	Robison Company	Hawthorne	CA
21604	Buckeye Stamping Company	Columbus	OH
21845	Solitron Devices (Semi-conductor Group)	Riviera Beach	FL
22599	Elastic Stop Nut Corp.	Van Nuys	CA
23050	Product Components Corp.	Hastings-on-Hudson	NY
23936	Pasotec, Inc.	San Francisco	CA
24011	ECC	Burlington	MA
24355	Analog Devices, Inc.	Norwood	MA
24444	General Semiconductor Inc.	Tempe	AZ
24796	Paralto, Inc.	Paramount	CA
24931	Specialty Connector Co., Inc.	Greenwood	IN
24972	AEG-Telefunken Corp.	Summerville	NJ
25403	Amperex Electronic Corp.	Slatersville	RI
25497	Meter Master	Los Angeles	CA
26405	Marathon Electric Mfg. Corp.	Bowling Green	OH
26806	American Zettler, Inc.	Costa Mesa	CA
27014	National Semi-Conductor Crp.	Santa Clara	CA
27191	Cutler-Hammer, Inc.	Milwaukee	WI
27264	Molex	Downers Grove	IL
27335	B & B Motor & Control Corp.	New York	NY
27556	IMB Electronic Products	Santa Fe Springs	CA
27683	Varo, Inc.	St. Garland	TX
27735	F-Dyne Electronics	Bridgeport	CT
27832	Hughes Aircraft	Newport Beach	CA
28480	Hewlett-Packard Co.	Palo Alto	CA
28520	Heyman Mfg. Company (Heyco)	Kenilworth	NJ
28606	Echlin Ltd.	Rexdale Ont.	Canada
29372	Rexnord Inc. Tridair Ind.	Torrance	CA
29593	Busaco Eng. Inc.	El Segundo	CA
30039	International Components Crp.	Asbury Park	NJ
30161	Aavid Engineering, Inc.	Laconia	NH
30897	Dorgan Company	Sylmar	CA
30983	Electra/Midland (Mepco/ Electra)	San Diego	CA
31827	Budwig Mfg. Co.	Ramona	CA
31951	Trididge, Inc.	Pittsburg	PA
32293	Interdil	Cupertino	CA
32559	Bivar, Inc.	Santa Ana	CA
32997	Bourns Inc. (Trimpot Div)	Riverside	CA
33005	Jewell Electrical Inst. Inc.	Manchester	NH
33335	Logic Dynamics, Inc.	Gardena	CA
33716	Kingsbacher Murray Co.	Los Angeles	CA
33855	Ducommun, Inc.	Los Angeles	CA
33901	Colber Corp.	Irvington	NJ
34238	Milis Resistor Co.	Los Alamitos	CA
34333	Silicon General	Westminster	CA
34649	Intel Corporation	Santa Clara	CA
35007	Aerovox Canada Ltd.	Amherst NS	Canada
37964	Linear Technology, Inc.	Burlington, Ont	CAN
44655	Ohmite Manufacturing Co.	Skokie	IL
45722	Parker-Kalon	Clifton	NJ
46384	Penn. Eng. and Mfg. Corp.	Doylestown	PA
50157	Midwest Components, Inc.	Hudsegon	MI
50522	Monsanto, Electronic Special Products	Cupertino	CA
50558	Electronic Concepts, Inc.	Eatontown	NJ
50811	Rowser Corp.	Santee	CA
51167	Aries Electronics, Inc.	Frenchtown	NJ
51506	Accurate Screw Machine Co.	Hutley	NJ
51705	ICO/Rally	Palo Alto	CA
52072	Circuit Assembly Corp.	Costa Mesa	CA
52745	Timco	Los Angeles	CA
53076	Kintex, Inc.	Buffalo	NY
53495	Data Components, Inc.	Gardena	CA
54361	Edwards Sheet Metal Works	Fredericktown	OH
54407	Power-One Co.	Camerillo	CA
55222	Samtek, Inc.	New Albany	NY
55566	RAF Electronic Hardwars, Inc.	Seymour	CT
56289	Sprague Electric Company	North Adams	MA
56637	RCD Components, Inc.	Manchester	NH
57640	United Chem-Con Corp.	Philadelphia	PA
57856	Kel-Am, Inc.	Eldon	MO
58474	Superior Electric Company	Bristol	CT
59730	Thomas and Betts Company	Elizabeth	NJ
59993	International Rectifier Semiconductor Div.	El Segundo	CA
60395	Xicor, Inc.	Milditas	CA
61294	Seeq Technology, Inc.	San Jose	CA
61441	Saronix	Palo Alto	CA
61529	Aromat Corp.	Mountainside	NJ
61735	Pulse Engineering, Inc.	College Park	MD
62483	Denkitron Corp. of America	Torrance	CA
62643	United Chemicon, Inc.	Rosemont	IL
62786	Hitachi America Ltd.	San Jose	CA
63743	Ward Leonard Electric Co.	Mt. Vernon	NY
63791	Stec Micromics, Inc.	New York	NY
70318	Allmetal Screw Prod. Co.	Garden City	NY
70903	Belden Manufacturing Co.	Chicago	IL
71218	Bud Industries, Inc.	Willoughby	OH
71279	Cambridge Thermionic Corp.	Cambridge	MA
71400	Bussman Mfg. Div. McGraw-Edison, Co.	St. Louis	MO
71450	CTS Corporation	Elkhart	IN
71468	ITT Cannon Electric, Inc.	Los Angeles	CA
71590	Centralab Div. Globe-Union	Milwaukee	WI
71707	Coto-Coil	Providence	RI
71744	Chicago Miniature Lampworks	Chicago	IL
71785	Cinch Manufacturing Company	Chicago	IL
71984	Dow Corning Corp.	Midland	MI
72136	Elmenco (Electro Motive)	Willimantic	CT
72619	Dialight Corporation	Brooklyn	NY
72699	General Instruments	Newark	NJ
72982	Erie Technological Prod. Inc.	Erie	PA
73138	Beckman Instruments, Inc.	Fullerton	CA
73612	Consolidated Electronic Wire and Cable Corp.	Chicago	IL
73734	Federal Screw Products, Inc.	Chicago	IL
74193	Heinemann Electric Company	Trenton	NJ
74545	Harvey Hubbell, Inc.	Bridgeport	CT
74840	Illinois Condenser Co.	Chicago	IL
74970	E.F. Johnson Company	Waseca	MN
75042	TRW Electronic Components	Philadelphia	PA
75382	Kulka Electric Corporation	Mt. Vernon	NY
75582	Lewis Mfg. Co.	Little Neck	NY
75915	Littlefuse, Inc.	Des Plaines	IL
76385	Minor Rubber Co., Inc.	Bloomfield	NJ
77062	Pabat Eng. Equipment Co.	Elizabeth	NJ
77132	United-Carr Inc., Fatwin Div	Waterbury	CT
77342	Potter and Bluefield Div, AMF	E. Princeton	IN
78189	Shakeproof Div, IL Tool Works	Chicago	IL
78553	Tinnerman Products, Inc.	Cleveland	OH
79130	Johns-Manville Products Corp	Chicago	IL
79136	Waldes Kohinoor Inc.	Long Island City	NY
79963	Zierick Mfg. Corp.	New Rochelle	NY
80031	Mepco/Electra	Morristown	NJ
80223	United Transformer Co.	New York	NY
80294	Bourns, Inc.	Riverside	CA
80495	High Voltage Engineering Corp (Anderson Pwr Prod. Div)	Brighton	MA
81095	Triad Transformer Corp	Venice	CA
81312	Winchester Electronics	Oakville	CT
81348	(Fed. Specs) Promulgated by General Services Administration Washington DC		
81349	Military Specification or Commercial Generic Number		
81541	Airpax Corp.	Cambridge	MD
81603	Raco Products Co.	Chicago	IL
81851	Bentley-Harris Mfg Co.	Lionville	PA
82104	Standard Grigsby	Aurora	IL
82389	Switchcraft, Inc.	Chicago	IL
82877	Rotron Mfg. Co., Inc.	Woodstock	NY
82893	Vector Electronics, Inc.	Sylmar	CA
83330	Herman H. Smith, Inc.	Brooklyn	NY
83486	Elco Tool & Screw Corp.	Rockford	IL
85480	Brady W.H. Co.	Milwaukee	WI
86684	RCA	Harrison	NJ
86928	Seastrom Mfg. Co., Inc.	Glendale	CA
87034	Marco-Oak Industries	Anaheim	CA
88245	Useco Div., Litton Ind.	Van Nuys	CA
90201	Mallory Capacitor Co.	Indianapolis	IN
91506	Augat, Inc.	Attleboro	MA
91637	Dale Electronics, Inc.	Columbus	NE
91662	Elco Corporation	Willow Grove	PA
91802	Industrial Devices, Inc.	Edgewater	NJ
91833	Keystone Electronics Corp.	New York	NY
91967	National Tel-Tronics	Meadville	PA
92194	Alpha Wire Corp.	Elizabeth	NJ
93303	Pentagon Products Co.	Washington	DC
94222	Southco, Inc.	Lester	PA
94696	Magnecraft Electric Co.	Chicago	IL
95146	Alco Electronic Prod., Inc.	No. Andover	MA
95303	RCA	Cincinnati	OH
95354	Methode Manufacturing Corp.	Rolling Meadows	IL
95566	Arnold Engineering Co.	Marengo	IL
95987	Weckesser Company, Inc.	Chicago	IL
96906	Military Std		
97525	Electronic Engineering Co.	Santa Ana	CA
98159	Rubber Teck, Inc.	Gardena	CA
98291	Sealecto Corp.	Mamaroneck	NY
98376	Iero Mfg. Co. (West)	Burbank	CA
98978	IERC	Burbank	CA
99017	Protective Closures Co., Inc. (Caplugs Div)	Buffalo	NY
99217	Bell Industries, Inc.	Delavan	WI
99742	Permacell	New Brunswick	NJ
99743	IMC	Maywood	CA
99800	Delevan Electronics Corp.	Aurora	NY

ONE YEAR WARRANTY

CALIFORNIA INSTRUMENTS CORPORATION warrants each instrument manufactured by them to be free from defects in material and workmanship for a period of one year from the date of shipment to the original purchaser. Excepted from this warranty are tubes, fuses, and batteries which carry the warranty of their original manufacturer where applicable. CALIFORNIA INSTRUMENTS will service, replace, or adjust any defective part or parts, free of charge, when the instrument is returned freight prepaid, and when examination reveals that the fault has not occurred because of misuse, abnormal conditions of operation, user modification, or attempted user repair. Equipment repaired beyond the effective date of warranty or when abnormal usage has occurred will be charged at applicable rates. CALIFORNIA INSTRUMENTS will submit an estimate for such charges before commencing repair, if so requested.

PROCEDURE FOR SERVICE

If a fault develops, notify CALIFORNIA INSTRUMENTS or its local representative, giving full details of the difficulty, including the model number and serial number. On receipt of this information, service information or a Return Material Authorization (RMA) number will be given. Add RMA No. to shipping label. Pack instrument carefully to prevent transportation damage, affix label to shipping container, and ship freight prepaid to the factory. CALIFORNIA INSTRUMENTS shall not be responsible for repair of damage due to improper handling or packing. Instruments returned without RMA No., or freight collect will be refused. Instruments repaired under Warranty will be returned by prepaid surface freight. Instruments repaired outside the Warranty period will be returned freight collect, F.O.B. CALIFORNIA INSTRUMENTS, San Diego, CA. If requested, an estimate of repair charges will be made before work begins on repairs not covered by the Warranty.

DAMAGE IN TRANSIT

The instrument should be tested as soon as it is received. If it fails to operate properly, or is damaged in any way, a claim should be filed immediately with the carrier. A full report of the damage should be obtained by the claim agent, and a copy of this report should be forwarded to us. CALIFORNIA INSTRUMENTS will prepare an estimate of repair cost and repair the instrument when authorized by the claim agent. Please include model number and serial number when referring to the instrument.

MP MASTER
MA28002